

OEM7

DEVELOPMENT KIT GUIDE

GM-14915145 Rev 3 October 2019

The OEM7 Development Kit (Dev Kit) provides a convenient way to access OEM7® input and output signals. The Dev Kit alone is used with NovAtel's OEM7700 and OEM7720 receiver cards. To use the Dev Kit with NovAtel's OEM719, OEM729 or OEM7600 receiver cards, an optional Interposer Card Kit is required.

Box Contents

The following is provided with your OEM7 Development Kit:

- OEM7 Development Board (NovAtel Part #01019417)
- One BNC-MMCX cable assembly (NovAtel Part #01019431)
- Two TNC-MMBX cable assemblies (NovAtel Part #01019599)
- Dev Kit power cable assembly (NovAtel Part #01019538)
- 2 m USB cable type A to micro B (NovAtel Part #60723119)
- 1.8 m null modem cable (NovAtel Part #01017658), DB-9 female/female to connect to COMs 1, 2 or 3.
- Four adhesive rubber feet (NovAtel Part #28325059)
- Four M3x0.5x10 mm standoffs (NovAtel Part #28423237)
- Four M3x0.5x6 mm Philips screws (NovAtel Part #35000306)
- Two 3 mm spacers (NovAtel Part #28423235)
- Two M2x8 socket head caps (NovAtel Part #28523067)

Optional Interposer Card Content

- OEM7 Interposer board (NovAtel Part #01019416) for use with (OEM729R, OEM729 and OEM719 receiver cards)
- One TNC-MCX cable assembly (NovAtel Part #01019429)
- One TNC-MMCX cable assembly (NovAtel Part #01019430)
- Four M3x0.5x14 mm standoffs (NovAtel Part #28423059)
- Five M3x0.5x10 mm standoffs (NovAtel Part #28423237)
- Six M3x0.5x12 mm standoffs (NovAtel Part #28423222)
- Four M3x0.5x8 mm standoffs (NovAtel Part #28423231)
- Five M3x0.5x6 mm Philips screw (NovAtel Part #35000306)

Optional OEM7600 Interposer Card Content


- OEM7600 Interposer Board (NovAtel Part #01020246)
- Six M3x0.5x10 mm standoffs (NovAtel Part #28423237)
- Ten M3x0.5x4 mm Philips screws (NovAtel Part #35023107)

Additional Equipment Required

Depending on the application, some or all of the following will be required:

- OEM7 series receiver card
- A Microsoft® Windows®-based computing device with a RS-232 DB-9, USB port or 10/100BASE-T port
- A +9 VDC to 36 VDC power supply, capable of supplying at least 10 W
- A quality antenna, such as NovAtel's GNSS-500 or GNSS-800 Series.
- A 50 ohm coaxial cable with a male TNC connector at the Dev Kit end, for connecting to the GNSS antenna. (Two if using an OEM7720 and two GNSS antennas.)
- If necessary, a 50 ohm coaxial cable with a male BNC connector at the Dev Kit end for connecting to an EXT OSC port (refer to **External Oscillator** and **Mounting the Coaxial Cable in the Bracket** sections on the other side of this sheet)
- If necessary, an RS-422 cable (COM1 or COM2) and CAN1 or CAN2 connection
- An RJ-45 Ethernet cable

See other side of this sheet for details on these ports, LEDs and button



See other side of this sheet for details on these ports

Questions or Comments

Contact NovAtel Customer Support to obtain copies of the Dev Kit BOM, schematics and assembly drawings. The OEM7 Dev Kit is not intended to be used as a reference design for implementation in end applications. Original component manufacturer design recommendations should be sought before incorporating any components used on the Dev Kit into an end application design. If you have any questions or comments regarding your OEM7 Development Kit, contact NovAtel using one of these methods:

Email: support@novatel.com

Web: www.novatel.com

Phone: 1-800-NOVATEL (U.S. & Canada)
403-295-4500 (International)



NovAtel and OEM7 are registered trademarks of NovAtel Inc. OEM719, OEM729, OEM7600, OEM7700 and OEM7720 are trademarks of NovAtel Inc. All other trademarks are the property of their respective owners. Content subject to change without notice. OEM7 Development Kit ©Copyright 2019 NovAtel Inc. All rights reserved. Printed in Canada on recycled paper. Recyclable.

Proper ESD precautions should be followed when handling boards.

Hardware Use


OEM Card	Size	# Included	NovAtel Standoff Part #	Connect Card to...	Standoff Insertion Position
Interposer Board	10 mm	5	28423237	Dev Board	A
OEM7720	10 mm	4	28423237	Dev Board	B
OEM7700					
OEM7600	M3 screws	4	35023107	Interposer Board	N/A
OEM729	14 mm	4	28423059	Interposer Board	D
OEM729R	12 mm	4	28423222	Interposer Board	E
OEM719 OEM719A OEM719B	8 mm	4	28423231	Interposer Board	F
Interposer Board to Dev Board	M3 screws	5	35000306		●
IMU (future use)	6 mm	4	28423223	Dev Board	Future use

Insert standoffs into appropriate holes for card(s) used. Secure using screws.

Attach the MCX, MMCX or MMBX connector of the coaxial cable(s) to the receiver BEFORE securing the receiver cards to the Dev Board with the standoffs and screws.

OEM7600/OEM7700/OEM7720 Development Board Switch Settings

Switch Label	Position	Function
S601	A=RS-422 B=RS-232	Select COM1 and COM2 RS-232 or RS-422 mode
	C=COM5 TXD/RXD D=COM2 CTS/RTS	Either activate COM5 or enable COM2 flow control
S301	C: 3V3=3V3, Default = C	Internal use only



OEM719/OEM729 Optional Interposer Card Switch Settings

Switch Label	Signal	OEM729	OEM719
S101	729 COM1 RS-422/232 (U201)	D=729 COM1 in RS-422 mode C=729 COM1 in RS-232 mode	n/a
S201	719 CAN MUX (U301)	n/a	B=CAN0 A=EVENT_OUT2 & EVENT_IN2
S301	729 COM3 MUX (U303)	A=GPIO & EVENT_IN2 B=COM3	n/a
S301	719 COM3/USB MUX (U304, U302)	n/a	C=COM3 D=USB & EVENT_IN1

Coaxial Cable Assembly (for ANT/OSC/EVENTS)

Connect this end as indicated below		Connect this end as indicated below		
Attach to Antenna port of receiver card	MCX	OEM719/OEM719A	TNC	GNSS Antenna
		#01019429		
	MMCX	OEM729/OEM729R/OEM7600		
		#01019430		
	MMBX	OEM719B/OEM7700/OEM7720		
		#01019599		
Attach to External Oscillator on receiver card or Event lines on Dev Board	MMCX	OEM729/OEM729R/Dev Board	BNC	OSC (External Oscillator) EVENTS
		#01019431		

Always connect the coaxial cable to the receiver card prior to attaching to the Dev Board or Interposer card.

External Oscillator

Some applications require greater precision than that possible with the OEM7 VCTCXO, in which case you may need to connect the OEM7 to an external high-stability oscillator, which may run at either 5 MHz or 10 MHz.

Antenna Selection


Select a quality GNSS antenna, such as one from NovAtel's 500 or 800 series. Contact your NovAtel representative or visit our web site www.novatel.com/products/gnss-antennas for a full range of available antenna options.

Mounting the Coaxial Cable into Bracket

The bracket openings are used to mount and secure the Antenna (ANT) and/or External Oscillator (OSC) connectors to the Development Board.

- Remove the top nut and washer from the TNC/BNC end of the coaxial cable. Set aside.
- Thread the TNC or BNC end of coaxial cable through the bracket from Dev Board side to the outside (either opening).
- Slide the washer and then the nut over the TNC or BNC end of the protruding coaxial cable and slide up against the external side of the bracket.
- Hand tighten nut to secure the cable and connector to the bracket.
- Connect antenna to receiver card or EVENT to the Dev Board.
- Continue to **Installation & Powering Steps** section or repeat as needed for second cable.

Attach the MCX, MMCX or MMBX connector of the coaxial cable(s) to the receiver BEFORE securing the receiver cards to the Dev Board with the standoffs and screws.



Warnings and Restrictions

For evaluation only, in Laboratory/Development Environments. The development kit is not finished electrical and electronic equipment (EEE) and is not intended for consumer use. It is intended solely for use for preliminary evaluation in laboratory/development environments by technically qualified experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems. The development kit should not be used as all or part of a finished end product.

Federal Communications Commission (FCC) and Industry Canada (IC) Notices:

This development kit is designed to allow:

- Product developers to evaluate electronic components, circuitry, or software associated with the kit to determine whether to incorporate such items in a finished product and
- Software developers to write software applications for use with the end product. This kit is not a finished product and when assembled may not be resold or otherwise marketed unless all required FCC and IC equipment authorizations are first obtained. Operation is subject to the condition that this product not cause harmful interference to licensed radio stations and that this product accept harmful interference.
- This kit generates, uses, and can radiate energy and has not been tested for compliance with the limits of digital devices pursuant to Part 15 of FCC or ICES-003 rules which are designed to provide reasonable protection against radio frequency interference.


EU Declaration of Conformity

Hereby, NovAtel Inc. declares that the OEM7 Development Kit is in compliance with Directive 2011/65/EU. The full text of the EU declaration of conformity is available at the following Internet address: www.novatel.com/products/compliance.

Status LED States

Left LED Stack from Top			Right LED Stack from Top		
LED#	Description	Color	LED#	Description	Color
6	n/a		7	n/a	
4	Status	GREEN*	5	ME_RDY	GREEN
2	Status	RED*	3	POS_VALID	GREEN
0	ERROR	RED	1	POWER	RED

* LED 2 and 4 represents the receiver card's onboard LED status (when on at the same time, they represent the yellow error status code). Search for *Status Indicator* in the OEM7 online documentation.



PIN	COM1		COM2 ¹		COM3, COM4, COM5
	RS-232	RS-422	RS-232	RS-422	
1	NC	NC	NC	NC	NC
2	RXD1	RX1+	RXD2	RX2+	RXD
3	TXD1	TX1+	TXD2	TX2+	TXD
4	NC	NC	NC	NC	NC
5	GND	GND	GND	GND	GND
6	NC	NC	NC	NC	NC
7	RTS1	TX1-	RTS2	TX2-	NC
8	CTS1	RX1-	CTS2	RX2-	NC
9	NC	NC	NC	NC	NC

¹ COM2 RTS/CTS MUX with COM5 TXD/RXD

PIN	CAN0	CAN1
1	NC	NC
2	CAN_L	CAN_L
3	GND	GND
4	NC	NC
5	GND	GND
6	GND	GND
7	CAN_H	CAN_H
8	NC	NC
9	12 V CAN power	12 V CAN power

Installation & Powering Steps

- Flip the Dev Board upside down. Attach the four provided rubber feet over the four white circles in each corner of the Dev Board. These provide stability for the board.
- Turn the Dev Board right side up and place on a flat stable surface.
- Ensure the steps listed in the **Mounting the Coaxial Cable into Bracket** section are complete before progressing to Step 4.
- If using, make the connections/attachments for the ANT/OSC cables using the TNC/BNC end of the coaxial cable and connect to receiver card or Dev Board as indicated in **Coaxial Cable Assembly** table.
- If needed, attach the Interposer card to the Dev Board using the provided standoffs and screws as indicated in the **Standoff Use** table on the other side of this sheet.
For the OEM7600, attach the OEM7600 to the OEM7600 Interposer board using M3 screws before attaching the Interposer Board to the Dev Board.
- If required, attach the applicable receiver card to the Interposer card using the provided standoffs and screws OR Attach applicable receiver card directly to the Dev Board using the provided standoffs and screws as indicated in the **Standoff Use** table on the other side of this sheet.
- If using, connect EVENT end cable to applicable EVENT connector on the Dev Board. Refer to the **Coaxial Cable Assembly** table on this page. For event connector locations, refer to the illustration on the other side of this sheet.
- Set external power supply to 9 V to 36 VDC.
- Set any Slide Switches on the Dev Board and, if using, the Interposer card. Refer to the **Switch Settings** tables on the other side of this sheet.
- Connect any communications equipment to be used.
- Connect the power cord and plug into external power supply.