



**OEM7[®] SPAN[®]
Installation and Operation
User Manual**

OEM7 SPAN Installation and Operation User Manual

Publication Number: OM-20000170

Revision Level: v3

Revision Date: September 2017

Firmware Version: 7.03.02 / OM7MR0302RN0000

Warranty

NovAtel Inc. warrants that its GNSS products are free from defects in materials and workmanship, subject to the conditions set forth on our web site: www.novatel.com/products/warranty/ and for the following time periods:

| | |
|------------------------|------------------|
| OEM7® Receivers | One (1) Year |
| GNSS Antenna Series | One (1) Year |
| Cables and Accessories | Ninety (90) Days |
| Software Warranty | One (1) Year |

Return instructions

To return products, refer to the instructions found at: www.novatel.com/warranty-return.

Proprietary Notice

Information in this document is subject to change without notice and does not represent a commitment on the part of NovAtel Inc. The software described in this document is furnished under a licence agreement or non-disclosure agreement. The software may be used or copied only in accordance with the terms of the agreement. It is against the law to copy the software on any medium except as specifically allowed in the license or non-disclosure agreement.

No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose without the express written permission of a duly authorized representative of NovAtel Inc.

The information contained within this manual is believed to be true and correct at the time of publication.

NovAtel, OEM7, SPAN, ALIGN, VEXXIS, Inertial Explorer and Waypoint are registered trademarks of NovAtel Inc.

OEM719, OEM729, OEM7700, OEM7720, PwrPak7, NovAtel CORRECT and NovAtel Connect are trademarks of NovAtel Inc.

All other product or brand names are trademarks of their respective holders.

© Copyright 2017 NovAtel Inc. All rights reserved. Unpublished rights reserved under International copyright laws.

Table of Contents

OEM7® SPAN® Installation and Operation User Manual

| | |
|--|---|
| OEM7 SPAN Installation and Operation User Manual | 2 |
| Warranty | 2 |
| Return instructions | 2 |
| Proprietary Notice | 2 |

Figures

Tables

Notices Receiver Card

| | |
|--|----|
| FCC | 16 |
| Innovation, Science and Economic Development (ISED) Canada | 16 |
| European Union (EU) | 16 |
| WEEE | 16 |
| RoHS | 17 |
| REACH | 17 |
| Ethernet Port | 17 |
| Lightning Protection Installation and Grounding Procedure | 18 |
| What is the hazard? | 18 |
| Hazard Impact | 18 |
| Actions to Mitigate Lightning Hazards | 18 |
| Conventions | 20 |

Customer Support

| | |
|--|----|
| NovAtel Knowledge Base | 21 |
| Before Contacting Customer Support | 21 |
| Contact Information | 21 |

Chapter 1 OEM7 SPAN Overview

| | |
|---|----|
| 1.1 Fundamentals of GNSS+INS | 23 |
| 1.2 Models and Features | 24 |
| 1.2.1 INS Options | 24 |
| 1.2.2 IMU Grade | 25 |
| 1.3 Related Documents and Information | 26 |

Chapter 2 SPAN Installation

| | |
|---|----|
| 2.1 OEM7 Receiver Card Installation | 27 |
| 2.1.1 Selecting a GNSS Antenna | 29 |
| 2.1.2 Choosing a Coaxial Cable | 29 |
| 2.1.3 Mounting the GNSS Antenna | 30 |
| 2.1.4 Mount the IMU | 30 |
| 2.1.5 Connect the IMU to the OEM7 Receiver Card | 32 |
| Connect Directly to the IMU | 43 |
| Use an OEM6 Receiver Command | 43 |
| 2.1.6 Connect Power | 44 |
| 2.2 MIC Installation | 45 |
| 2.2.1 Install a MIC in a Stack Up Configuration | 45 |
| 2.2.2 Install a MIC in a Standalone Configuration | 51 |

| | | |
|-------|--|----|
| 2.3 | UIC Installation | 56 |
| 2.3.1 | Mount the SPAN System Components | 58 |
| 2.3.2 | Connect the IMU to the UIC | 59 |
| 2.3.3 | Connect the UIC to a receiver | 59 |
| 2.3.4 | Connect Power to the UIC and OEM7 Receiver | 60 |
| 2.3.5 | UIC Status LEDs | 60 |
| 2.4 | PwrPak7 Installation | 61 |
| 2.4.1 | Connect the IMU to the PwrPak7 | 63 |
| 2.5 | PwrPak7-E1 Installation | 64 |
| 2.6 | Wheel Sensor Installation | 66 |
| 2.6.1 | Wheel Sensor Requirements | 66 |
| 2.6.2 | Wheel Sensor Connection | 67 |
| 2.7 | IMU LEDs | 69 |

Chapter 3 SPAN Operation

| | | |
|-------|---|-----|
| 3.1 | Definition of Reference Frames Within SPAN | 71 |
| 3.1.1 | The Local-Level Frame (ENU) | 71 |
| 3.1.2 | The IMU Body Frame | 72 |
| 3.1.3 | The Vehicle Frame | 72 |
| 3.1.4 | The User Output Frame | 73 |
| 3.2 | SPAN Translations and Rotations | 73 |
| 3.2.1 | Translational Offsets | 73 |
| 3.2.2 | Rotational Offsets | 75 |
| 3.3 | Software Configuration | 77 |
| 3.3.1 | Minimum Recommended Configuration | 77 |
| 3.3.2 | GNSS Configuration | 77 |
| 3.3.3 | INS Profiles | 77 |
| 3.3.4 | SPAN Configuration | 79 |
| 3.4 | Real-Time Operation | 82 |
| 3.4.1 | System Start-Up and Alignment Techniques | 84 |
| 3.4.2 | INS Seed / Fast INS Initialization | 86 |
| | Saving | 86 |
| | Use at Boot-up | 86 |
| | Alignment Type: Bits 26-28 | 87 |
| | NVM Seed Status: Bits 29-31 | 88 |
| 3.4.3 | Navigation Mode | 88 |
| 3.4.4 | Data Collection | 88 |
| 3.4.5 | Lever Arm Calibration Routine | 90 |
| 3.4.6 | Body to Vehicle Frame Rotation Calibration Routine | 91 |
| 3.4.7 | Multi-Line Body to Vehicle Frame Rotation Calibration Routine | 92 |
| 3.5 | Synchronizing External Equipment | 94 |
| 3.5.1 | Configuring an Input Strobe | 94 |
| 3.6 | Adding Timed Sensor Triggers | 95 |
| 3.6.1 | Configuring the Hardware | 95 |
| 3.6.2 | Configuring the Software | 96 |
| 3.6.3 | Using Timed Event Pulses | 96 |
| 3.6.4 | Recording Incoming Sensor Events | 96 |
| 3.7 | SPAN Wheel Sensor Configuration | 96 |
| 3.7.1 | Wheel Sensor Data Collected on the PwrPak7 | 97 |
| 3.7.2 | Wheel Sensor Data Collected on IMU | 98 |
| 3.8 | Azimuth Sources on a SPAN System | 98 |
| 3.8.1 | Course Over Ground | 99 |
| 3.8.2 | Inertial Azimuth | 99 |
| 3.8.3 | ALIGN Azimuth | 99 |
| 3.9 | Data Collection for Post Processing | 100 |

| | | |
|--------|---|-----|
| 3.10 | Firmware Updates and Model Upgrades | 101 |
| 3.11 | Variable Lever Arm | 101 |
| 3.11.1 | Reference Frame Description | 101 |
| 3.11.2 | How to Use Variable Lever Arm | 103 |
| 3.12 | Relative INS | 105 |
| 3.12.1 | Configure Relative INS | 106 |

Chapter 4 SPAN with Dual Antenna

| | | |
|-------|--|-----|
| 4.1 | Installation | 108 |
| 4.2 | Configuring ALIGN with SPAN | 110 |
| 4.3 | Configuring SPAN with ALIGN | 111 |
| 4.3.1 | Alignment on a Moving Vessel - Aided Transfer Alignment | 112 |
| 4.3.2 | Alignment on a Stationary Vehicle - Aided Static Alignment | 112 |
| 4.3.3 | Unaided Alignment | 112 |
| 4.3.4 | Automatic Alignment Mode - Automatic Alignment (default) | 112 |
| 4.4 | SPAN ALIGN Attitude Updates | 112 |

APPENDIX A IMU Technical Specifications

| | | |
|-------|---|-----|
| A.1 | HG1700 IMU (single-connector enclosure) | 115 |
| A.1.1 | HG1700 IMU Mechanical Drawings | 116 |
| A.1.2 | HG1700 IMU Performance | 118 |
| A.1.3 | HG1700 Electrical and Environmental | 119 |
| A.1.4 | Interface Cable for the HG1700 IMU | 119 |
| A.2 | IMU-CPT | 120 |
| A.2.1 | IMU-CPT Mechanical Drawings | 121 |
| A.2.2 | IMU-CPT Sensor Specifications | 123 |
| A.2.3 | IMU-CPT Electrical and Environmental | 124 |
| A.2.4 | IMU-CPT Cable | 125 |
| A.3 | IMU-FSAS | 127 |
| A.3.1 | IMU-FSAS Mechanical Drawings | 128 |
| A.3.2 | IMU-FSAS Performance | 131 |
| A.3.3 | IMU-FSAS Electrical and Environmental | 131 |
| A.3.4 | Interface Cable for IMU-FSAS | 132 |
| A.3.5 | IMU-FSAS Cable with Wheel Sensor | 132 |
| A.4 | IMU-HG1900 | 135 |
| A.4.1 | IMU-HG1900 Mechanical Drawings | 136 |
| A.4.2 | IMU-HG1900 Sensor Specifications | 138 |
| A.4.3 | IMU-HG1900 Electrical and Environmental | 139 |
| A.4.4 | IMU-HG1900 Cables | 139 |
| A.5 | IMU-IGM | 140 |
| A.5.1 | IMU-IGM Mechanical Drawings | 141 |
| A.5.2 | IMU-IGM Ports | 143 |
| A.5.3 | IMU-IGM Sensor Specifications | 145 |
| A.5.4 | IMU-IGM Electrical and Environmental | 146 |
| A.5.5 | IMU-IGM Interface Cable | 147 |
| A.6 | IMU-ISA-100C | 149 |
| A.6.1 | IMU-ISA-100C Mechanical Drawings | 150 |
| A.6.2 | Optional Side Mounting Holes | 152 |
| A.6.3 | IMU-ISA-100C Performance | 154 |
| A.6.4 | IMU-ISA-100C Electrical and Environmental | 155 |
| A.6.5 | IMU Enclosure Interface Cable | 156 |
| A.6.6 | IMU Enclosure Power Cable | 158 |
| A.6.7 | IMU Enclosure Wheel Sensor Cable | 160 |
| A.7 | IMU-KVH1750 | 162 |

| | | |
|--------|---|-----|
| A.7.1 | IMU-KVH1750 Mechanical Drawings | 163 |
| A.7.2 | IMU-KVH1750 Sensor Specifications | 167 |
| A.7.3 | IMU-KVH1750 Electrical and Environmental | 168 |
| A.7.4 | IMU-KVH1750 Cable | 169 |
| A.8 | IMU-ENC-LN200 | 171 |
| A.8.1 | IMU-ENC-LN200 Mechanical Drawings | 172 |
| A.8.2 | IMU-ENC-LN200 Sensor Specifications | 174 |
| A.8.3 | IMU-ENC-LN200 Electrical and Environmental | 175 |
| A.8.4 | IMU-ENC-LN200 Cables | 175 |
| A.9 | IMU- μ IMU-IC | 176 |
| A.9.1 | IMU- μ IMU-IC Mechanical Drawings | 177 |
| A.9.2 | IMU- μ IMU-IC Sensor Specifications | 179 |
| A.9.3 | IMU- μ IMU-IC Electrical and Environmental | 180 |
| A.9.4 | IMU- μ IMU-IC Cables | 180 |
| A.10 | LN-200 IMU (single-connector enclosure) | 181 |
| A.10.1 | LN-200 IMU Mechanical Drawings | 182 |
| A.10.2 | LN-200 IMU Performance | 184 |
| A.10.3 | LN-200 Electrical and Environmental | 184 |
| A.10.4 | Interface Cable for the LN-200 IMU | 185 |
| A.11 | OEM-IMU-ADIS-16488 | 186 |
| A.11.1 | OEM-IMU-ADIS-16488 Mechanical Drawings | 187 |
| A.11.2 | OEM-IMU-ADIS-16488 Sensor Specifications | 190 |
| A.11.3 | OEM-IMU-ADIS-16488 Electrical and Environmental | 190 |
| A.11.4 | OEM-IMU-ADIS-16488 SPI Connection | 191 |
| A.11.5 | ADIS-16488 IMU-to-MIC Cable Assembly | 193 |
| A.12 | OEM-IMU-EG320N | 194 |
| A.12.1 | OEM-IMU-EG320N Mechanical Drawings | 195 |
| A.12.2 | OEM-IMU-EG320N Sensor Specifications | 196 |
| A.12.3 | OEM-IMU-EG320N Electrical Environmental | 196 |
| A.12.4 | OEM-IMU-EG320N Interface Connector | 197 |
| A.13 | OEM-IMU-ISA-100C | 199 |
| A.13.1 | OEM-IMU-ISA-100C Mechanical Drawings | 200 |
| A.13.2 | OEM-IMU-ISA-100C Sensor Specifications | 202 |
| A.13.3 | OEM-IMU-ISA-100C Electrical and Environmental | 202 |
| A.13.4 | OEM-IMU-ISA-100C IMU to UIC Cable Assembly | 203 |
| A.14 | OEM-IMU-STIM300 | 206 |
| A.14.1 | OEM-IMU-STIM300 Mechanical Drawings | 207 |
| A.14.2 | OEM-IMU-STIM300 Sensor Specifications | 208 |
| A.14.3 | OEM-IMU-STIM300 Electrical and Environmental | 208 |
| A.14.4 | OEM-IMU-STIM300 Direct Connection | 209 |
| A.14.5 | STIM300 IMU-to-MIC Cable Assembly | 211 |
| A.15 | OEM-IMU- μ IMU | 213 |
| A.15.1 | OEM-IMU- μ IMU Mechanical Drawings | 214 |
| A.15.2 | OEM-IMU- μ IMU Sensor Specifications | 217 |
| A.15.3 | OEM-IMU- μ IMU Electrical and Environmental | 217 |
| A.15.4 | μ IMU to UIC Cable Assembly | 218 |
| A.16 | Universal IMU Enclosure (HG1700, LN200) | 220 |
| A.16.1 | Universal IMU Enclosure Mechanical Drawings | 221 |
| A.16.2 | IMU Performance | 225 |
| A.16.3 | Electrical and Environmental | 227 |
| A.16.4 | Universal IMU Enclosure Interface Cable | 228 |
| A.17 | MIC - MEMS Interface Card | 230 |
| A.17.1 | MIC Mechanical Drawings | 231 |
| A.17.2 | MIC Electrical and Environmental | 233 |
| A.17.3 | MIC Connectors | 234 |

| | | |
|--------|---|-----|
| A.17.4 | HG1930 IMU-to-MIC Cable Assembly | 239 |
| A.17.5 | HG1700 and HG1900 IMU-to-MIC Cable Assembly | 241 |
| A.18 | UIC - Universal IMU Controller | 243 |
| A.18.1 | UIC Mechanical Drawings | 244 |
| A.18.2 | UIC Electrical and Environmental | 246 |
| A.18.3 | UIC Connectors | 247 |
| A.18.4 | HG1900 IMU to UIC Cable Assembly | 251 |
| A.18.5 | LN200 IMU to UIC Cable Assembly | 252 |

APPENDIX B HG1700 IMU in Universal Enclosure

| | | |
|-----|---|-----|
| B.1 | Disassemble the Universal Enclosure | 255 |
| B.2 | Install the HG1700 Sensor Unit | 257 |

APPENDIX C LN-200 IMU in Universal Enclosure

| | | |
|-----|---|-----|
| C.1 | Disassemble the Universal Enclosure | 265 |
| C.2 | Install the LN-200 Sensor Unit | 266 |

APPENDIX D HG1700 IMU in SPAN HG Enclosure

| | | |
|-----|--|-----|
| D.1 | Disassemble the SPAN IMU Enclosure | 271 |
| D.2 | Install the HG1700 Sensor Unit | 273 |
| D.3 | Make the Electrical Connections | 274 |
| D.4 | Re-Assemble the SPAN IMU Enclosure | 276 |

APPENDIX E LN-200 IMU in SPAN IMU Enclosure

| | | |
|-----|--|-----|
| E.1 | Disassemble the SPAN IMU Enclosure | 278 |
| E.2 | Install the LN-200 Sensor Unit | 280 |
| E.3 | Make the Electrical Connections | 281 |
| E.4 | Re-Assemble the SPAN IMU Enclosure | 283 |

APPENDIX F Frequently Asked Questions

APPENDIX F Importance of Antenna Selection

APPENDIX G Replacement Parts for SPAN

Figures

| | |
|--|-----|
| Figure 1: Typical Installation of a SPAN System with an OEM7 Receiver Card | 28 |
| Figure 2: IMU Enclosure Mounting Plate | 32 |
| Figure 3: OEM-IMU-ADIS-16488 Pin Locations | 36 |
| Figure 4: OEM-IMU-EG320N Pin Locations | 38 |
| Figure 5: OEM-IMU-STIM300 Pin Out | 41 |
| Figure 6: Basic Set Up – MIC in Stack Up Configuration | 46 |
| Figure 7: Mount the MIC on the OEM719 | 49 |
| Figure 8: Connect the ADIS IMU to the MIC (OEM Cable Kit: 01019007) | 50 |
| Figure 9: Connect the HG1700 IMU to the MIC (OEM Cable Kit: 01018868) | 50 |
| Figure 10: Connect the HG1900 IMU to the MIC (OEM Cable Kit: 01018871) | 50 |
| Figure 11: Connect the HG1930 IMU to the MIC (OEM Cable Kit: 01018869) | 50 |
| Figure 12: Connect the STIM300 IMU to the MIC (OEM Cable Kit: 01019174) | 51 |
| Figure 13: Basic MIC Set Up | 52 |
| Figure 14: Connect the ADIS IMU to the MIC (OEM Cable Kit: 01019007) | 54 |
| Figure 15: Connect the HG1700 IMU to the MIC (OEM Cable Kit: 01018868) | 54 |
| Figure 16: Connect the HG1900 IMU to the MIC (OEM Cable Kit: 01018871) | 55 |
| Figure 17: Connect the HG1930 IMU to the MIC (OEM Cable Kit: 01018869) | 55 |
| Figure 18: Connect the STIM300 IMU to the MIC (OEM Cable Kit: 01019174) | 55 |
| Figure 19: Basic UIC Installation | 57 |
| Figure 20: UIC Status LEDs | 60 |
| Figure 21: Typical Installation of a SPAN System with a PwrPak7 | 62 |
| Figure 22: Typical Installation of a SPAN System with a PwrPak7-E1 | 65 |
| Figure 23: Kistler WPT | 66 |
| Figure 24: Local-Level Frame (ENU) | 72 |
| Figure 25: IMU Body Frame Marking | 72 |
| Figure 26: Vehicle Frame | 73 |
| Figure 27: IMU to Antenna Translation Offset | 74 |
| Figure 28: Multi-Line IMU Body to Vehicle Calibration | 93 |
| Figure 29: Sample Configuration | 102 |
| Figure 30: Operating Gimbal | 103 |
| Figure 31: Relative INS Example | 106 |
| Figure 32: SPAN - Two Receiver Dual Antenna Installation | 109 |
| Figure 33: SPAN - Single Receiver Dual Antenna Installation | 110 |
| Figure 34: HG1700 Top/Bottom Dimensions | 116 |
| Figure 35: HG1700 Enclosure Side Dimensions | 117 |
| Figure 36: IMU-CPT Side and Perspective View | 121 |
| Figure 37: IMU-CPT Top, Front and Bottom View | 122 |
| Figure 38: IMU-CPT Development Terminated Cable | 125 |

| | |
|--|-----|
| Figure 39: IMU-FSAS Top Dimensions | 128 |
| Figure 40: IMU-FSAS Bottom Dimensions | 128 |
| Figure 41: IMU-FSAS Side Dimensions | 129 |
| Figure 42: IMU-FSAS Center of Navigation | 130 |
| Figure 43: IMU-FSAS Interface Cable with Wheel Sensor | 132 |
| Figure 44: IMU-HG1900 Dimensions | 136 |
| Figure 45: IMU-HG1900 Center of Navigation | 137 |
| Figure 46: IMU-IGM-A1 Dimensions | 141 |
| Figure 47: IMU-IGM-S1 Dimensions | 142 |
| Figure 48: IMU-IGM Interface Cable | 147 |
| Figure 49: IMU-ISA-100C Dimensions | 150 |
| Figure 50: IMU-ISA-100C Center of Navigation | 151 |
| Figure 51: Optional Side Mounting Holes | 153 |
| Figure 52: IMU Enclosure Interface Cable | 156 |
| Figure 53: IMU Enclosure Power Cable | 158 |
| Figure 54: IMU Enclosure Wheel Sensor Cable | 160 |
| Figure 55: IMU-KVH1750 Bottom view | 163 |
| Figure 56: IMU-KVH1750 Top View | 164 |
| Figure 57: IMU-KVH1750 Side View | 165 |
| Figure 58: IMU-KVH1750 Gyro Axes | 166 |
| Figure 59: IMU-KVH1750 Cable | 169 |
| Figure 60: IMU-ENC-LN200 Dimensions | 172 |
| Figure 61: IMU-ENC-LN200 Center of Navigation | 173 |
| Figure 62: IMU- μ IMU-IC Dimensions | 177 |
| Figure 63: IMU- μ IMU-IC Center of Navigation | 178 |
| Figure 64: LN-200 IMU Enclosure Top/Bottom Dimensions and Center of Navigation | 182 |
| Figure 65: LN-200 Enclosure Side Dimensions | 183 |
| Figure 66: ADIS-16488 Dimensions | 187 |
| Figure 67: ADIS-16488 Center of Navigation | 188 |
| Figure 68: OEM ADIS-16488 Dimensions | 189 |
| Figure 69: ADIS-16488 IMU-to-MIC Cable Assembly | 193 |
| Figure 70: EG320N Dimensions | 195 |
| Figure 71: OEM-IMU-EG320N Pin Locations | 197 |
| Figure 72: ISA-100C Dimensions | 200 |
| Figure 73: ISA-100C Coordinate Axis | 201 |
| Figure 74: OEM-IMU-ISA-100C IMU to UIC Cable Assembly | 203 |
| Figure 75: STIM300 Dimensions | 207 |
| Figure 76: STIM300 Center of Navigation | 207 |
| Figure 77: STIM300 IMU-to-MIC Cable Assembly | 211 |
| Figure 78: μ IMU Dimensions | 215 |

| | |
|--|-----|
| Figure 79: μ IMU Coordinate Axis | 216 |
| Figure 80: μ IMU to UIC Cable Assembly | 218 |
| Figure 81: Universal IMU Enclosure Side Dimensions | 221 |
| Figure 82: Universal IMU Enclosure Top/Bottom Dimensions | 222 |
| Figure 83: Universal IMU Center of Navigation | 223 |
| Figure 84: Universal IMU Frame Axis | 224 |
| Figure 85: Universal IMU Enclosure Interface Cable | 228 |
| Figure 86: MIC Top/Bottom Dimensions | 231 |
| Figure 87: MIC Keep-Out Zone | 232 |
| Figure 88: HG1930 IMU-to-MIC Cable Assembly | 239 |
| Figure 89: HG1700 and HG1900 IMU-to-MIC Cable Assembly | 241 |
| Figure 90: UIC Dimensions and Keep Out Zones | 244 |
| Figure 91: UIC Connectors, LEDs and Heat Sink Details | 245 |
| Figure 92: OEM-IMU-HG1900 IMU to UIC Cable Assembly | 251 |
| Figure 93: OEM-IMU-LN200 IMU to UIC Cable Assembly | 252 |
| Figure 94: Required Parts | 254 |
| Figure 95: Remove Base | 255 |
| Figure 96: Disconnect Wiring Harness from Enclosure Body | 256 |
| Figure 97: Remove IMU Mounting Plate and Bracket | 257 |
| Figure 98: Remove IMU Mounting Screws | 258 |
| Figure 99: Connect IMU to IMU Mounting Plate | 258 |
| Figure 100: Installing IMU to Mounting Plate | 259 |
| Figure 101: Assemble Into Enclosure Body | 260 |
| Figure 102: Fasten Internal Cable Harness | 261 |
| Figure 103: Install O-rings | 261 |
| Figure 104: Install Enclosure Body on the Base | 262 |
| Figure 105: Screw Enclosure Base to Body | 262 |
| Figure 106: Final Assembly | 263 |
| Figure 107: Required Parts | 264 |
| Figure 108: Remove Base | 265 |
| Figure 109: Disconnect Wiring Harness from SDLC Card | 265 |
| Figure 110: IMU Bracket | 266 |
| Figure 111: Remove IMU Bracket/SDLC | 266 |
| Figure 112: Install LN-200 IMU to Base | 267 |
| Figure 113: Install Bracket to Base | 267 |
| Figure 114: Making Connections | 268 |
| Figure 115: Connect Internal Cable Harness | 268 |
| Figure 116: Installing the Enclosure Body to the Base | 269 |
| Figure 117: Screw Enclosure Base to Body | 270 |
| Figure 118: Final Assembly | 270 |

Figure 119: Required Parts 271

Figure 120: Bolts and Hex Key 272

Figure 121: Lift Top Cover, Tube Body and 3 Ring Spacer Screws 273

Figure 122: SPAN IMU Re-Assembly 274

Figure 123: Attach Flex Cable 275

Figure 124: Incorrect (Bowed) Flex Cable Installation 276

Figure 125: Correct (Flat) Flex Cable Installation 276

Figure 126: HG1700 SPAN IMU 277

Figure 127: Required Parts 278

Figure 128: Bolts and Hex Key 279

Figure 129: Lift Top Cover and Tube Body 280

Figure 130: SPAN IMU Re-Assembly 281

Figure 131: Attach Wiring Harness 282

Figure 132: Attach Samtec Connector 283

Figure 133: LN-200 SPAN IMU 284

Figure 134: Plot of Good and Poor Antenna Phase Center Variation over Elevation Angle 0-90° 288

Tables

| | |
|--|-----|
| Table 1: INS Options | 25 |
| Table 2: SPAN-Compatible IMUs | 25 |
| Table 3: IMU Connection Method | 33 |
| Table 4: Receiver to ADIS-16488 Pin Connections | 36 |
| Table 5: Receiver to EG320N Pin Connections | 39 |
| Table 6: Receiver to STIM300 Pin Connections | 41 |
| Table 7: IMU Power Supply | 44 |
| Table 8: COM Port Recommendations | 56 |
| Table 9: COM Port Recommendations | 59 |
| Table 10: UIC Status LEDs | 60 |
| Table 11: Additional IMU to PwrPak7 Connections | 64 |
| Table 12: Kistler to NovAtel Wheel Sensor Cable Connections | 67 |
| Table 13: IMU-IGM LEDs | 70 |
| Table 14: IMU Enclosure LEDs | 70 |
| Table 15: INS Profiles | 78 |
| Table 16: Enable INS Commands | 79 |
| Table 17: Inertial Solution Status | 83 |
| Table 18: NVM Seed Indication | 88 |
| Table 19: Solution Parameters | 88 |
| Table 20: Valid Event Inputs and Outputs for Timed Sensor Triggers | 95 |
| Table 21: Logs with Azimuth Data | 99 |
| Table 22: Logs used with Variable Lever Arm | 104 |
| Table 23: Commands used with Variable Lever Arm | 104 |
| Table 24: HG1700 IMU Physical Specifications | 115 |
| Table 25: HG1700-AG58 IMU Performance | 118 |
| Table 26: HG1700-AG62 IMU Performance | 118 |
| Table 27: HG17000 Electrical Specifications | 119 |
| Table 28: HG17000 Environmental Specifications | 119 |
| Table 29: IMU-CPT Physical Specifications | 120 |
| Table 30: IMU-CPT Performance | 123 |
| Table 31: IMU-CPT Electrical Specifications | 124 |
| Table 32: IMU-CPT Environmental Specifications | 124 |
| Table 33: IMU-CPT Connector Pinout Descriptions | 125 |
| Table 34: Connectors | 126 |
| Table 35: Maximum Cable Length | 126 |
| Table 36: IMU-FSAS Physical Specifications | 127 |
| Table 37: IMU-FSAS Performance | 131 |
| Table 38: IMU-FSAS Electrical Specifications | 131 |

| | |
|---|-----|
| Table 39: IMU-FSAS Environmental Specifications | 131 |
| Table 40: IMU-FSAS Cable with Wheel Sensor Pinout | 133 |
| Table 41: Connectors | 134 |
| Table 42: Maximum Cable Length | 134 |
| Table 43: IMU-HG1900 Physical Specifications | 135 |
| Table 44: IMU-HG1900 IMU Performance | 138 |
| Table 45: IMU-HG1900 Electrical Specifications | 139 |
| Table 46: IMU-HG1900 Environmental Specifications | 139 |
| Table 47: IMU-IGM-A1 Physical Specifications | 140 |
| Table 48: IMU-IGM-S1 Physical Specifications | 140 |
| Table 49: IMU-IGM Main Port Pinout | 143 |
| Table 50: IMU-IGM AUX Port Pinout | 143 |
| Table 51: IMU-IGM-A1 IMU Performance | 145 |
| Table 52: IMU-IGM-S1 IMU Performance | 145 |
| Table 53: IMU-IGM-A1 Electrical Specifications | 146 |
| Table 54: IMU-IGM-A1 Environmental Specifications | 146 |
| Table 55: IMU-IGM-S1 Electrical Specifications | 146 |
| Table 56: IMU-IGM-S1 Environmental Specifications | 146 |
| Table 57: IMU-IGM Interface Cable Pinout Descriptions | 147 |
| Table 58: Connectors | 148 |
| Table 59: Maximum Cable Length | 148 |
| Table 60: IMU-ISA-100C Physical Specifications | 149 |
| Table 61: IMU-ISA-100C IMU Performance | 154 |
| Table 62: IMU-ISA-100C Electrical Specifications | 155 |
| Table 63: IMU-ISA-100C Environmental Specifications | 155 |
| Table 64: IMU Enclosure Interface Cable Pinouts | 156 |
| Table 65: Connectors | 157 |
| Table 66: Maximum Cable Length | 157 |
| Table 67: IMU Enclosure Power Cable Pinouts | 158 |
| Table 68: IMU Enclosure Wheel Sensor Cable Pinouts | 160 |
| Table 69: Connectors | 161 |
| Table 70: Maximum Cable Length | 161 |
| Table 71: IMU-KVH1750 Physical Specifications | 162 |
| Table 72: IMU-KVH1750 Performance | 167 |
| Table 73: IMU-KVH1750 Electrical Specifications | 168 |
| Table 74: IMU-KVH1750 Environmental Specifications | 168 |
| Table 75: IMU-KVH1750 Connector Pinout Descriptions | 169 |
| Table 76: Connectors | 170 |
| Table 77: Maximum Cable Length | 170 |
| Table 78: IMU-ENC-LN200 Physical Specifications | 171 |

| | |
|--|-----|
| Table 79: IMU-ENC-LN200 IMU Performance | 174 |
| Table 80: IMU-ENC-LN200C IMU Performance | 174 |
| Table 81: IMU-ENC-LN200 Electrical Specifications | 175 |
| Table 82: IMU-ENC-LN200 Environmental Specifications | 175 |
| Table 83: IMU- μ IMU-IC Physical Specifications | 176 |
| Table 84: IMU- μ IMU-IC IMU Performance | 179 |
| Table 85: IMU- μ IMU-IC Electrical Specifications | 180 |
| Table 86: IMU- μ IMU-IC Environmental Specifications | 180 |
| Table 87: LN-200 IMU Physical Specifications | 181 |
| Table 88: LN-200 IMU Performance | 184 |
| Table 89: LN-200 Electrical Specifications | 184 |
| Table 90: LN-200 Environmental Specifications | 184 |
| Table 91: OEM-IMU-ADIS-16488 Physical Specifications | 186 |
| Table 92: OEM-IMU-ADIS-16488 Performance | 190 |
| Table 93: OEM-IMU-ADIS-16488 Electrical Specifications | 190 |
| Table 94: OEM-IMU-ADIS-16488 Environmental Specifications | 190 |
| Table 95: Receiver to ADIS-16488 Pin Connections | 191 |
| Table 96: ADIS-16488 IMU-to-MIC Cable Pinout | 193 |
| Table 97: OEM-IMU-EG320N Physical Specifications | 194 |
| Table 98: OEM-IMU-EG320N Performance | 196 |
| Table 99: OEM-IMU-EG320N Electrical Specifications | 196 |
| Table 100: OEM-IMU-EG320N Environmental Specifications | 196 |
| Table 101: OEM-IMU-EG320N Connector | 197 |
| Table 102: OEM-IMU-ISA-100C Physical Specifications | 199 |
| Table 103: OEM-IMU-ISA-100C IMU Performance | 202 |
| Table 104: OEM-IMU-ISA-100C Electrical Specifications | 202 |
| Table 105: OEM-IMU-ISA-100C Environmental Specifications | 202 |
| Table 106: OEM-IMU-ISA-100C IMU to UIC Cable Pinout | 203 |
| Table 107: OEM-IMU-STIM300 Physical Specifications | 206 |
| Table 108: OEM-IMU-STIM300 Performance | 208 |
| Table 109: OEM-IMU-STIM300 Electrical Specifications | 208 |
| Table 110: OEM-IMU-STIM300 Environmental Specifications | 208 |
| Table 111: Receiver to STIM300 Pin Connections | 209 |
| Table 112: STIM300 IMU-to-MIC Cable Pinout | 211 |
| Table 113: OEM-IMU- μ IMU Physical Specifications | 213 |
| Table 114: OEM-IMU- μ IMU IMU Performance | 217 |
| Table 115: OEM-IMU- μ IMU Electrical Specifications | 217 |
| Table 116: OEM-IMU- μ IMU Environmental Specifications | 217 |
| Table 117: μ IMU to UIC Cable Pinout | 218 |
| Table 118: Universal IMU Enclosure Physical Specifications | 220 |

| | |
|--|-----|
| Table 119: HG1700-AG58 IMU Performance | 225 |
| Table 120: HG1700-AG62 IMU Performance | 225 |
| Table 121: LN200 IMU Performance | 226 |
| Table 122: Universal IMU Enclosure Electrical Specifications | 227 |
| Table 123: Universal IMU Enclosure Environmental Specifications | 227 |
| Table 124: Universal IMU Enclosure Interface Cable Pinouts | 228 |
| Table 125: Connectors | 229 |
| Table 126: Maximum Cable Length | 229 |
| Table 127: MEMS Interface Card Physical Specifications | 230 |
| Table 128: MIC Electrical Specifications | 233 |
| Table 129: MIC Electrical and Environmental Specifications | 233 |
| Table 130: MIC Connectors | 234 |
| Table 131: Pinouts for Power Connector (P101) | 234 |
| Table 132: Pinouts for User Interface Connector (P301) | 234 |
| Table 133: Pinouts for IMU Connector (P601) | 237 |
| Table 134: Pinouts for IMU Connector (P701) | 238 |
| Table 135: MIC LED Indicator Drivers | 238 |
| Table 136: HG1930 IMU-to-MIC Cable Assembly | 239 |
| Table 137: HG1700 and HG1900 IMU-to-MIC Cable Assembly | 241 |
| Table 138: UIC Physical Specifications | 243 |
| Table 139: UIC Electrical Specifications | 246 |
| Table 140: UIC Environmental Specifications | 246 |
| Table 141: UIC Connectors | 247 |
| Table 142: Pinouts for Power Connector (J101) | 247 |
| Table 143: Pinouts for UIC to Receiver Communications Connector (J102) | 247 |
| Table 144: Pinouts for UIC to IMU Communications Connector (J1401) | 248 |
| Table 145: OEM-IMU-HG1900 IMU to UIC Cable Pinout | 251 |
| Table 146: OEM-IMU-LN200 IMU to UIC Cable Pinout | 252 |

Notices Receiver Card

The following notices apply to the OEM7 family products.



Changes or modifications to this equipment, not expressly approved by NovAtel Inc., could void the user's authority to operate this equipment.

FCC

The devices covered by this manual comply with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note:

The equipment listed has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. The Class B limits are designed to provide reasonable protection against harmful interference in a residential installation. The equipment listed generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Innovation, Science and Economic Development (ISED) Canada

OEM7 Class B digital device complies with Canadian ICES-003.

OEM7 appareils numérique de la classe B sont conforme à la norme NMB-003 du Canada.

European Union (EU)

Hereby, NovAtel Inc. declares that the radio equipment type OEM7 GNSS receiver is in compliance with Directive 2014/53/EU


The full text of the EU Declaration of Conformity may be obtained from the NovAtel website at: www.novatel.com/products/compliance/eu-declaration-of-conformity/.

WEEE

If you purchased your OEM7 family product in Europe, please return it to your dealer or supplier at the end of life. The objectives of the European Community's environment policy are, in particular, to preserve, protect and improve the quality of the environment, protect human health

and utilise natural resources prudently and rationally. Sustainable development advocates the reduction of wasteful consumption of natural resources and the prevention of pollution. Waste Electrical and Electronic Equipment (WEEE) is a regulated area. Where the generation of waste cannot be avoided, it should be reused or recovered for its material or energy. WEEE products



may be recognized by their wheeled bin label ().

See www.novatel.com/products/compliance/environmental-compliance/ for more information.

RoHS

The OEM7 GNSS receivers are in conformity with Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

REACH

The OEM7 receivers are in compliance with Regulation (EC) No 1907/2006 OF THE EUROPEAN PARLIAMENT AND THE COUNCIL of 18 December 2006 concerning the Registration, Evaluation, Authorization and Restriction of Chemicals (REACH). The Candidate List of Substances of Very High Concern (SVHC) published by the European Chemical Agency (ECHA) is available at <https://echa.europa.eu/candidate-list-table>.

Ethernet Port



The Ethernet ports are Safety Extra Low Voltage (SELV) circuits only and are suitable for connection within a building only. Do not connect them to Telephone Network Voltage (TNV) circuits.

Lightning Protection Installation and Grounding Procedure

What is the hazard?

A lightning strike into the ground causes an increase in the earth's potential which results in a high voltage potential between the center conductor and shield of the coaxial cable. This high voltage develops because the voltage surge induced onto the center conductor lags in time behind the voltage surge induced onto the shield.

Hazard Impact

A lightning strike causes the ground potential in the area to rise to dangerous levels resulting in harm to personnel or destruction of electronic equipment in an unprotected environment. It also conducts a portion of the strike energy down the inner conductor of the coaxial cable to the connected equipment.



Only qualified personnel, such as electricians mandated by the governing body in the country of installation, may install lightning protection devices.


Actions to Mitigate Lightning Hazards

1. Do not install antennas or antenna coaxial cables outside the building during a lightning storm.
2. It is not possible to avoid over voltages caused by lightning, but a lightning protection device may be used to shunt a large portion of the transient energy to the building ground, reducing the over voltage condition as quickly as possible.
3. Primary lightning protection must be provided by the operator/customer according to local building codes as part of the extra building installation.
4. To ensure compliance with clause 7 "Connection to Cable Distribution Systems" of EN 60950-1, Safety for Information Technology Equipment, a secondary lightning protection device must be used for in-building equipment installations with external antennas. The following device has been approved by NovAtel Inc.:

Polyphaser - Surge Arrestor DGXZ+36NFNF-A

If this device is not chosen as the primary lightning protection device, the device chosen must meet the following requirements:

- UL listed, or equivalent, in country of installation (for example, TUV, VDE and so on) for lightning surge protection
 - The primary device must be capable of limiting an incoming surge to 10 kV
5. The shield of the coaxial cable entering the building should be connected at a grounding plate at the building's entrance. The lightning protection devices should have their chassis grounded to the same ground near to the building's entrance.
 6. The primary and secondary lightning protections should be as close to the building's entrance as possible. Where feasible, mount onto the grounding plate itself (refer to the figure below).



| Ref # | Description |
|-------|---|
| 1 | Primary lightning protection device |
| 2 | Secondary lightning protection device |
| 3 | External antenna |
| 4 | GNSS Receiver |
| 5 | To ground |
| 6 | Grounding plate or grounding point at the building's entrance |



Acceptable choices for earth grounds, for central buildings, are:

- Grounded interior metal cold water pipe within five feet (1.5 m) of the point where it enters the building
- Grounded metallic service raceway
- Grounded electrical service equipment enclosure
- Eight-foot grounding rod driven into the ground (only if bonded to the central building ground by #6, or heavier, bonding wire)

These installation instructions are the minimum requirements for receiver and antenna installations. Where applicable, follow the electrical codes for the country of installation. Examples of country codes include:

- **USA** National Electrical Code (NFPA 70)
- **Canada** Canadian Electrical Code (CSA C22.1)
- **UK** British Standards Institute (BSI 7671)

Conventions

The following conventions are used in this manual:



Information that supplements or clarifies text.



A caution that actions, operation or configuration may lead to incorrect or improper use of the hardware.



A warning that actions, operation or configuration may result in regulatory non-compliance, safety issues or equipment damage.

Customer Support

NovAtel Knowledge Base

If you have a technical issue, visit the NovAtel Support page at www.novatel.com/support. Through the *Support* page, you can contact Customer Support, find papers and tutorials or download current manuals and the latest firmware.

Before Contacting Customer Support

Before you contact NovAtel Customer Support about a software problem, perform the following steps:



If logging data over an RS-232 serial cable, ensure that the configured baud rate can support the data bandwidth (see **SERIALCONFIG** command). NovAtel recommends a minimum suggested baud rate of 115200 bps.

1. Log the following data to a file on your computer for 15 minutes:

```
RXSTATUSB once
RAWEPHEMB onchanged
GLORAWEPHEMB onchanged
BESTPOSB ontime 1
RANGEB ontime 1
RXCONFIGA once
VERSIONA once
```

For SPAN systems, add the following logs to the above list in the file created on your computer:

```
RAWIMUSXB onnew
INSUPDATESTATUSB onnew
INSPVAXB ontime 1
INSCONFIGA once
```

2. Send the data file to NovAtel Customer Support: support@novatel.com
3. You can also issue a **FRESET** command to the receiver to clear any unknown settings.



The **FRESET** command will erase all user settings. You should know your configuration (by requesting the RXCONFIGA log) and be able to reconfigure the receiver before you send the **FRESET** command.

If you are having a hardware problem, send a list of the troubleshooting steps taken and the results.

Contact Information

Log a support request with NovAtel Customer Support using one of the following methods:

Log a Case and Search Knowledge:

Website: www.novatel.com/support

Log a Case, Search Knowledge and View Your Case History: (login access required)

Web Portal: <https://novatelsupport.force.com/community/login>

E-mail:

support@novatel.com

Telephone:

U.S. and Canada: 1-800-NOVATEL (1-800-668-2835)

International: +1-403-295-4900

Chapter 1 OEM7 SPAN Overview

NovAtel's Synchronous Position, Attitude and Navigation (SPAN[®]) technology brings together two very different but complementary positioning and navigation systems namely Global Navigation Satellite System (GNSS) and an Inertial Navigation System (INS). By combining the best aspects of GNSS and INS into one system, SPAN technology is able to offer a solution that is more accurate and reliable than either GNSS or INS could provide alone. The combined GNSS+INS solution has the advantage of the absolute accuracy available from GNSS and the continuity of INS through traditionally difficult GNSS conditions.

The SPAN system consists of the following components:

- NovAtel OEM7 receiver
These receivers are capable of receiving and tracking different combinations of GPS, GLONASS, Galileo, BeiDou, NavIC and QZSS signals on a maximum of 555 channels. OEM7 receivers can also allocate channels for the reception of correction service signals from SBAS (standard) and NovAtel Correct™ with PPP (optional). OEM7 adaptability offers multi-system, frequency, and size configurations for any application requirement. Patented Pulsed Aperture Correlator (PAC) technology combined with a powerful microprocessor enable multipath-resistant processing. Excellent acquisition and re-acquisition times allow this receiver to operate in environments where very high dynamics and frequent interruption of signals can be expected. The OEM7 receiver also supports the timing requirements of the IMU and runs the real-time INS filter.
- IMU
The Inertial Measurement Unit (IMU) consists of three accelerometers and three gyroscopes (gyros) so that accelerations along specific axes and angular rotations can be measured. Several IMU types are supported and are listed in *Table 2: SPAN-Compatible IMUs* on page 25.
- GNSS antenna

The GNSS receiver is connected to the IMU with an RS-232, RS-422 or SPI link. A NovAtel GNSS antenna must also be connected to the receiver to track GNSS signals. After the IMU enclosure, GNSS antenna and appropriate power supplies are attached, and a few simple configuration commands are entered, the SPAN system will be ready to navigate.

1.1 Fundamentals of GNSS+INS

GNSS positioning observes range measurements from orbiting GNSS satellites. From these observations, the receiver can compute position and velocity with high accuracy. NovAtel GNSS positioning systems are highly accurate positioning tools. However, GNSS in general has some restrictions which limit its usefulness in some situations. GNSS positioning requires line of sight view to at least four satellites simultaneously. If these criteria are met, differential GNSS positioning can be accurate to within a few centimetres. If however, some or all of the satellite signals are blocked, the accuracy of the position reported by GNSS degrades substantially, or may not be available at all.

In general, an INS uses forces and rotations measured by an IMU to calculate position, velocity and attitude. This capability is embedded in the firmware of OEM7 receivers. Forces are measured by accelerometers in three perpendicular axes within the IMU and the gyros measure angular rotation rates around those axes. Over short periods of time, inertial navigation gives very accurate acceleration, velocity and attitude output. The INS must have prior knowledge of its

initial position, initial velocity, initial attitude, Earth rotation rate and gravity field. Since the IMU measures changes in orientation and acceleration, the INS determines changes in position and attitude, but initial values for these parameters must be provided from an external source. Once these parameters are known, an INS is capable of providing an autonomous solution with no external inputs. However, because of errors in the IMU measurements that accumulate over time, an inertial-only solution degrades with time unless external updates such as position, velocity or attitude are supplied.

The SPAN system's combined GNSS+INS solution integrates the raw inertial measurements with all available GNSS information to provide the optimum solution possible in any situation. By using the high accuracy GNSS solution, the IMU errors can be modeled and mitigated. Conversely, the continuity and relative accuracy of the INS solution enables faster GNSS signal reacquisition and RTK solution convergence.

The advantages of using SPAN technology are its ability to:

- Provide a full attitude solution (roll, pitch and azimuth)
- Provide continuous solution output (in situations when a GNSS-only solution is impossible)
- Provide faster signal reacquisition and RTK solution resolution (over stand-alone GNSS because of the tightly integrated GNSS and INS filters)
- Output high-rate (up to 200 Hz or greater depending on your logging selections) position, velocity and attitude solutions for high-dynamic applications, see also *Logging Restriction Important Notice* on page 90
- Use raw phase observation data (to constrain INS solution drift even when too few satellites are available for a full GNSS solution)



For more information about GNSS and INS, refer to www.novatel.com/an-introduction-to-gnss/

1.2 Models and Features

All SPAN system receivers are factory configurable for L1/L2 RTK capability and are compatible with an IMU. Each model is capable of multiple positioning modes of operation.

The SPAN features enabled on a receiver are identified in the 10th and 11th characters of the OEM7 model string. For example, if the model string is FFNRNNTBNS**1**, the characters **S1** identify the SPAN features. If the 10th and 11th characters are not present in the model number, SPAN has not been enabled on the receiver.



The model string is viewed using the **VERSION** log.
The SPAN features can also be viewed using the **MODELFEATURES** log.

The 10th character (S in this example) identifies the INS Options. The 11th character (1 in this example) identifies the IMU grade.

1.2.1 INS Options

The INS Model character indicates which features are enabled by the model. The INS options are explained in *Table 1: INS Options* on the next page.

Table 1: INS Options

| INS Model | Meaning | Description | Functionality Inheritance |
|-----------|-------------------|---|---------------------------|
| S | SPAN Enabled | Standard SPAN functionality. This model enables most SPAN functionality. | S |
| P | Enhanced Profiles | Allows the use of enhanced INS profiles for certain applications. For example, dead reckoning performance is controlled using the LAND_PLUS INS Profile and Heave filter output is controlled using the MARINE_PLUS INS Profile. For information about INS Profiles, see <i>INS Profiles</i> on page 77. For information about enabling and disabling INS Profiles, see the SETINSPROFILE command. Heave filter output is also controlled under this option. | S+P |
| R | Relative INS | Allows for two SPAN systems to communicate and produce a relative solution (position, velocity, attitude) between them. This option also inherits the enhanced profile functionality of the P model. For more information, see <i>Relative INS</i> on page 105 | S+P+R |

1.2.2 IMU Grade

The IMU grade indicates which classes of IMUs are supported by the model. The IMU grade is specified as a number between 1 and 3 to indicate the IMU grade available to the model.

So, for example, to use an ISA-100C IMU, an IMU grade of 3 is required. A larger number also allows use of any IMU in a lower grade. So the S3 model required for the ISA-100C would also allow the use of any IMU in grades 1 and 2.

Table 2: *SPAN-Compatible IMUs* below shows the IMU grade classification.

Table 2: SPAN-Compatible IMUs

| Supported IMUs | | |
|----------------|--------------------|--------------------------|
| IMU Grade | NovAtel Part Name | IMU Name |
| 1 | IMU-CPT | KVH CPT IMU |
| | IMU-H1930-CA50 | Honeywell HG1930-CA50 |
| | IMU-IGM-A1 | IMU-IGM-A1 |
| | IMU-IGM-S1 | IMU-IGM-S1 |
| | OEM-IMU-ADIS-16488 | Analog Devices ADIS16488 |
| | OEM-IMU-EG320N | Epson G320 |
| | OEM-IMU-STIM300 | Sensoror STIM300 |

| Supported IMUs | | |
|----------------|-------------------|---------------------------|
| IMU Grade | NovAtel Part Name | IMU Name |
| 2 | IMU-H1900-CA50 | Honeywell HG1900-CA50 |
| | IMU-H58 | Honeywell HG1700-AG58 |
| | IMU-H62 | Honeywell HG1700-AG62 |
| | IMU-KVH1750 | KVH 1750 IMU |
| | IMU- μ IMU | Lifef μ IMU-IC |
| | UIMU-H58 | Honeywell HG1700-AG58 |
| | UIMU-H62 | Honey well HG1700-AG62 |
| 3 | IMU-FSAS-EI | IMAR iIMU-FSAS |
| | IMU-ISA-100C | Litef ISA-100C |
| | IMU-LN200 | Northrop Grumman LN-200-L |
| | OEM-IMU-ISA-100C | Litef ISA-100C |

1.3 Related Documents and Information

This manual contains sufficient information about the installation and operation of the SPAN system. It is beyond the scope of this manual to provide details on service or repair. Contact your local NovAtel dealer for any customer service related inquiries, see *Customer Support* on page 21.

The OEM7 receiver utilizes a comprehensive user-interface command structure, which requires communications through its communications ports. For descriptions of the commands and logs available with OEM7 receivers, refer to the [OEM7 Commands and Logs Reference Manual](#) available on the NovAtel website at www.novatel.com/support/. It is recommended that these documents be kept together for easy reference.

For more information about the OEM7 receivers, refer to the [OEM7 Installation and Operation User Manual](#) or [PwrPak7 Installation and Operation User Manual](#).

SPAN system output is compatible with post-processing software from NovAtel's Waypoint® Products Group. Visit our web site at www.novatel.com for details.

Chapter 2 SPAN Installation

A SPAN system consists of an OEM7 receiver, an IMU, a GNSS antenna, power and a communication link (if your application requires real time differential operation). The installation process varies based on the OEM7 receiver.

- *OEM7 Receiver Card Installation* below
- *PwrPak7 Installation* on page 61
- *PwrPak7-E1 Installation* on page 64




If your IMU enclosure and IMU were supplied separately, additional instructions for installing the IMU into an the enclosure are available in the following appendices: *HG1700 IMU in Universal Enclosure* on page 254, *LN-200 IMU in Universal Enclosure* on page 264, *HG1700 IMU in SPAN HG Enclosure* on page 271 and *LN-200 IMU in SPAN IMU Enclosure* on page 278.

2.1 OEM7 Receiver Card Installation

The following diagram shows a typical SPAN installation using an OEM7 receiver card and an IMU in an enclosure.

Figure 1: Typical Installation of a SPAN System with an OEM7 Receiver Card



Complete the following steps to set up your NovAtel SPAN system.

1. Mount the GNSS antenna.
See *Mounting the GNSS Antenna* on page 30 for details.
2. Mount the IMU.
See *Mount the IMU* on page 30 for details.
3. Install the OEM7 receiver card.

See the [OEM7 Installation and Operation User Manual](#) for information about installing an OEM7 receiver.

4. Connect the GNSS antenna to the OEM7 receiver card.

See the [OEM7 Installation and Operation User Manual](#) for information about installing an OEM7 receiver.

5. Connect the IMU to the OEM7 receiver.

See *Connect the IMU to the OEM7 Receiver Card* on page 32 for details.

6. Connect the I/O strobe signals (optional).

See the [OEM7 Installation and Operation User Manual](#) for information about installing an OEM7 receiver.

7. Connect power to the IMU and receiver.

See *Connect Power* on page 44 for details.

8. Connect a data communication device, such a computer, to the receiver. A data communication device is used to configure and monitor the receiver.

See the [OEM7 Installation and Operation User Manual](#) for information about installing an OEM7 receiver.

2.1.1 Selecting a GNSS Antenna

NovAtel offers a variety of antennas, including single, dual and triple-frequency, triple-band and wide-band reference GNSS antennas (refer to our web site: www.novatel.com/antennas for details of available antennas). All antennas include band pass filtering and an LNA. The GNSS antenna chosen depends on the particular application. Each model offers exceptional phase center stability and a significant measure of immunity against multipath interference. Each antenna has an environmentally sealed radome and all meet the European Union's Restriction of Hazardous Substances (RoHS) and Waste Electrical and Electronic Equipment (WEEE).

If a non-NovAtel GNSS antenna is chosen, a typical antenna LNA gain between 26 dB to 30 dB is recommended in a rover station application.

For more information about antenna selection, see *Importance of Antenna Selection* on page 287.

2.1.2 Choosing a Coaxial Cable

An appropriate coaxial cable matches the impedances of the antenna and receiver (50 ohms) and has a line loss not exceeding 10.0 dB. If the limit is exceeded, excessive signal degradation may occur and the receiver may not meet performance specifications. NovAtel offers several coaxial cables to meet GNSS antenna interconnection requirements, including:

- 5, 15 and 30 m antenna cable with TNC connectors on both ends (NovAtel part numbers GPS-C006, GPS-C016 and GPS-C032)



A conversion is required between the MMCX, MMBX or MCX connector on the OEM7 receiver card and the female TNC connector on NovAtel's GNSS antennas.



NovAtel recommends using high quality coaxial cables because an impedance mismatch is possible when using lower quality cables and this produces reflections in the cable that increases signal loss. Although other high quality antenna cables can be used, the performance specifications of the OEM7 receivers are warranted only when used with NovAtel supplied accessories.

2.1.3 Mounting the GNSS Antenna

The OEM7 receiver is designed to operate with any NovAtel GNSS antenna.

When installing the antenna:

- Choose an antenna location with a clear view of the sky so each satellite above the horizon can be tracked without obstruction. For more information on RF signal propagation and multipath, refer to the NovAtel application note [APN-008 Discussions on RF Signal Propagation and Multipath](#) at www.novatel.com/support/.
- Mount the antenna on a secure, stable structure capable of safe operation in the specific environment.
- Ensure the antenna cannot move due to dynamics.

Antenna LNA Power

NovAtel antennas and coaxial cables meet receiver RF input gain requirements. NovAtel coaxial cables are designed to introduce no more than 10 dB loss and NovAtel antennas are equipped with built-in LNAs that provide 26 dB of gain to the satellite signal received.

The power to the antenna LNA is provided through the receiver's RF port center conductor.

OEM7 receivers provide +5 VDC \pm 5% at a maximum of 200 mA.

Antenna supply over current protection limits the LNA power.



If a short circuit or other problem causes an overload of the current supplied to the antenna, the receiver hardware shuts down the power supplied to the antenna. To restore power, power cycle the receiver. The Receiver Status word, available in the **RXSTATUS** log (see [OEM7 Commands and Logs Reference Manual](#)), provides more information about the cause of the problem.

2.1.4 Mount the IMU

Mount the IMU in a fixed location where the distance from the IMU to the GNSS antenna phase center is constant. Ensure that the orientation with respect to the vehicle and antenna is also constant.

For attitude output to be meaningful, the IMU should be mounted such that the positive Z-axis marked on the IMU enclosure points up and the Y-axis points forward through the front of the vehicle, in the direction of track. If the IMU is not mounted in this orientation, a rotational offset must be applied. See *Rotational Offsets* on page 75 for more information.

Also, it is important to measure the distance from the IMU to the antenna (the Antenna Lever Arm), on the first usage, on the axis defined on the IMU enclosure. See *Lever Arm Calibration Routine* on page 90. See also *IMU Technical Specifications* on page 114 for dimensional drawings of the IMU enclosures.

Ensure the IMU cannot move due to dynamics and that the distance and relative direction between the antenna and the IMU is fixed. See *SPAN Configuration* on page 79.



The closer the antenna is to the IMU, particularly in the horizontal plane, the more accurate the position solution.

Also, your measurements entered using the **SETINSTRANSLATION** command must be as accurate as possible, or at least more accurate than the GNSS positions being used.

For example, a 10 cm error in recording the antenna offset will result in at least a 10 cm error in the output. Millimeter accuracy is preferred.

The offset from the IMU to the antenna, and/or a user point device, must remain constant especially for RTK or DGPS data. Ensure the IMU, antenna and user point device are bolted in one position perhaps by using a custom bracket.

Securing the IMU Enclosure

The IMU Enclosure (IMU-ISA-100C, IMU-ENC-LN200, IMU-HG1900 and IMU- μ IMU-IC) can be secured directly to the mounting surface or can be secured using the IMU Enclosure Mounting Plate.

To secure the IMU Enclosure directly to the mounting surface, use four M6 screws that pass through the mounting surface and into the bottom of the IMU Enclosure. For the location and spacing of the mounting holes, refer to the mechanical drawings of the IMU in *IMU Technical Specifications* on page 114.



The optimal screw penetration into the IMU Enclosure mounting holes is 5.0 to 6.0 mm deep. When selecting screws for mounting the IMU Enclosure, ensure the screw penetration does not exceed 6 mm. Using excessively long screws can damage the IMU Enclosure.



The mounting screws should be torqued to 42 to 45 in-lbs.

For information about securing the IMU Enclosure using the mounting plate, refer to *Secure an IMU Enclosure Using the Mounting Plate* below.




Other IMUs are secured using the four through holes in the base of the IMU.

Secure an IMU Enclosure Using the Mounting Plate

To secure an IMU enclosure using the IMU Enclosure Mounting Plate:

1. Place the mounting plate on the bottom of the IMU Enclosure and align the holes in the mounting plate with the threaded holes in the IMU Enclosure base plate.
2. Secure the mounting plate to the IMU Enclosure using the 4 screws (M6 x 8 mm) included with the mounting plate.
3. Secure the IMU Enclosure mounting plate to the mounting location using 4 M6 screws.

Figure 2: IMU Enclosure Mounting Plate



2.1.5 Connect the IMU to the OEM7 Receiver Card

The method used to connect the IMU depends on the IMU and OEM7 receiver in the system.

IMUs that are contained within an IMU enclosure communicate with the OEM7 receiver using a serial port. IMUs in an enclosure typically have *IMU* or *UIMU* at the start of their names (for example, IMU-ISA-100C, IMU- μ IMU-IC or IMU-IGM-S1).

IMUs not contained in an IMU enclosure use an interface card (MIC or UIC) or direct connection to communicate with the OEM7 receiver card. IMUs not in an IMU enclosure typically have *OEM*

at the start of their names (for example, OEM-IMU-ISA-100C, OEM-IMU- μ IMU or OEM-IMU-STIM300).

Table 3: IMU Connection Method

| IMU | Receiver | Connection Method |
|-------------------|----------------------------------|--------------------------------|
| IMU-H58/62 | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-422) |
| IMU-CPT | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-422) |
| IMU-FSAS | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-422) |
| IMU-HG1900 | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-422) |
| IMU-IGM-A1 | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-232 or RS-422) |
| IMU-IGM-S1 | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-232 or RS-422) |
| IMU-ISA-100C | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-422) |
| IMU-KVH-1750 | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-422) |
| IMU-ENC-LN200 | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-422) |
| IMU- μ IMU-IC | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-422) |
| IMU-LN200 | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-422) |
| OEM-IMU-ADIS16488 | OEM719, OEM729, OEM7700, OEM7720 | MIC |
| | OEM7700, OEM7720 | SPI port |
| OEM-IMU-EG320N | OEM7700, OEM7720 | SPI port |
| OEM-IMU-HG1900 | OEM719, OEM729, OEM7700, OEM7720 | UIC |
| OEM-IMU-HG1930 | OEM719, OEM729, OEM7700, OEM7720 | MIC |
| OEM-IMU-ISA-100C | OEM719, OEM729, OEM7700, OEM7720 | UIC |

| IMU | Receiver | Connection Method |
|-------------------------|-------------------------------------|----------------------|
| OEM-IMU-STIM300 | OEM719, OEM729, OEM7700, OEM7720 | MIC |
| | | Serial port (RS-422) |
| OEM-IMU- μ IMU | OEM719, OEM729, OEM7700, OEM7720 | UIC |
| UIMU-HG1700 (H58 & H62) | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-422) |
| UIMU-LN200 | OEM719, OEM729, OEM7700, OEM7720 | Serial port (RS-422) |

Connect an IMU Enclosure to an OEM7 Receiver Card Using a Serial Port

An interface is needed between the OEM7 receiver card and IMU that provides:

- Communication signals to the OEM7 receiver
- A serial port connection between the IMU and receiver
- Power to the receiver
- Power to the IMU

For information about the interface requirements for the OEM7 receiver card, see the [OEM7 Installation and Operation User Manual](#).

For information about the interface to the IMU, refer to the technical specifications of the IMU in *IMU Technical Specifications* on page 114.



IMU-CPT, IMU-KVH1750 and IMU-FSAS

These IMUs require an additional output from the receiver to synchronize the IMU and receiver.

- IMU-CPT

Connect the EVENT_OUT1 (VARF) signal from the receiver to the External Clock Input signal (pin 36) on the IMU-CPT. Refer to the *IMU-CPT Cable* on page 125 for information about the cable requirements for the IMU-CPT.

- IMU-KVH1750

Connect the EVENT_OUT1 (VARF) signal from the receiver to the MSync signal (pin 11) on the IMU-KVH1750. Refer to the *IMU-KVH1750 Cable* on page 169 for information about the cable requirements for the IMU-KVH1750.

- IMU-FSAS

Connect the EVENT_OUT1 (VARF) signal from the receiver to the DAS(+) signal (pin 7) on the IMU-FSAS. Refer to the *IMU-FSAS Cable with Wheel Sensor* on page 132 for information about the cable requirements for the IMU-FSAS.



The interface between the OEM7 receiver card and IMU must include circuitry to convert from the LVCMOS signal levels of the receiver COM port to the RS-232 or RS422 signal levels of the IMU COM port.

The exception is COM1 on the OEM729 which provides either RS-232 or RS-422 signal levels.



If using a KVH1750 IMU not purchased through NovAtel, the baud rate of the IMU must be changed to 460,800 bps. For information about changing the IMU baud rate, see *Connect Directly to the IMU* on page 43.

Connect an OEM IMU to an OEM7 Receiver Card Using a UIC

The UIC provides power to the IMU and communication between the IMU and receiver. For information about using a UIC, see *UIC Installation* on page 56.

Connect an OEM IMU to an OEM7 Receiver Card Using a MIC

The MIC provides power to the IMU and communication between the IMU and receiver. For information about using a MIC, see *MIC Installation* on page 45.

Connect an OEM IMU to an OEM7 Receiver Card Using a Direct Connection

Some OEM IMUs can communicate with the OEM7 receiver card without using an interface card. For information about using a direct connection, see:

- *Connect an OEM-IMU-ADIS-16488 Directly to an OEM7 Receiver Card* below
- *Connect an OEM-IMU-EG320N Directly to an OEM7 Receiver Card* on page 38
- *Connect an OEM-IMU-STIM300 Directly to an OEM7 Receiver Card* on page 40

Connect an OEM-IMU-ADIS-16488 Directly to an OEM7 Receiver Card

The OEM-IMU-ADIS-16488 can connect directly to SPI capable OEM7 receivers, such as the OEM7700 and OEM7720, using a SPI connection. The SPI connection handles timing and data communication between the receiver and IMU.



The OEM-IMU-ADIS-16488 can also connect to any OEM7 receiver using a MEMS Interface Card (MIC). For information about using MIC, see *MIC Installation* on page 45.

The interface to the OEM-IMU-ADIS-16488 must provide:

- a Samtec CLM-112-02 connector

This connector mates with the connector on the OEM-IMU-ADIS-16488. See *Figure 3: OEM-IMU-ADIS-16488 Pin Locations* on the next page for the location of the IMU connector and pins.

- a SPI port connection to the OEM7 receiver

Refer to the following table for the connections required between the IMU and receiver. For information about the receiver connector, see the [OEM7 Installation and Operation User Manual](#).

- a 3.3 VDC (± 0.3 VDC) regulated power supply

Refer to the following table for the location of the power supply connections.

Figure 3: OEM-IMU-ADIS-16488 Pin Locations




Table 4: Receiver to ADIS-16488 Pin Connections

| ADIS-16488 | | Receiver | | |
|------------|----------|----------|------------|------------------------|
| Pin | Pin Name | Pin | Pin Name | Description |
| 1 | NC | - | - | Do not connect |
| 2 | NC | - | - | Do not connect |
| 3 | SCLK | 44 | SPI_SCLK | SPI Serial Clock |
| 4 | SDO | 43 | SPI_MISO | SPI Data Output |
| 5 | SDI | 41 | SPI_MOSI | SPI Data Input |
| 6 | /CS | 42 | SPI_nCS | SPI Chip Select |
| 7 | DIO1 | 26 | EVENT_OUT2 | Synchronization signal |

| ADIS-16488 | | Receiver | | |
|-------------------|-----------------|-----------------|-----------------|---|
| Pin | Pin Name | Pin | Pin Name | Description |
| 8 | /RST | - | - | <p>Reset IMU</p> <p>RST must be high for the IMU to be active.</p> <p>To enable the IMU when the receiver is powered on, connect this pin to Pin 1 or Pin 2 of the receiver interface connector through a 10 kΩ resistor (recommended).</p> <p>Can also connect this pin to any stable 3.3 VDC power supply or output configuration to have more control over when IMU is enabled. When using this configuration note that:</p> <ul style="list-style-type: none"> • pin 8 must be pulled low for greater than 100 ms to properly soft-reset the IMU • pin has an internal pull-up resistor |
| 9 | DIO2 | 29 | EVENT_IN2 | Data ready |
| 10 | VDD | - | - | 3.3 VDC power supply |
| 11 | VDD | - | - | 3.3 VDC power supply |
| 12 | VDD | - | - | 3.3 VDC power supply |
| 13 | GND | - | - | Digital ground |
| 14 | GND | - | - | Digital ground |
| 15 | GND | - | - | Digital ground |
| 16 | NC | - | - | Do not connect |
| 17 | NC | - | - | Do not connect |
| 18 | NC | - | - | Do not connect |
| 19 | NC | - | - | Do not connect |
| 20 | NC | - | - | Do not connect |
| 21 | NC | - | - | Do not connect |
| 22 | NC | - | - | Do not connect |
| 23 | NC | - | - | Do not connect |
| 24 | NC | - | - | Do not connect |



For the location of the receiver pins, refer to the [OEM7 Installation and Operation User Manual](#).

For more information about the OEM-IMU-ADIS-16488, see *OEM-IMU-ADIS-16488* on page 186.

Connect an OEM-IMU-EG320N Directly to an OEM7 Receiver Card

The OEM-IMU-EG320N can connect directly to SPI capable OEM7 receivers, such as the OEM7700 or OEM7720, using a SPI connection. The SPI connection handles timing and data communication between the receiver and IMU.

The interface to the OEM-IMU-EG320 must provide:

- a Samtec CLM-110-02-H-D connector

This connector mates with the connector on the OEM-IMU-EG320N. See *Figure 4: OEM-IMU-EG320N Pin Locations* below for the location of the IMU connector and pins.

- a SPI port connection to the OEM7 receiver

See *Table 5: Receiver to EG320N Pin Connections* on the next page for the connections required between the IMU and receiver. For information about the receiver connector, see the [OEM7 Installation and Operation User Manual](#).

- a 3.3 VDC (± 0.15 VDC) regulated power supply

See *Table 5: Receiver to EG320N Pin Connections* on the next page for the location of the power supply connections.

Figure 4: OEM-IMU-EG320N Pin Locations




Table 5: Receiver to EG320N Pin Connections

| EG320N | | Receiver | | |
|--------|--------------|----------|------------|---|
| Pin | Pin Name | Pin | Pin Name | Description |
| 1 | SCLK | 44 | SPI_SCLK | SPI Serial Clock |
| 2 | SDO | 43 | SPI_MISO | SPI Data Output |
| 3 | GND | - | - | Digital ground |
| 4 | GND | - | - | Digital ground |
| 5 | SDI | 41 | SPI_MOSI | SPI Data Input |
| 6 | /CS | 42 | SPI_nCS | SPI Chip Select |
| 7 | SOUT | - | - | UART Data Out Connect to the 3.3 VDC power supply through a resistor (default 10 k Ω). |
| 8 | GND | - | - | Digital ground |
| 9 | SIN | - | - | UART Data In Connect to the 3.3 VDC power supply through a resistor (default 10 k Ω). |
| 10 | VCC | - | - | 3.3 VDC power supply |
| 11 | VCC | - | - | 3.3 VDC power supply |
| 12 | VCC | - | - | 3.3 VDC power supply |
| 13 | DRDY (GPIO1) | 29 | EVENT_IN2 | Data Ready |
| 14 | GPIO2 (EXT) | 26 | EVENT_OUT2 | External Trigger |
| 15 | GND | - | - | Digital ground |

| EG320N | | Receiver | | |
|--------|----------|----------|----------|---|
| Pin | Pin Name | Pin | Pin Name | Description |
| 16 | /RST | - | - | <p>Reset IMU</p> <p>RST must be high for the IMU to be active.</p> <p>To enable the IMU when the receiver is powered on, connect this pin to Pin 1 or Pin 2 of the receiver connector through a 10 kΩ resistor (recommended).</p> <p>Can also connect this pin to any stable 3.3 VDC power supply or output configuration to have more control over when IMU is enabled. When using this configuration note that:</p> <ul style="list-style-type: none"> pin 16 must be pulled low for greater than 100 ms to properly soft-reset the IMU pin 16 has an internal 32-224 kΩ pull-up resistor |
| 17 | NC | - | - | Do not connect |
| 18 | NC | - | - | Do not connect |
| 19 | NC | - | - | Do not connect |
| 20 | NC | - | - | Do not connect |



For the location of the receiver pins, refer to the [OEM7 Installation and Operation User Manual](#).

For more information about the OEM-IMU-EG320N, see *OEM-IMU-EG320N* on page 194.

Connect an OEM-IMU-STIM300 Directly to an OEM7 Receiver Card

The OEM-IMU-STIM300 can connect directly to an OEM7700 or OEM7720 using a serial port connection.



The OEM-IMU-STIM300 serial port uses RS-422 signal levels. Since the receiver uses LVCMOS signal levels, a RS-422 line driver is needed to convert from LVCMOS to RS-422.



The OEM-IMU-STIM300 can also connect to any OEM7 receiver using a MEMS Interface Card (MIC). For information about using MIC, see *MIC Installation* on page 45.

The interface to the OEM-IMU-STIM300 must provide:

- a Micro-D 15 pin male connector

This connector mates with the connector on the OEM-IMU-STIM300. See *Figure 5: OEM-IMU-STIM300 Pin Out* below for the IMU connector pin out.

- a RS-422 serial port connection to the OEM7 receiver that includes a RS-422 line driver

Refer to the following table for the connections required between the IMU and receiver. For information about the receiver connector, see the [OEM7 Installation and Operation User Manual](#).

- a 5.0 VDC (±0.5 VDC) regulated power supply

Refer to the following table for the location of the power supply connections.

Figure 5: OEM-IMU-STIM300 Pin Out





Table 6: Receiver to STIM300 Pin Connections

| STIM300 | | RS-422 Line Driver | | Receiver | | Description |
|---------|-----------|--------------------|-------|----------|----------|---|
| Pin | Pin Name | Output | Input | Pin | Pin Name | |
| 1 | STIM TXD- | RS422 B- | - | - | - | Part of RS-422 transmit pair from STIM300 |
| 2 | STIM RxD- | RS422 A- | - | - | - | Part of RS-422 receive pair from STIM300 |
| 3 | NC | - | - | - | - | Do not connect |

| STIM300 | | RS-422 Line Driver | | Receiver | | Description |
|---------|-----------|--------------------|--------------|----------|-----------|---|
| Pin | Pin Name | Output | Input | Pin | Pin Name | |
| 4 | STIM TOV | - | - | 29 | EVENT_IN2 | <div style="border: 1px solid black; padding: 5px;">  <p>Interface Circuit Required The STIM TOV output uses 5V logic, but the OEM7 EVENT_IN lines are not 5V tolerant. A circuit to convert from 5V logic to 3.3V levels is required.</p> </div> |
| 5 | NC | - | - | - | - | Do not connect |
| 6 | NC | - | - | - | - | Do not connect |
| 7 | NC | - | - | - | - | Do not connect |
| 8 | 5V Pwr | - | - | - | - | 5 VDC power supply |
| 9 | STIM TxD+ | RS422 B+ | - | - | - | Part of RS-422 transmit pair from STIM300 |
| 10 | STIM RxD+ | RS422 A+ | - | - | - | Part of RS-422 receive pair from STIM300 |
| 11 | NC | - | - | - | - | Do not connect |
| 12 | GND | - | - | - | - | Any receiver ground pin |
| 13 | GND | - | - | - | - | Any receiver ground pin |
| 14 | NC | - | - | - | - | Do not connect |
| 15 | GND | - | - | - | - | Any receiver ground pin |
| - | - | - | LVC MOS A IN | | COMx_TXD | Any receiver COM port transmit and receive pair |
| - | - | - | LVC MOS B IN | | COMx_RXD | |
| - | - | - | GND | | | Any receiver ground pin |



For the location of the receiver ground pins and transmit and receive pairs, refer to the [OEM7 Installation and Operation User Manual](#).

KVH1750 Baud Rate Conversion

The maximum baud rate of the COM ports on an OEM7 receiver is 460,800 bps. If purchased directly from KVH, the KVH1750 natively communicates at 921,600 bps, so it needs to be modified to use 460,800 bps.



Though slower, 460,800 bps is more than adequate to transmit the data at the required 200 Hz without any impact to performance.

There are two methods to change the KVH1750 IMU baud rate. If an OEM6 receiver is available, a command is available that will allow the receiver to change the IMU baud rate. If not, a direct RS-422 connection at 921,600 baud is required to change the IMU baud rate.

Connect Directly to the IMU



This method requires a direct connection to the IMU at 921,600 baud over RS-422. Make sure the RS-422 link used is capable of 921,600 baud as not all serial ports are capable of that rate.

1. Open a command terminal at 921600 baud via an RS-422 serial link.
By default, the IMU will output 0.5 Hz binary messages which will help confirm you are connected properly.
2. Issue the following two commands in sequence to enter configuration mode and change the baud rate.


```
=CONFIG,1
=BAUD,460800
```
3. Upon completion of these commands, power cycle the IMU to boot up in the new baud rate.
4. Confirm the change by connecting to the IMU at 460,800 baud and verifying the incoming messages.

The new baud rate configuration is saved to the IMU NVM automatically so the process is complete and the IMU is ready for use with an OEM7 receiver.

Use an OEM6 Receiver Command

OEM6 firmware as of version OEM060630RN0000 (Dec 2016) includes the **IMUCONFIGURATION** command that internally configures the KVH1750 IMU for SPAN communication. Three sets of configuration options are available, two of which allow changing the baud rate of the IMU to either 921,600 or 460,800. This provides customers upgrading to OEM7 an easy method to modify the baud rate. To change the IMU to 460800 baud, use the following procedure:

1. Connect the KVH-1750 IMU to an RS422 capable OEM6 receiver communication port.
2. Issue the following command.

```
CONNECTIMU COM# IMU_KVH_1750
```

3. Issue the following command.

```
IMUCONFIGURATION IMU_KVH_1750 2
```

The **IMUCONFIGURATION** command can be used to configure the KVH17xx IMU's depending on the value of the Option field.

```
IMUCONFIGURATION IMUType [Option]
```

| IMU Type | Option | Configuration Details |
|--------------|--------|--|
| IMU_KVH_1750 | 0 | Configure KVH options for NovAtel communication. |
| | 1 | Change KVH baud rate to 921,600 |
| | 2 | Change KVH baud rate to 460,800 |

2.1.6 Connect Power



If you are using a MEMS OEM IMU (ADIS-16488, HG1900, HG1930, STIM300) and a MIC, see *MIC Installation* on the next page for information about connecting and powering the MIC and IMU.



If you are using an OEM IMU (ISA-100C, HG1900, LN200 or μ IMU) and a UIC, see *UIC Installation* on page 56 for information about connecting and powering the UIC and IMU.

Receiver Power

For information about connecting power to an OEM7 receiver card, see the [OEM7 Installation and Operation User Manual](#).

For information about connecting power to a PwrPak7, see the [PwrPak7 Installation and Operation User Manual](#).

IMU Power

In addition to the receiver power supply, a power supply is needed for the IMU. See *Table 7: IMU Power Supply* below for the voltage requirements for each IMU. The same power supply can be used for the receiver and the IMU, if the power supply meets the power requirements of both devices.

Table 7: IMU Power Supply

| IMU | Power Requirement |
|--------------|-------------------|
| IMU-CPT | +9 to +18 VDC |
| IMU-FSAS | +10 to +34 VDC |
| IMU-HG1900 | +10 to +34 VDC |
| IMU-IGM | +10 to +30 VDC |
| IMU-ISA-100C | +10 to +34 VDC |
| IMU-KVH1750 | +9 to +36 VDC |

| IMU | Power Requirement |
|----------------------------|-------------------|
| IMU-ENC-LN200 | +10 to +34 VDC |
| IMU- μ IMU | +10 to +34 VDC |
| UIMU-HG1700 (AG58 or AG62) | +12 to +28 VDC |
| UIMU-LN200 | +12 to +28 VDC |

For most IMUs, connect the power leads on the IMU interface cable to the IMU power supply. For an IMU in the IMU Enclosure (IMU-HG1900, IMU-ISA-100C, IMU-ENC-LN200 or IMU- μ IMU-IC), connect the IMU Power Cable (NovAtel part # 60723136) from the IMU to the IMU power supply.



The IMU Power Cable has four power leads, two positive (VIN+) and two negative (VIN-). Typically, all four wires are connected to the power supply. However, the IMU Enclosure can be powered from a single pair (VIN+ and VIN-). This is beneficial in systems with a backup power supply as one pair can be connected to the main power supply and the second pair can be connected to the backup power supply.

Details about the IMU ports and cables can be found in *IMU Technical Specifications* on page 114.

2.2 MIC Installation

For IMUs that are not mounted inside a NovAtel IMU enclosure (e.g. OEM-HG1930), an interface card is required to connect the IMU to the OEM7 receiver. The MEMS Interface Card (MIC) provides the connection between OEM7 receiver cards and Micro Electromechanical Systems (MEMS) IMUs.



IMUs have different interface requirements. Use a MIC to connect MEMS IMUs (ADIS-16488, HG-1700, HG-1900, HG-1930 or STIM-300) to an OEM7 receiver. For other supported IMUs (e.g. ISA100C, LN200, HG-1900 or μ IMU), use a Universal IMU Controller (UIC). See *UIC Installation* on page 56.

There are two MIC configurations: stack up and standalone. In a stack up configuration, the MIC card is mounted on an OEM719 receiver. In a standalone configuration, the MIC is mounted separately from the receiver.



The MIC supports all OEM7 receiver cards for communications. The OEM719 is the only OEM7 receiver card that can be directly integrated and powered by the MIC.


2.2.1 Install a MIC in a Stack Up Configuration

In a stack up configuration, the MIC is connected to an OEM719 receiver using the 20-pin header on the OEM719. Power and communications connections to the receiver are made through the MIC.

Important! Assemble in accordance with applicable industry standards. Ensure all Electrostatic Discharge (ESD) measures are in place, in particular, use a ground strap before exposing or handling any electronic items, including the MIC, receiver and IMU. Take care to prevent damaging or marring painted surfaces, O-rings, sealing surfaces and the IMU.

For more information about ESD practices, see the [OEM7 Installation and Operation User Manual](#).

Figure 6: Basic Set Up – MIC in Stack Up Configuration



| Ref | Connector | Part Number | Mating Connector | Description |
|-----|-----------|--------------------|--------------------|--|
| 1 | P101 | 43650-0313 (Molex) | 43645-0300 (Molex) | Connects to the MIC power supply. This connection provides power to the MIC and the OEM719 receiver. (user supplied cable) |
| 2 | P601 | 53780-2070 (Molex) | 51146-2000 (Molex) | Connects to HG1700, HG1900, HG1930 and STIM300 IMUs. (NovAtel supplied cable kit) |
| 3 | P701 | 53780-1070 (Molex) | 51146-1000 (Molex) | Connects to ADIS-16488 IMUs. (NovAtel supplied cable kit) |

| Ref | Connector | Part Number | Mating Connector | Description |
|-----|-----------|---------------------------|------------------------|---|
| 4 | P301 | 501571-3007 (Molex) | 501189-3010 (Molex) | Connects the MIC and OEM719 communication signals to the user system. (user supplied cable) |
| 5 | J301 | ASP-163577-01 (Samtec) | N/A | Connects to the main connector (P1701) on an OEM719 receiver. J301 is on the bottom of the MIC card |



For information about the MIC connectors and pin-outs, see *MIC Connectors* on page 234.



For information about the OEM7 receiver card connectors and pinouts, refer to the [OEM7 Installation and Operation User Manual](#).

Use the following steps to install the OEM719 receiver and MIC:

1. Mount the components of the SPAN system. See *Mount the SPAN System Components* below.
2. Connect the IMU to the MIC. See *Connect the IMU to the MIC* on page 49.
3. Connect power to the MIC. See *Connect Power to the MIC* on page 51.
4. Connect the input and output signals to the MIC. See *Connect the Input and Output Signals* on page 51.

Mount the SPAN System Components

1. Mount the antenna. See *Mounting the GNSS Antenna* on page 30.
2. Use the standoffs supplied with the MIC card to secure the OEM719 to its mounting location. See *Figure 7: Mount the MIC on the OEM719* on page 49. See the [OEM7 Installation and Operation User Manual](#) for information about installing an OEM7 receiver.



The part number for the recommended standoffs is RAF-M21073005AL7 (Irwin Industrial).

If alternate standoffs are selected, use equivalent parts with a minimum height of 12 mm.



Ensure all standoffs are properly installed and the mounting location is flat. The amount of board deflection (bow and twist) must not exceed 0.75%. For example, on the MIC which is 75 mm long and 46 mm wide, the deflection along the length must not exceed 0.56 mm and the deflection along the width must not exceed 0.34 mm.



Ensure the MIC is mounted close enough to the IMU so the interface cable can reach both devices.

3. Connect the antenna cable to the antenna jack on the OEM719.

The antenna cable must have a right angle MCX connector on the end that connects to the OEM719.




Warning! Do not apply power to the cards until the antenna cable is attached.




The part number for the recommended MCX connector is M1051-110 (ShinA Telecom). If an alternate part is used, it should meet the dimensions shown in the diagram.

The space between the OEM719 and the MIC is limited. The height of the MCX connector must not exceed 8.65 mm.



4. Align the mating connector (J301) on the MIC with the 20-pin header (P1701) on the OEM719. Make sure all of the pins on the header are aligned with the holes in the mating connector. Press down on the MIC to seat the connector on the header.
5. Use the four screws supplied with MIC to secure the MIC card to the OEM719.

Figure 7: Mount the MIC on the OEM719

Connect the IMU to the MIC

1. Attach the IMU mounting Printed Circuit Board (PCB) to the IMU. Ensure all the pins on the header are aligned with the holes on the mating connector.



An IMU mounting PCB is not used with the STIM300 IMU.

2. Connect the IMU-to-MIC interface cable to the IMU.
3. Connect the IMU-to-MIC interface cable to the IMU connector on the MIC.
 - Use the 10 pin locking connector (P701) for the ADIS IMUs. See *Figure 8: Connect the ADIS IMU to the MIC (OEM Cable Kit: 01019007)* on the next page.
 - Use the 20 pin locking connector (P601) for the HG1700, HG1900, HG1930 or STIM300 IMU. See *Figure 9: Connect the HG1700 IMU to the MIC (OEM Cable Kit: 01018868)* on the next page, *Figure 10: Connect the HG1900 IMU to the MIC (OEM Cable Kit: 01018871)* on the next page, *Figure 11: Connect the HG1930 IMU to the MIC (OEM Cable Kit:*

01018869) on the next page or *Figure 12: Connect the STIM300 IMU to the MIC (OEM Cable Kit: 01019174)* on the next page.

Figure 8: Connect the ADIS IMU to the MIC (OEM Cable Kit: 01019007)




Figure 9: Connect the HG1700 IMU to the MIC (OEM Cable Kit: 01018868)




Figure 10: Connect the HG1900 IMU to the MIC (OEM Cable Kit: 01018871)




Figure 11: Connect the HG1930 IMU to the MIC (OEM Cable Kit: 01018869)





Figure 12: Connect the STIM300 IMU to the MIC (OEM Cable Kit: 01019174)

Connect Power to the MIC

Connect a +10 to +30 VDC power supply to the power connector (P101) on the MIC. See *MIC Connectors* on page 234 for pinout information for the power connector.



This connection provides power to the MIC and the OEM719.

Connect the Input and Output Signals

All of the communication connections to the MIC and the OEM719 receiver are available on the communications connector (P601) on the MIC. These connections include:

- MIC serial port
- OEM719 serial port (COM2)
- USB port
- Event1 trigger input
- Event2 trigger input
- 1 PPS (Pulse Per Second) output
- VARF (Variable Frequency) output
- Reset input
- Position Valid output

See *MIC Connectors* on page 234 for the pinouts of the communications connector.



All signal I/O with the exception of the USB port are at LVCMOS levels. To connect the MIC to devices that use other signals levels, such as a computer with an RS-232 serial port, an interface circuit that converts LVCMOS to the other signal level must be used.



Use a twisted pair for the USB port connection and keep the wires as short as possible.


2.2.2 Install a MIC in a Standalone Configuration

In a standalone configuration, the MIC is mounted separately from the OEM7 receiver.

Important! Assemble in accordance with applicable industry standards. Ensure all Electrostatic Discharge (ESD) measures are in place, in particular, use a ground strap before exposing or handling any electronic items, including the MIC, receiver and IMU. Take care to prevent damaging or marring painted surfaces, O-rings, sealing surfaces and the IMU.

For more information about ESD practices, see the [OEM7 Installation and Operation User Manual](#).

Figure 13: Basic MIC Set Up



| Ref | Connector | Part Number | Mating Connector | Description |
|-----|-----------|------------------------|---------------------|---|
| 1 | P101 | 43650-0313 (Molex) | 43645-0300 (Molex) | Connects to the MIC power supply. (user supplied cable) |
| 2 | P601 | 53780-2070 (Molex) | 51146-2000 (Molex) | Connects to HG1700, HG1900, HG1930 and STIM300 IMUs. (NovAtel supplied cable) |
| 3 | P701 | 53780-1070 (Molex) | 51146-1000 (Molex) | Connects to ADIS-16488 IMUs. (NovAtel supplied cable) |
| 4 | P301 | 501571-3007 (Molex) | 501189-3010 (Molex) | Connects the MIC serial port to the OEM7 receiver. (user supplied cable) |
| 5 | J301 | ASP-163577-01 (Samtec) | N/A | This connector is not used. |



For information about the MIC connectors and pin-outs, see *MIC Connectors* on page 234.



For information about the OEM7 receiver card connectors and pinouts, refer to the [OEM7 Installation and Operation User Manual](#).



OEM729 Recommendations

- Use COM1 for connection to a computer. COM1 uses RS-232 levels and can be connected to a computer without additional interface circuitry.
- Use COM2 for connection to the MIC serial port. Both the MIC serial port and COM2 use LVCMOS levels and can be connected without additional interface circuitry.

Use the following steps to install the OEM7 receiver and MIC:

1. Mount the components of the SPAN system. See *Mount the SPAN System Components* below.
2. Connect the IMU to the MIC. See *Connect the IMU to the MIC* on the next page.
3. Connect the MIC to the OEM7 receiver. See *Connect the MIC to a Receiver* on page 55.
4. Connect power to the MIC and OEM7 receiver. See *Connect Power to the MIC and OEM7 Receiver* on page 56.

Mount the SPAN System Components

1. Mount the antenna. See *Mounting the GNSS Antenna* on page 30.
2. Mount the OEM7 receiver. See the [OEM7 Installation and Operation User Manual](#) for information about installing an OEM7 receiver.
3. Install the MIC in a secure enclosure to reduce environmental exposure and RF interference. If there is sufficient space, the MIC can reside in the same enclosure as the receiver.

Use the screws supplied with the MIC card to secure the MIC to its mounting location. See *MIC Mechanical Drawings* on page 231 for the MIC dimensions.



Ensure the MIC is mounted close enough to the IMU so the interface cable can reach both devices.



Ensure all standoffs are properly installed and the mounting location is flat. The amount of board deflection (bow and twist) must not exceed 0.75%. For example, on the MIC which is 75 mm long and 46 mm wide, the deflection along the length must not exceed 0.56 mm and the deflection along the width must not exceed 0.34 mm.

4. Mount the IMU. See *Mount the IMU* on page 30.

Connect the IMU to the MIC

1. Attach the IMU mounting Printed Circuit Board (PCB) to the IMU.
Ensure all the pins on the header are aligned with the holes on the mating connector.



An IMU mounting PCB is not used with the STIM300 IMU.

2. Connect the IMU-to-MIC interface cable to the IMU.
3. Connect the IMU-to-MIC interface cable to the IMU connector on the MIC.
 - Use the 10 pin locking connector (P701) for the ADIS IMUs.
See *Figure 14: Connect the ADIS IMU to the MIC (OEM Cable Kit: 01019007)* below.
 - Use the 20 pin locking connector (P601) for the HG1700, HG1900, HG1930 or STIM300 IMU.
See *Figure 15: Connect the HG1700 IMU to the MIC (OEM Cable Kit: 01018868)* below, *Figure 16: Connect the HG1900 IMU to the MIC (OEM Cable Kit: 01018871)* on the next page, *Figure 17: Connect the HG1930 IMU to the MIC (OEM Cable Kit: 01018869)* on the next page or *Figure 18: Connect the STIM300 IMU to the MIC (OEM Cable Kit: 01019174)* on the next page.

Figure 14: Connect the ADIS IMU to the MIC (OEM Cable Kit: 01019007)




Figure 15: Connect the HG1700 IMU to the MIC (OEM Cable Kit: 01018868)




Figure 16: Connect the HG1900 IMU to the MIC (OEM Cable Kit: 01018871)




Figure 17: Connect the HG1930 IMU to the MIC (OEM Cable Kit: 01018869)





Figure 18: Connect the STIM300 IMU to the MIC (OEM Cable Kit: 01019174)



Connect the MIC to a Receiver

1. Using a customer supplied wiring harness, connect the MIC serial port to a serial port on the OEM7 receiver. The MIC serial port is available on the communications connector (P301) of the MIC.

See *MIC Connectors* on page 234 for the pinouts of the communications connector. See the [OEM7 Installation and Operation User Manual](#) for information about connecting a serial port to the receiver.



All signal I/O on the MIC, with the exception of the USB port, are at LVCMOS levels.

To connect the MIC to devices that use other signals levels, such as a computer with an RS-232 serial port, an interface circuit that converts LVCMOS to the other signal level must be used.

Table 8: COM Port Recommendations

| | |
|----------------|--|
| OEM719 | All of the COM ports on these receivers use LVCMOS levels and are signal level compatible with the MIC serial port. |
| OEM7700 | |
| OEM7720 | |
| OEM729 | Use COM2 or COM3 of the OEM729 receiver to connect the MIC serial port. These COM ports use LVCMOS levels and are signal level compatible with the MIC serial port. COM1 on the OEM729 receiver can use RS-232 levels (default) or RS-422 levels and is not signal level compatible with the MIC serial port. |



For information about the OEM7 receiver card connectors and pinouts, refer to the [OEM7 Installation and Operation User Manual](#).

2. Connect a computer (for monitoring and configuration) to the OEM7 receiver. Refer to the [OEM7 Installation and Operation User Manual](#) for information about connecting data communications equipment to an OEM7 receiver.

Connect Power to the MIC and OEM7 Receiver



A separate power supply is required for the OEM7 receiver.

For information about the power supply requirements, refer to the Technical Specifications appendix for the receiver card in the [OEM7 Installation and Operation User Manual](#).

1. Using a customer supplied wiring harness, connect a +10 to +30 VDC power supply to the power connector (P101) on the MIC.
See *MIC Connectors* on page 234 for pinout information for the power connector.
2. Using a customer supplied wiring harness, connect power to the OEM7 receiver. See the [OEM7 Installation and Operation User Manual](#) for information about connecting power to the receiver.


2.3 UIC Installation

For IMUs that are not mounted inside a NovAtel IMU enclosure (e.g. OEM-IMU-ISA-100C), an interface card is required to connect an IMU to an OEM7 receiver. The Universal IMU Controller (UIC) provides the connection between OEM7 receiver cards and IMUs.



IMUs have different interface requirements. Use a UIC to connect OEM IMUs (ISA-100C, LN200, HG-1900 or μ IMU) to an OEM7 receiver. Use a MEMS Interface Card (MIC) to connect MEMS OEM IMUs (ADIS-16488, HG-1700, HG-1900, HG-1930 or STIM-300) to an OEM7 receiver. See *MIC Installation* on page 45.

Figure 19: Basic UIC Installation



| Ref | Connector | Part Number | Mating Connector | Description |
|-----|-----------|--------------------------|-------------------------|---|
| 1 | J101 | 43650-0513 (Molex) | 43645-0500 (Molex) | Connects to the UIC power supply (user supplied cable) |
| 2 | J102 | 98464-G61-16LF (FCI) | 90311-016LF (FCI) | Connects the UIC serial port to the OEM7 receiver (user supplied cable) |
| 3 | J1401 | LTMM-125-02-L-D (Samtec) | SQT-125-01-L-D (Samtec) | Connects to the IMU (NovAtel supplied cable) |



For information about the UIC connectors and pinouts, see *UIC Connectors* on page 247.



For information about the OEM7 receiver card connectors and pinouts, refer to the [OEM7 Installation and Operation User Manual](#).



Important! Assemble in accordance with applicable industry standards. Ensure all Electrostatic Discharge (ESD) measures are in place, in particular, use a ground strap before exposing or handling any electronic items, including the UIC, receiver and IMU. Take care to prevent damaging or marring painted surfaces, O-rings, sealing surfaces and the IMU.

For more information about ESD practices, see the [OEM7 Installation and Operation User Manual](#).

Use the following steps to install the OEM7 receiver and UIC:

1. Mount the components of the SPAN system. See *Mount the SPAN System Components* below.
2. Connect the IMU to the UIC. See *Connect the IMU to the UIC* on the next page.
3. Connect the UIC to the OEM7 receiver. See *Connect the UIC to a receiver* on the next page.
4. Connect power to the UIC and OEM7 receiver. See *Connect Power to the UIC and OEM7 Receiver* on page 60.

2.3.1 Mount the SPAN System Components

1. Mount the antenna. See *Mounting the GNSS Antenna* on page 30.
2. Mount OEM7 receiver. See the [OEM7 Installation and Operation User Manual](#) for information about installing an OEM7 receiver.
3. Mount the IMU. See *Mount the IMU* on page 30.
4. Install the UIC in a secure enclosure to reduce environmental exposure and RF interference. If there is sufficient space, the UIC can reside in the same enclosure as the receiver.

Use M3 pan head stainless steel screws to secure the UIC to its mounting location. See *UIC Mechanical Drawings* on page 244 for the UIC dimensions.



Ensure the UIC is mounted close enough to the IMU so the interface cable can reach both devices. For the length of the interface cable, refer to the specifications for the IMU in *IMU Technical Specifications* on page 114.



Ensure the mounting location provides at least 5 mm of clearance below the board to allow for components on the bottom of the UIC.



Ensure all standoffs are properly installed and the mounting location is flat. The amount of board deflection (bow and twist) must not exceed 0.75%. For example, on the UIC which is 100 mm long and 113 mm wide, the deflection along the length must not exceed 0.75 mm and the deflection along the width must not exceed 0.85 mm.

2.3.2 Connect the IMU to the UIC

1. If using an ISA-100C, attach the screw kit to the *IMU to UIC Interface Cable*.
2. Connect the *IMU to UIC Interface Cable* supplied with the UIC to the IMU. For IMU cables with screws, secure the cable to the IMU using the screws.
3. Connect the *IMU to UIC Interface Cable* to the IMU connector (J1401) on the UIC.

2.3.3 Connect the UIC to a receiver

1. Using a customer supplied wiring harness, connect the UIC serial port to a serial port on the OEM7 receiver. See *UIC Connectors* on page 247 for pinout information for the communications connector (J102).



The serial port on the UIC uses RS-422 levels.

To connect the UIC to devices that use other signals levels, such as an LVCMOS COM port on the OEM7 receiver, an interface circuit that converts to and from RS-422 must be used.

Table 9: COM Port Recommendations

| | |
|----------------|---|
| OEM719 | All of the COM ports on these receivers use LVCMOS levels. |
| OEM7700 | An interface circuit that converts to and from RS-422 levels is required for the port connected to the UIC. |
| OEM7720 | |
| OEM729 | <p>COM1 on the OEM729 receiver can use RS-232 levels (default) or RS-422 levels.</p> <p>To use COM1 for connection to the UIC, configure the COM1 port to use RS-422 levels. Refer to the OEM7 Installation and Operation User Manual for information about changing COM1 to RS-422 levels.</p> <p>COM2 and COM3 on the OEM729 receiver use LVCMOS levels. To use COM2 or COM3 for connection to the UIC serial port, an interface circuit that converts to and from RS-422 levels is required.</p> |



For information about the OEM7 receiver card connectors and pinouts, refer to the [OEM7 Installation and Operation User Manual](#).

2. Connect a computer (for monitoring and configuration) to the OEM7 receiver.

Refer to the [OEM7 Installation and Operation User Manual](#) for information about connecting data communications equipment to an OEM7 receiver.

2.3.4 Connect Power to the UIC and OEM7 Receiver



A separate power supply is required for the OEM7 receiver. For information about the power supply requirements, refer to the Technical Specifications appendix for the receiver card in the [OEM7 Installation and Operation User Manual](#).

1. Using a customer supplied wiring harness, connect a +10 to +34 VDC power supply to the power connector (J101) on the UIC.
See *UIC Connectors* on page 247 for pinout information for the power connector.
2. Using a customer supplied wiring harness, connect power to the OEM7 receiver. See the [OEM7 Installation and Operation User Manual](#) for information about connecting power to the receiver.

2.3.5 UIC Status LEDs

The LEDs on the UIC provide basic status information.

Figure 20: UIC Status LEDs





Table 10: UIC Status LEDs

| LED | Off | On (Red) | On (Green) | Flash Slow (Yellow, 1 Hz) | Flash Fast (Yellow, 3 Hz) |
|-------|------------------|---|---|---------------------------------|---------------------------|
| Power | No power to UIC. | An error occurred during boot up or initialization. | UIC is powered on with no errors detected during boot up or initialization. | Boot up and IMU initialization. | N/A |

| LED | Off | On (Red) | On (Green) | Flash Slow (Yellow, 1 Hz) | Flash Fast (Yellow, 3 Hz) |
|------|---|----------|--|---|---|
| Data | No communication between UIC and GNSS receiver. | N/A | UIC is transmitting and receiving data without errors. | UIC is receiving data from the receiver, but not transmitting data. | UIC is transmitting data to the receiver, but not receiving data. |

2.4 PwrPak7 Installation

The following diagram shows a typical SPAN installation using a PwrPak7 and an IMU in an enclosure.

Figure 21: Typical Installation of a SPAN System with a PwrPak7

Complete the following steps to set up your NovAtel SPAN system.

1. Mount the GNSS antenna.

See *Mounting the GNSS Antenna* on page 30 for details.

2. Mount the IMU.

See *Mount the IMU* on page 30 for details.

3. Mount the PwrPak7.

See the [PwrPak7 Installation and Operation User Manual](#) for information about mounting a PwrPak7.

4. Connect the antenna cable from the GNSS antenna to the ANT port on the PwrPak7.

5. Connect the IMU to the OEM7 receiver.
See *Connect the IMU to the PwrPak7* below for details.
6. Connect the I/O strobe signals (optional).
See the [PwrPak7 Installation and Operation User Manual](#) for information about connecting I/O signals to a PwrPak7.
7. Connect power to the IMU and receiver.
See *Connect Power* on page 44 for details.
8. Connect a data communication device, such a computer, to the receiver. A data communication device is used to configure and monitor the receiver.
See the [PwrPak7 Installation and Operation User Manual](#) for information about connecting a data communication device to a PwrPak7.

2.4.1 Connect the IMU to the PwrPak7

Connect the IMU to the COM1 or COM2 serial port on the PwrPak7. Both of these serial ports are available on the HD26 COM PORTS connector on the PwrPak7.



IMU-CPT, IMU-KVH1750 and IMU-FSAS

These IMUs require an additional output from the HD26 COM PORTS connector on the PwrPak7 to synchronize the IMU and receiver. See *Table 11: Additional IMU to PwrPak7 Connections* on the next page.



If using a KVH1750 IMU, the baud rate of the IMU must be changed to 460,800 bps. For information about changing the IMU baud rate, see *Connect Directly to the IMU* on page 43.

NovAtel IMU Interface Cables

An interface cable is available from NovAtel for each IMU supported by OEM7 receivers. The interface cables provide access to the IMU power and communication signals. For information about these cables, refer to the applicable IMU in the *IMU Technical Specifications* on page 114.

PwrPak7 Cables

The following communication cable is available from NovAtel for connecting an IMU to the PwrPak7.

- PwrPak7 IMU Cable (01019767)

This cable connects the PwrPak7 to an IMU in an IMU Enclosure (IMU-ISA-100C, IMU-ENC-LN200, IMU-HG1900 or IMU- μ IMU-IC) using the COM1 serial port.

This cable is applicable to SPAN systems with an IMU in the IMU Enclosure that do not require the EVENT inputs, EVENT outputs, PPS output or the other serial COM ports.

Custom IMU Interface Cable Requirements

The HD26 COM PORTS connector provides access to three serial COM ports, three EVENT inputs, three EVENT outputs, the wheel sensor input and PPS output. When selecting or building the

cabling for the PwrPak7, make sure all of the required input and output signals are accounted for in the HD26 COM PORTS connector cabling design.

For information about the DB26 COM PORTS pinout, refer to the [PwrPak7 Installation and Operation User Manual](#).

For information about the IMU port pinout, refer to refer to the applicable IMU in the *IMU Technical Specifications* on page 114.


Some IMUs require an additional signal from the receiver to synchronize the receiver and IMU.

Table 11: Additional IMU to PwrPak7 Connections

| IMU | IMU Connector | | PwrPak7 DB26 COM PORTS | |
|-------------|----------------------|-----|------------------------|-----|
| | Signal Name | Pin | Signal Name | Pin |
| IMU-CPT | External Clock Input | 36 | EVENT_OUT1 | 16 |
| IMU-KVH1750 | MSync | 11 | EVENT_OUT1 | 16 |
| IMU-FSAS | DAS(+) | 7 | EVENT_OUT1 | 16 |

2.5 PwrPak7-E1 Installation

The following diagram shows a typical SPAN installation using a PwrPak7-E1.

Figure 22: Typical Installation of a SPAN System with a PwrPak7-E1

Complete the following steps to set up your NovAtel SPAN system.

1. Mount the GNSS antenna.

See *Mounting the GNSS Antenna* on page 30 for details.

2. Mount the PwrPak7-E1.

See the [PwrPak7 Installation and Operation User Manual](#) for information about mounting a PwrPak7-E1.

3. Connect the antenna cable from the GNSS antenna to the ANT port on the PwrPak7-E1.

4. Connect the I/O strobe signals (optional).

See the [PwrPak7 Installation and Operation User Manual](#) for information about connecting I/O signals to a PwrPak7.

5. Connect power to the PwrPak7-E1.

See *Connect Power* on page 44 for details.

6. Connect a data communication device, such a computer, to the receiver. A data communication device is used to configure and monitor the receiver.

See the [PwrPak7 Installation and Operation User Manual](#) for information about connecting a data communication device to a PwrPak7.

2.6 Wheel Sensor Installation

A wheel sensor, also known as a Distance Measurement Instrument (DMI), is used to measure the distance traveled by counting the number of revolutions of a ground vehicle wheel.

2.6.1 Wheel Sensor Requirements

The PwrPak7 and certain IMU enclosures receivers are compatible with any wheel sensor meeting the following requirements:

- Output signal range is less than or equal to 45 Hz.
- Output signal duty cycle is symmetric 40% to 60%.
- Output signal voltage is between -11 and +15 VDC.
- The wheel sensor is powered externally. The receiver does not supply power to the wheel sensor.
- Quadrature, pulse and direction wheel sensors are compatible.

An example of a compatible DMI is the Kistler Wheel Pulse Transducer CWPTA411 (WPT). See *Figure 23: Kistler WPT* below.

- A transducer traditionally fits to the outside of a non-drive wheel. A pulse is then generated from the transducer which is fed to the receiver.
- The WPT mounts to the wheel lug nuts via adjustable mounting collets. The torsion protection rod, which maintains rotation around the wheel axis, affixes to the vehicle body with suction cups. Refer to the Kistler WPT (part number CWPTA411) user manual for mounting instructions.

Figure 23: Kistler WPT





Kistler provides an M12 to DB9 cable for use with the WPT DMI. However, certain revisions of this cable do not bring through all four signal inputs. SPAN systems require at a minimum the A+ and A- signals for distance. All four signal inputs are required to measure both distance and direction correctly. See your WPT documentation for cable details.

Table 12: Kistler to NovAtel Wheel Sensor Cable Connections

| Kistler Cable ¹ | | PwrPak7 | IMU Enclosure | | IMU-FSAS |
|----------------------------|----------------------------------|-----------------------|--------------------------------|------------|-----------------------|
| M12 Connector | | All I/O Cable | M12 Connector on NovAtel Cable | | Female DB9 |
| Pin | Signal | Wire Label | Pin | Wire Color | Pin |
| Pin 1 | GND | External ² | External ² | | External ² |
| Pin 2 | +U _B (Input Power) | | | | |
| Pin 3 | Signal A+ | Wheel Sensor A+ | Pin 1 | White | Pin 6 |
| Pin 4 | Signal A- | Wheel Sensor A- | Pin 4 | Yellow | Pin 7 |
| Pin 5 | Signal B+ | Wheel Sensor B+ | Pin 2 | Brown | Pin 3 |
| Pin 6 | Signal B- | Wheel Sensor B- | Pin 5 | Grey | Pin 1 |
| Pin 7 | Reserved | No Connection | No Connection | | No Connection |
| Pin 8 | | | | | |

2.6.2 Wheel Sensor Connection

Depending on the SPAN system components, the wheel sensor can be connected to the PwrPak7, the IMU or a UIC.

Wheel Sensor Connection to a PwrPak7

A wheel sensor can be used with any SPAN capable PwrPak7 receiver. This can be a PwrPak7-E1 or a PwrPak7 with an external IMU.



When using a PwrPak7 with an external IMU, the wheel sensor can be connected to the PwrPak7 or the IMU. If connecting the wheel sensor to the IMU, refer to *Wheel Sensor Connection to the IMU* on the next page.

This modification is for the Kistler WPT 8-pin M12-plug cable number 14865.

²The WPT requires power to operate, which is not supplied through the receiver or IMU. Pins 1 and 2 should therefore be connected to an external power supply (+10 to +30 VDC).



The PwrPak7 can accept wheel sensor data from only one wheel sensor. If connecting the wheel sensor to the PwrPak7, do not connect a second wheel sensor to the external IMU.

To connect a wheel sensor:

1. Connect the PwrPak7 All I/O Cable, or custom interface cable, to the HD26 COM PORT connector on the PwrPak7.

For information about creating a custom interface cable, see the [PwrPak7 Installation and Operation User Manual](#).

2. Connect the wheel sensor wires on the interface cable to the wheel sensor.
3. Connect an external power supply to the wheel sensor.

The power required for the wheel sensor depends on the wheel sensor used. Refer to the wheel sensor user documents for more information.

For information about configuring the wheel sensor, see *SPAN Wheel Sensor Configuration* on page 96.

Wheel Sensor Connection to the IMU

A wheel sensor can be connected to the following IMUs:

- IMUs in the NovAtel IMU Enclosure
 - IMU-ISA-100C
 - IMU-ENC-LN200
 - IMU-HG1900
 - IMU- μ IMU-IC
- IMU-IGM-A1
- IMU-IGM-S1
- IMU-FSAS

When a wheel sensor is connected to the IMU, the wheel sensor data goes through the IMU and then into the SPAN receiver through the serial communication line.

To connect a wheel sensor to the IMU:

1. Install the SPAN system using the instructions in *OEM7 Receiver Card Installation* on page 27 or *PwrPak7 Installation* on page 61.



If using an IMU-FSAS, use the IMU-FSAS Cable with Wheel Sensor or a custom cable that provides access to the wheel sensor inputs. See the *IMU-FSAS Cable with Wheel Sensor* on page 132 for more information.

2. Connect the wheel sensor to the IMU.

For IMUs in the NovAtel IMU Enclosure, use the IMU Enclosure Wheel Sensor cable, or a custom cable, to connect the wheel sensor to the Wheel Sensor port on the IMU. See *IMU*

Enclosure Wheel Sensor Cable on page 160 for information about the cable or for information about creating a custom wheel sensor cable.

For the IMU-IGM-A1 or IMU-IGM-S1, use a custom cable to connect the wheel sensor to the AUX port on the IMU. Refer to *IMU-IGM Ports* on page 143 for the pin out of the IMU-IGM AUX port.

For the IMU-FSAS, connect the wheel sensor to the wheel sensor inputs on the IMU interface cable.

3. Connect an external power supply to the wheel sensor.

The power required for the wheel sensor depends on the wheel sensor used. Refer to the wheel sensor user documents for more information.

For information about configuring the wheel sensor, see *SPAN Wheel Sensor Configuration* on page 96.

Wheel Sensor Connection to a UIC

When a UIC is used to connect one of the following IMUs to an OEM7 receiver, a wheel sensor can also be connected to the SPAN system using the UIC.

- OEM-IMU-ISA-100C
- OEM-IMU-LN200
- OEM-IMU-HG1900
- OEM-IMU- μ IMU

To connect a wheel sensor to the UIC:

1. Install the SPAN system components using the instruction in *UIC Installation* on page 56.

When creating the UIC cabling, ensure the wheel sensor inputs on the UIC to Receiver Communications Connector (J102) are brought out to a separate connector or wire bundle.

2. Connect the wheel sensor to the UIC wiring harness
3. Connect an external power supply to the wheel sensor.

The power required for the wheel sensor depends on the wheel sensor used. Refer to the wheel sensor user documents for more information.

For information about configuring the wheel sensor, see *SPAN Wheel Sensor Configuration* on page 96.



2.7 IMU LEDs

The IMU-IGM and IMU Enclosure (IMU-HG1900, IMU-ISA-100C, IMU-ENC-LN200, IMU- μ IMU-IC) have LEDs that provide the IMUs basic status information.

Table 13: IMU-IGM LEDs

| LED | Off | On | Flash Slow (1 Hz) | Flash Fast (3 Hz) |
|---------------------------|----------------------|----------------------------------|--|----------------------------|
| Power (Red) | No power to unit | Unit is powered on | UNKNOWN or UNSUPPORTED IMU | Programming error |
| GNSS ¹ (Green) | Waiting for GPS time | Time Status FINE or FINESTEERING | Time status COARSE, COARSESTEERING or FREEWHEELING | N/A |
| INS ¹ (Green) | Not connected to IMU | Connected to IMU | N/A | Bootup or loading firmware |

Table 14: IMU Enclosure LEDs

| LED | Off | On (Red) | On (Green) | Flash Slow (Yellow, 1 Hz) | Flash Fast (Yellow, 3 Hz) |
|--|---|---|---|---|---|
| Power  | No power to IMU Enclosure. | An error occurred during boot up or initialization. | IMU Enclosure is powered on with no errors detected during boot up or initialization. | Boot up and IMU initialization. | N/A |
| COM  | No communication between IMU Enclosure and GNSS receiver. | N/A | IMU Enclosure is transmitting and receiving data without errors. | IMU Enclosure is receiving data from the receiver, but not transmitting data. | IMU Enclosure is transmitting data to the receiver, but not receiving data. |

¹The IMU-IGM must be connected to a GNSS receiver before the state of these LEDs can change to On.

Chapter 3 SPAN Operation

Before operating your SPAN system, ensure that you have followed the installation and setup instructions in *SPAN Installation* on page 27.

You can use the NovAtel Connect software to configure receiver settings and to monitor data in real-time, between a rover SPAN system and base station.

SPAN system output is compatible with post-processing software from the NovAtel Waypoint Products Group. Visit our web site at www.novatel.com for details.



Ensure the Control Panel Power Settings on your computer are not set to go into Hibernate or Standby modes. Data will be lost if one of these modes occurs during a logging session.

3.1 Definition of Reference Frames Within SPAN


The reference frames that are most frequently used throughout the SPAN documentation are the following:

- *The Local-Level Frame (ENU)* below
- *The IMU Body Frame* on the next page
- *The Vehicle Frame* on the next page
- *The User Output Frame* on page 73

3.1.1 The Local-Level Frame (ENU)

The definition of the local level coordinate frame is as follows:


- z-axis – pointing up (aligned with gravity)
- y-axis – pointing north
- x-axis – pointing east

Figure 24: Local-Level Frame (ENU)

3.1.2 The IMU Body Frame

The definition of the IMU Body frame is given by the physical axes of the IMU and represents how the sensors are mounted inside the IMU. If your IMU is enclosed, both the IMU Body frame axes and center of navigation are marked on the enclosure. Otherwise, refer to *IMU Technical Specifications* on page 114 for illustrations of the IMU Body frame axes for each device.

The origin of this frame is not the enclosure center, but the center of navigation (sensor center).


Figure 25: IMU Body Frame Marking

3.1.3 The Vehicle Frame

The definition of the vehicle frame is as follows:

- z-axis – points up through the roof of the vehicle perpendicular to the ground
- y-axis – points out the front of the vehicle in the direction of travel
- x-axis – completes the right-handed system (out the right-hand side of the vehicle when facing forward)

Figure 26: Vehicle Frame



3.1.4 The User Output Frame

The user output frame is an arbitrary frame, which can be optionally defined to transfer inertial output to a more useful position or reference frame.

By default, SPAN position and velocity output is given at the center of navigation of the IMU. To output position and velocity at a different location, specify a user offset translation using the **SETINSTRLANSATION** command.

By default, SPAN attitude output is the rotation from the Local-Level frame to the Vehicle frame. If attitude output is desired relative to another frame, specify a user offset rotation using the **SETINSROTATION** command.

3.2 SPAN Translations and Rotations

A SPAN system combines GNSS and INS into a single system. In a GNSS system, the position is reported relative to the phase center of the GNSS antenna. In an INS system, the velocity and attitude data is reported relative to the center of navigation of the IMU. For a SPAN system to provide a combined GNSS+INS position, velocity and attitude, it must know where the GNSS antenna is positioned relative to the IMU.

The orientation of the IMU relative to the forward direction of the vehicle is also needed to convert the velocity and attitude changes sensed by the IMU into the actual motion of the vehicle.

If the SPAN system incorporates other devices, such as a camera connected to an Event Input, the SPAN system also needs to know the location and orientation of these additional devices relative to the IMU.

3.2.1 Translational Offsets

The three dimensional distances between the IMU and other SPAN components are called translational offsets.


The translational offsets are measured in three directions, X axis, Y axis and Z axis, typically relative to the IMU Body frame. Translational offsets can also be entered relative to the Vehicle frame.



The X, Y and Z axes of the IMU Body frame are typically indicated on the IMU enclosure. The X, Y and Z axes of the IMU Body frame are also indicated on the mechanical drawings of the IMUs in the *IMU Technical Specifications* on page 114.

Figure 27: IMU to Antenna Translation Offset below shows an example of the translational offsets from the IMU to a GNSS antenna. In this example, the IMU Body Frame (indicated by the small arrows) has the Y axis pointing in the direction of the vehicle motion and the z axis pointing up.

Figure 27: IMU to Antenna Translation Offset



If the distances measured in this example were X Offset = 1 m, Y Offset = 1.5 m and Z Offset = 2 m, the following values would be entered, based on the IMU Body Frame:

- x = -1
- y = -1.5
- z = 2

The translational offsets are entered using the **SETINSTRLATION** command. For this example, the command to enter these offsets is:

```
SETINSTRLATION ANT1 -1 -1.5 2
```



The measurements for the translational offsets should be done as accurately as possible, preferably to within millimeters especially for RTK operation. Any error in the offsets will translate into an error in the INS position.

The translational offsets from the IMU to the GNSS antenna are required for all SPAN systems. However, some SPAN systems may have other sensors or devices integrated into the system for which the SPAN needs translational offsets. For example, a gimbal mount or a camera or LiDAR connected to an Event Input line. The offsets to these additional sensors and devices are also entered using the **SETINSTRANSLATION** command.

By default, the translational offsets are entered in the IMU Body Frame. However, in some systems the IMU Body Frame may not be known precisely. For these cases, the **SETINSTRANSLATION** command has an option that allows the offsets to be entered relative to the Vehicle Frame. In these cases, the rotation from the IMU Body Frame to the Vehicle Frame (RBV) is used to rotate offsets into the default IMU Body frame as required. To achieve the best results, this means that the RBV rotation must be known very precisely. Typically this is achieved through the SPAN RBV Calibration procedure. See *Body to Vehicle Frame Rotation Calibration Routine* on page 91 for information about this calibration procedure.

3.2.2 Rotational Offsets

The differences in orientation between the IMU and other SPAN components are called rotational offsets. Rotational offsets are given as the rotation from the IMU Body Frame to the frame of interest.




The order of rotations is Z-X-Y and all rotations are right handed.

Generally, frames of reference are defined as Z up, with Y forward, and X completing the right-handed system. An example is the vehicle frame, where Z is always considered to be upwards, Y forward through the direction of travel, and X to the right.

Rotational Offsets - Example

Consider an IMU installed in the following way:



Here, the Euler Angles to rotate from the IMU Body frame to the Vehicle frame (RBV) are:


- X: -90
- Y: 0
- Z: +90

To reach this answer, keep in mind the following rules:

- The goal is to rotate the IMU Body frame to be coincident with the Vehicle frame (i.e. IMU X equals Vehicle X, IMU Y equals Vehicle Y, IMU Z equals Vehicle Z).
- You must rotate from the IMU Body frame to the Vehicle frame.
- You must rotate in the order Z, X, Y.
- Positive rotation is defined according to the right hand rule.


Z Rotation:

Observe that if a positive 90 degree rotation is performed about the IMU Z axis, the rotated IMU X axis becomes collinear with the Vehicle X axis.



X Rotation:

Observe that if a negative 90 degree rotation is performed about the new IMU X axis, the rotated IMU Y axis is now collinear with the Vehicle Y axis, and the rotated IMU Z axis is also collinear with the Vehicle Z axis.



Y Rotation:

Since all three sets of axes are already collinear, our frames are coincident, and no further rotation is required.



This solution is not unique. Due to the properties of Euler Angles, there are usually multiple sets of equivalent rotations.

The rotational offsets are entered using the **SETINSROTATION** command. For this example, the command to enter the rotations for the previous example is:

```
SETINSROTATION RBV -90 0 90
```

3.3 Software Configuration

On a SPAN system, both the GNSS receiver and the IMU must be configured.

3.3.1 Minimum Recommended Configuration

When configuring your OEM7 SPAN system for first time use, the following is the minimum amount of information required to ensure proper operation of a SPAN system.

| Required Information | Required Command |
|----------------------------------|------------------------|
| IMU type and communication port | CONNECTIMU |
| IMU to primary antenna lever arm | SETINSTRANS�ATION ANT1 |
| IMU to vehicle frame rotation | SETINSROTATION RBV |

While this is the minimum amount of information required, additional information is typically needed for SPAN systems. The following commands are commonly used to configure SPAN systems.

| Common User Settings | Appropriate Command | Notes |
|------------------------------------|------------------------|--|
| IMU to output position offset | SETINSTRANS�ATION USER | Default output position is at the IMU center |
| IMU to output frame rotation | SETINSROTATION USER | Default output frame is the vehicle frame |
| IMU to secondary antenna lever arm | SETINSTRANS�ATION ANT2 | Only required for dual antenna systems |
| Vehicle type | SETINSPROFILE | |
| Minimum alignment velocity | SETALIGNMENTVEL | |

3.3.2 GNSS Configuration

The GNSS configuration can be set up for different accuracy levels such as single point, SBAS, DGPS, PPP and RTK. Refer to the [OEM7 Installation and Operation User Manual](#) for details on DGPS, RTK, L-Band or SBAS setup and operation.

With no additional configuration, the system operates in single point mode.

3.3.3 INS Profiles

INS Profiles provide two major functions; simplified configuration and enhanced performance. These functions are divided into *basic* and *plus* settings via the command. The *basic* options are available to all SPAN enabled models and allow for simple configuration rather than sending many discreet commands. The *plus* models are restricted by model and enable additional performance or functionality, such as dead reckoning or heave.

Table 15: INS Profiles

| Profile | Description | Default Settings Modified |
|-----------------|---|---|
| DEFAULT | The default SPAN profile. This profile has legacy SPAN default settings. | None |
| LAND_BASIC | Basic profile for fixed axle land vehicles. Enables robust kinematic alignment routines and configures the update profile. | Enable direction detection on kinematic alignment routine Enable course over ground attitude updates |
| LAND_PLUS | Extended profile for fixed axle land vehicles. Builds upon the basic profile and also enables the ability for extended dead reckoning. This profile requires an enhanced profile capable receiver model. | Enable Dead Reckoning |
| MARINE_BASIC | Basic profile for marine vessels. Enacts changes to disable static behavior and make the marine solution more robust. | Disable Zero Velocity Updates Disable turn-on bias estimation |
| MARINE_PLUS | Enhanced marine profile adds access to the Heave filter output. This profile requires an enhanced profile capable receiver model. | Enable Heave algorithms |
| FIXEDWING_BASIC | For fixed wing aircraft | Disable Zero Velocity Updates |
| VTOL_BASIC | For Vertical Take Off and Landing aircraft (helicopter, quadcopter, etc.) | Disable Zero Velocity Updates |
| RAIL_BASIC | For railway applications | Enable direction detection on kinematic alignment routine Enable course over ground attitude updates |

Use

To use an INS Profile, send the **SETINSPROFILE** command at startup (or save to NVM) to activate the mode. For example:

```
SETINSPROFILE LAND
```



The currently selected profile option is available in the **INSCONFIG** log.

RBV Calibration

For the profiles to provide the greatest benefit, the rotation offset of the IMU body to the vehicle frame (RBV) should be known as accurately as possible. Since constraints happen at the vehicle level, any error in the offset will translate into worse performance. These parameters are estimated in the background when the system is fully converged, however it is always better to have this measured as precisely as possible before mission critical data is collected.

The INSCALIBRATE RBV functionality can be used to estimate and save these offsets to NVM in a controlled manor.

3.3.4 SPAN Configuration

- *Configure SPAN Manually* below
- *SPAN Configuration with NovAtel Connect* on page 82
- *SPAN Configuration with NovAtel Web User Interface* on page 82

Configure SPAN Manually

Follow these steps to enable INS as part of the SPAN system using software commands:



A GNSS antenna with a clear view of the sky must be connected and tracking satellites for operation.

1. Issue the **CONNECTIMU** command to specify the type of IMU being used and the receiver port connected to the IMU, see *Table 16: Enable INS Commands* below and the **CONNECTIMU** command.

Table 16: Enable INS Commands

| IMU Type | CONNECTIMU command ¹ |
|-------------|---|
| ADIS-16488 | CONNECTIMU COMx ADIS16488 ² CONNECTIMU SPI ADIS16488 ³ |
| EG320N | CONNECTIMU SPI EPSON_G320 |
| HG1700 AG11 | CONNECTIMU COMx HG1700_AG11 |
| HG1700 AG17 | CONNECTIMU COMx HG1700_AG17 |
| HG1700 AG58 | CONNECTIMU COMx HG1700_AG58 |

Use the COM port number the IMU is connected to.

If you are using the OEM719+MIC board stack, you must use COM1.

For SPAN systems with a OEM729 receiver, COM2 is the recommended serial port for the IMU, however you can use any available port for these IMUs

²When the ADIS16488 is connected using a MIC.

³When the ADIS16488 is connected directly to an OEM7 receiver.

| IMU Type | CONNECTIMU command ¹ |
|----------------|---|
| HG1700 AG62 | CONNECTIMU COMx HG1700_AG62 |
| HG1900 CA50 | CONNECTIMU COMx HG1900_CA50 |
| HG1930 CA50 | CONNECTIMU COMx HG1930_CA50 |
| IMU-FSAS | CONNECTIMU COMx IMAR_FSAS |
| IMU-CPT | CONNECTIMU COMx KVH_COTS |
| IMU-IGM-A1 | CONNECTIMU COMx ADIS16488 |
| IMU-IGM-S1 | CONNECTIMU COMx STIM300 |
| IMU-ISA-100C | CONNECTIMU COMx ISA100C |
| IMU-KVH1750 | CONNECTIMU COMx KVH_1750 |
| IMU- μ IMU | CONNECTIMU COMx LITEF_MICROIMU |
| LN-200 | CONNECTIMU COMx LN200 |
| STIM300 | CONNECTIMU COMx STIM300 ² CONNECTIMU COMx STIM300D ³ |

- If the SPAN system uses an OEM-HG1900 IMU connected to a MIC card, issue the following command.

```
SETIMUPORTPROTOCOL RS232
```

Basic configuration of the SPAN system is now complete. The inertial filter starts after the GNSS solution is solved and the IMU is connected.

- Issue the **SETINSTRANSLATION** command, using the **ANT1** parameter, to enter the distance from the IMU to the GNSS antenna. See the **SETINSTRANSLATION** command in the [OEM7 Commands and Logs Reference Manual](#) for more information.

The offset between the antenna phase center and the IMU axis must remain constant and be known accurately (m). The X, Y and Z directions are clearly marked on the IMU enclosure. The SETINSTRANSLATION parameters are (where the standard deviation fields are optional and the distances are measured from the IMU to the antenna):

```
ANT1 x_offset y_offset z_offset [x_stdev] [y_stdev] [z_stdev]
```


Use the COM port number the IMU is connected to.

If you are using the OEM719+MIC board stack, you must use COM1.

For SPAN systems with a OEM729 receiver, COM2 is the recommended serial port for the IMU, however you can use any available port for these IMUs

²When the STIM300 is connected using a MIC.

³When the STIM300 is connected directly to an OEM7 receiver.



This example shows a mounting configuration with a negative X offset, negative Y offset and positive Z offset.

A typical RTK GNSS solution is accurate to a few centimetres. For the integrated GNSS+INS system to have this level of accuracy, the offset must be measured to within a centimetre. Any offset error between the two systems shows up directly in the output position. For example, a 10 cm error in recording this offset will result in at least a 10 cm error in the output.

If it is impossible to measure the IMU to GNSS antenna offset precisely, the offset can be estimated by carrying out the Lever Arm Calibration Routine. See *Lever Arm Calibration Routine* on page 90.

- Issue the **SETINSROTATION** command, using the **RBV** parameter, to enter the Euler Angle rotation from the IMU Body frame to the Vehicle frame. See the **SETINSROTATION** command in the [OEM7 Commands and Logs Reference Manual](#) for more information.


Accurate knowledge of the rotational offset between the IMU Body frame and the Vehicle frame (the RBV rotation) is critical to correctly computing an attitude solution, and is required before a Kinematic alignment is possible.

The SETINSROTATION parameters are (where the standard deviation fields are optional):

```
RBV x_rotation y_rotation z_rotation [x_stddev] [y_stddev] [z_stddev]
```



The order of rotations is Z-X-Y. All rotations are right handed.



For an example of how to solve for the IMU Body to Vehicle frame rotation refer to *Rotational Offsets* on page 75.

If the rotation between the IMU Body frame and the Vehicle frame is not precisely known, enter an approximate rotation (to the nearest 45 degrees). The precise offset can be estimated by carrying out the *Body to Vehicle Frame Rotation Calibration Routine* on page 91.

SPAN Configuration with NovAtel Connect

NovAtel Connect provides a wizard that takes you through the steps required to configure a SPAN system. For information about using the SPAN Configuration wizard in NovAtel Connect, refer to the help file available within NovAtel Connect.



NovAtel Connect version 2.0 or greater is required for OEM7 receivers. Download the latest NovAtel Connect software and documentation from www.novatel.com/novatel-connect.

SPAN Configuration with NovAtel Web User Interface

The SPAN parameters can be configured using the NovAtel Web User Interface. For information about using the NovAtel Web User Interface, refer to the online OEM7 documentation (docs.novatel.com/OEM7).

3.4 Real-Time Operation

SPAN operates through the OEM7 command and log interface. Commands and logs are documented in the [OEM7 Commands and Logs Reference Manual](#).

Real-time operation notes:

- By default, raw IMU data will begin to output as soon as the IMU is connected. However an initial position is required to begin the INS alignment process. This position is typically set by GNSS. The GNSS position will not be used until the FINESTEERING time status is reached. This requires a GNSS antenna connected with a clear view of the sky. See *System Start-Up and Alignment Techniques* on page 84 for more details.
- The inertial solution is computed separately from the GNSS solution. The GNSS solution is

available from the SPAN system through the GNSS-specific logs, even without SPAN running. The integrated GNSS+INS solution is available through special INS logs documented in the [OEM7 Commands and Logs Reference Manual](#).

- The IMU raw data is available at the maximum rate of output of the IMU. Because of this high data rate, a shorter header format was created. These shorter header logs are defined with an S (RAWIMUSXB rather than RAWIMUXB). We recommend you use these logs instead of the standard header logs to save throughput on the COM port.

Status of the inertial solution can be monitored using the inertial status field in the INS logs, see *Table 17: Inertial Solution Status* below.

Table 17: Inertial Solution Status

| Binary | ASCII | Description |
|--------|-------------------------|--|
| 0 | INS_INACTIVE | IMU logs are present, but the alignment routine has not started; INS is inactive. |
| 1 | INS_ALIGNING | INS is in alignment mode. |
| 2 | INS_HIGH_VARIANCE | The INS solution is still being computed but the azimuth solution uncertainty has exceeded the threshold. The default threshold is IMU dependent. ^a The solution is still valid but you should monitor the solution uncertainty in the INSSTDEV log. You may encounter this state during times when the GNSS, used to aid the INS, is absent. ^b |
| 3 | INS_SOLUTION_GOOD | The INS filter is in navigation mode and the INS solution is good. |
| 6 | INS_SOLUTION_FREE | The INS filter is in navigation mode and the GNSS solution is suspected to be in error. This may be due to multipath or limited satellite visibility. The inertial filter has rejected the GNSS position and is waiting for the solution quality to improve. |
| 7 | INS_ALIGNMENT_COMPLETE | The INS filter is in navigation mode, but not enough vehicle dynamics have been experienced for the system to be within specifications. |
| 8 | DETERMINING_ORIENTATION | INS is determining the IMU axis aligned with gravity. |
| 9 | WAITING_INITIALPOS | The INS filter has determined the IMU orientation and is awaiting an initial position estimate to begin the alignment process. |

^aThis value is configured using the INSTHRESHOLDS command. See the [OEM7 Commands and Logs Reference Manual](#) for more information..

^bSee also question #7 in *Frequently Asked Questions* on page 285.

| Binary | ASCII | Description |
|--------|---------------------|---|
| 10 | WAITING_AZIMUTH | The INS filter has determined the IMU orientation, received an initial position and completed initial bias estimates. Azimuth input (from vehicle motion, dual antenna or command) is required for alignment. |
| 11 | INITIALIZING_BIASES | The INS filter has determined the IMU orientation, received an initial position and is conducting an initial IMU bias estimate. |
| 12 | MOTION_DETECT | Vehicle motion has been detected. |

3.4.1 System Start-Up and Alignment Techniques

The system requires an initial position, velocity and attitude estimate to start the navigation filter. This is called system alignment. On start-up, the system has no position, velocity or attitude information. When the system is first powered up, the following sequence of events happens:

1. The first satellites are tracked and coarse time is solved.
2. Enough satellites are tracked to compute a position.
3. Receiver "fine time" is solved, meaning the time on board the receiver is accurate enough to begin timing IMU measurements.
4. The INS Status field changes from INS_INACTIVE through DETERMINING_ORIENTATION and WAITING_INITIALPOS.
5. Once a GNSS position is available, an initial IMU bias estimate is conducted. During this period, the INS Status field reports INITIALIZING_BIASES.
6. After the bias estimate is complete, the coarse alignment routine starts. Bias estimates will be refined and a static alignment completed, if IMU quality allows. During this period the INS Status field reports INS_ALIGNING.
7. If static coarse alignment is not possible or is locked out by command, the system will require an external azimuth input, either from vehicle motion, dual antenna input or command input. While in this state the INS Status field reports WAITING_AZIMUTH.

If vehicle movement is detected, any ongoing static coarse alignment will be reset, and the INS Status field will report MOTION_DETECT.

8. After an alignment is completed, the INS Status field changes to INS_ALIGNMENT_COMPLETE. The system transitions to navigation mode.
9. The solution is refined using updates from GNSS. Once the system is operating within specifications and after some vehicle movement, the INS Status field changes to INS_SOLUTION_GOOD. This indicates that the estimated azimuth standard deviation is below the preset value. If it increases above the preset value, the status changes to INS_HIGH_VARIANCE.

Coarse Alignment

The coarse alignment is the default alignment routine for SPAN. The alignment starts automatically when a GNSS solution is available, the receiver has computed fine time, the IMU is connected and configured and initial bias estimates have been completed. During the coarse alignment, accelerometer and gyro measurements are averaged over a period of time to measure Earth rotation and gravity. From these averaged measurements, initial estimates of roll,

pitch and heading are computed. Because the coarse alignment uses averaged sensor output, the vehicle must remain stationary for the duration of the alignment, which is approximately 45 seconds. The attitude estimates solved by the alignment are larger than the system specified attitude accuracy and vary upon the characteristics of the sensor and the geographic latitude of the system. Attitude accuracy converges with motion after the coarse alignment is complete (see *Navigation Mode* on page 88).



The ADIS-16488, IMU-CPT, IMU-IGM, HG1930, EG320N and STIM300 IMUs, and PwrPak7-E1, cannot perform coarse alignments, as these IMUs cannot accurately measure Earth rotation. For these IMUs, the default alignment routine is the kinematic alignment. Refer to *Kinematic Alignment* below. If a stationary alignment is required, refer to *Manual Alignment* on the next page.

Kinematic Alignment

An alternate form of aligning the SPAN system is a kinematic alignment. A kinematic alignment can be used for any SPAN system and is the best alignment alternative for lower performance sensors (ADIS-16488, IMU-IGM, IMU-CPT, HG1930, EG320N, STIM300 and PwrPak7-E1). The kinematic or moving alignment is performed by estimating the heading from the GNSS velocity vector and injecting it into the SPAN filter as the initial system heading.

This method for alignment assumes that the roll and pitch of the vehicle are near to zero. This should be kept in mind when attempting to do this in airborne or marine environments as these assumptions may not hold causing a poor initial solution.

For the kinematic alignment routine to work optimally, the course-over-ground azimuth and pitch must match the IMU enclosure azimuth and pitch. (For example, a plane being blown in the wind has a large 'crab angle' and the course-over-ground trajectory will not match the direction the IMU is pointing.)

The rotation from the IMU Body frame to the Vehicle frame (RBV) must be set to enable kinematic alignment. In order to simplify this configuration it is strongly suggested that you mount the IMU in parallel to the vehicle frame. The Y axis marked on the IMU enclosure, should point in the direction of travel.

The kinematic alignment begins when the receiver has a good GNSS position, fine time is solved, the Body to Vehicle frame rotation is known and a GNSS velocity of at least 5 m/s (~ 18 km/h) is observed. During kinematic alignment, keep the vehicle roll at less than 10°.



5 m/s is the default alignment velocity. If a different alignment velocity is required, it can be changed using the **SETALIGNMENTVEL** command. See the [OEM7 Commands and Logs Reference Manual](#) for more information.

While it is possible to lower the minimum speed required for kinematic alignment to take place, the higher the value, the more closely the course-over-ground estimate will match the vehicle heading.

The accuracy of the initial attitude of the system following the kinematic alignment varies and depends on the dynamics of the vehicle. The attitude accuracy will converge to within specifications once some motion is observed by the system. This transition can be observed by monitoring the INS Status field in the INS logs.

Dual Antenna Alignment

SPAN can also use heading information available from a NovAtel Dual Antenna ALIGN solution to rapidly perform an alignment. Refer to *SPAN with Dual Antenna* on page 108 for details.

NVM Seeded Alignment

SPAN can use the alignment information from a previous power up to quickly perform an alignment. For information about enabling and using an NVM Seeded Alignment, refer to *INS Seed / Fast INS Initialization* below.

Manual Alignment

If the initial azimuth of the system is known, it can be entered manually using the **SETINITAZIMUTH** command. Refer the [OEM7 Commands and Logs Reference Manual](#) for more information about the **SETINITAZIMUTH** command.



A manual alignment should be used only if the azimuth is accurately known.

3.4.2 INS Seed / Fast INS Initialization

The INS Seed functionality is an alignment method whereby INS alignment information from a previous powerup can be injected into the system at startup to achieve an INS alignment very quickly. This is especially useful for systems that previously required a kinematic alignment.

This works by automatically saving the current INS position and attitude information to NVM when the system is stationary. During subsequent power ups, the saved solution is compared to the current position of the system, and if it is determined not to have moved since the seed data was stored, this information is used to rapidly initialize the INS filter, meaning the system will be ready for navigation.

This feature is enabled via the **INSEED** command. This command setting must be saved to NVM via the **SAVECONFIG** command to be used upon next system boot-up.

Criteria

For the INS seed functionality to be enabled, the **INSEED ENABLE** command must be sent.

Saving

The following criteria must be met for a valid seed to be saved into receiver NVM.

- The INS solution status must be `INS_SOLUTION_GOOD`.
- The velocity drops below 0.2 m/s.

When these conditions are met, the requirement information is automatically saved to NVM. If these conditions cease to be met, the saved information is automatically discarded.

Use at Boot-up

Upon boot, several checks are done to verify that any seed data existing in NVM is appropriate for use. These checks require a GNSS position to be computed, so an NVM seed will never be injected prior to achieving a GNSS position. The following criteria must be met in order to use a seed:

- Seed data from NVM must be valid
- The system must be stationary
- The system must not have moved significantly from the seed position: <10 metres position and 5 degrees in roll and pitch



INJECT Option (Advanced Users Only)

There is an advanced option available to skip the second and third validation steps described in the boot-up section above. This can be used if GNSS is not available on power-up or if speed to achieve an alignment is imperative.

This option is for advanced users only. Forcing an injection of an NVM seed without the validation checks can cause an unstable INS solution if the vehicle has moved.

Apart from injecting the seed at startup without validation, this will also remove some requirements typically asserted to allow the filter to converge. This will allow the system to run without GNSS adequately at startup.

Example Usage

Enabling functionality after FRESET:

1. Send the following command.

```
INSSEED ENABLE VALIDATE
```

2. Send the following command.

```
SAVECONFIG
```

Saving valid INS information:

1. Drive around until INS Status = INS_SOLUTION_GOOD.
2. Bring the system to a complete stop before powering off or resetting.

Using valid INS information on start-up:

1. Remain static while starting.
2. Wait for system to receive valid position from GNSS.
3. If validated, INS information will be injected.

System Indicators

The **INSSEEDSTATUS** log reports the seed injection status for the current power up and information on current seed validity. Refer the [OEM7 Commands and Logs Reference Manual](#) for more information about the **INSSEEDSTATUS** log.

The Extended Solution Status field has bits that indicate the Alignment type that occurred and NVM seed injection status.

Alignment Type: Bits 26-28

These bits indicate how the INS system reached INS_ALIGNMENT_COMPLETE. When the INS system aligns using saved INS solution data from NVM, bits 27-29 will be set to 101

NVM Seed Status: Bits 29-31

These bits indicate the current status of the seeding process at start-up, as described in the table below:

Table 18: NVM Seed Indication

| Bit 29-31 Values | Hex Value | NVM Seed Type |
|------------------|-----------|--|
| 000 | 0x00 | NVM Seed Inactive |
| 001 | 0x01 | Seed stored in NVM is invalid |
| 010 | 0x02 | NVM Seed failed validation check |
| 011 | 0x03 | NVM Seed is pending validation (awaiting GNSS) |
| 100 | 0x04 | NVM Seed Injected |

3.4.3 Navigation Mode

Once the alignment routine has successfully completed, SPAN enters navigation mode.

SPAN computes the solution by accumulating velocity and rotation increments from the IMU to generate position, velocity and attitude. SPAN models system errors by using a filter. The GNSS solution, phase observations and automatic zero velocity updates (ZUPTs) provide updates to the filter. Peripheral updates can also be supplied; wheel sensor for displacement updates or an external receiver for heading updates.

Following the alignment, the attitude is coarsely defined, especially in heading. Vehicle dynamics, specifically turns, stops and starts, allow the system to observe the heading error and allows the heading accuracy to converge. The amount of dynamics required for filter convergence vary by the alignment quality, IMU quality, and maneuvers performed. The INS Status field changes to `INS_SOLUTION_GOOD` once convergence is complete. If the attitude accuracy decreases, the INS Status field changes to `INS_HIGH_VARIANCE`. When the accuracy converges again, the INS status continues as `INS_SOLUTION_GOOD`.

3.4.4 Data Collection

The INS solution is available in the INS-specific logs with either a standard or short header. Other parameters are available in the logs shown in *Table 19: Solution Parameters* below:

Table 19: Solution Parameters

| Parameter | Logs | |
|-----------|---|--------------------|
| Position | INSPOS or INSPOSS INSPVA or INSPVAS | INSPOSX or INSPVAX |
| Velocity | INSVEL or INSVELS INSSPD or INSSPDS INSPVA or INSPVAS | INSVELX or INSPVAX |

| Parameter | Logs | |
|----------------------|--|--------------------|
| Attitude | INSATT or INSATTS INSPVA or INSPVAS | INSATTX or INSPVAX |
| Solution Uncertainty | INSSTDEV or INSSTDEVS | |



The **INSATTX** log, **INSPOSEX** log, **INSPVAX** log and **INSVELX** log contain solution and variance information and are therefore large logs. Use a low logging rate (<20 Hz) only. These logs also contain solution uncertainty in standard deviation format.

Note that the position, velocity and attitude are available together in the **INSPVA** log, **INSPVAS** log and **INSPVAX** log.

The inertial solution is available up to a rate of 200 Hz. Data can be requested at a specific synchronous time interval, asynchronously matching the IMU output rate, or can be triggered by the mark input trigger at rates up to 200 Hz.

The GNSS-only solution is still available through the GNSS-only logs such as RTKPOS and PSRPOS. Refer to the [OEM7 Commands and Logs Reference Manual](#) for more details on these logs. INS-only data logging and output can be at rates of up to the rate of the IMU data.



The highest rate that you should request GNSS logs (RANGE, BESTPOS, RTKPOS, PSRPOS, and so on) while in INS operation is 5 Hz. If the receiver is not running INS (no IMU is attached), GNSS logs can be requested at rates up to 20 Hz.



Ensure that all windows, other than the Console, are closed in NovAtel Connect and then use the **SAVECONFIG** command to save settings in NVM. Otherwise, unnecessary data logging occurs and may overload your system.

**Logging Restriction Important Notice**

Logging excessive amounts of high rate data can overload the system. When configuring the output for SPAN, NovAtel recommends that only one high rate (>50 Hz) message be configured for output at a time. It is possible to log more than one message at high rates, but doing so could have negative impacts on the system. Also, if logging 100/200 Hz data, always use the binary format and, if possible, the short header binary format (available on most INS logs).

For optimal performance, log only one high rate output at a time. These logs could be:

- Raw data for post processing
RAWIMUXSB ONNEW (output rate depends on IMU see *Table 2: SPAN-Compatible IMUs* on page 25)
 - RAWIMU logs are not valid with the ONTIME trigger. The raw IMU observations contained in these logs are sequential changes in velocity and rotation. As such, you can only use them for navigation if they are logged at their full rate. See details of these logs in the [OEM7 Commands and Logs Reference Manual](#).
- Real time INS solution
IMURATEPVA ONNEW or IMURATEPVAS ONNEW
(These logs require asynchronous logging to be enabled. See **ASYNCHINSLOGGING** command in the [OEM7 Commands and Logs Reference Manual](#))
 - Other possible INS solution logs available at high rates are: INSPVASB, INSPOSSB, INSVELSB, INSATTSB

Specific logs need to be collected for post-processing. See *Data Collection for Post Processing* on page 100.

To store data from an OEM7 receiver, connect the receiver to a computer running NovAtel Connect or other terminal program capable of recording data. On PwrPak7 receivers, you can also collect data on internal memory.

3.4.5 Lever Arm Calibration Routine

Each time the system is re-mounted on a vehicle, or the IMU or antenna is moved on the vehicle, the lever arm must be redefined either through manual measurement or through calibration.



We recommend that you measure the lever arm using survey methodology and equipment, for example, a total station. Only use calibrations when precise measurement of the lever arm is not possible.

Initial estimates and uncertainties for the lever arm may be entered using the **SETINSTRANSLATION ANT1** command. The calibration routine uses these values as the starting point for the lever arm computation.



The Lever Arm Calibration routine is not available for the IMU-CPT, HG-1930, ADIS-16488, EG320N, IMU-IGM, STIM300 or PwrPak7-E1.

The steps involved in the calibration are:

1. Apply power to the receiver and the IMU.
2. Configure the SPAN system, see *SPAN Configuration* on page 79.
3. Perform an initial system alignment using one of the methods described in *System Start-Up and Alignment Techniques* on page 84. Ensure the system reaches Solution Good.
4. Enter the initial estimate for the lever arm using the **SETINSTRANSLATION ANT1** command.
Ensure the standard deviation values entered for the antenna offset are not overly optimistic (i.e, err on the side of a larger standard deviation).
5. Enable calibration using the **INSCALIBRATE** command with an optional standard deviation target.

```
INSCALIBRATE ANT1 NEW [target_stdev]
```

6. To monitor the calibration, log **INSCALSTATUS** using the ONCHANGED trigger.
7. Start to move the system. The lever arm is not observable while the system is stationary. Immediately, drive a series of maneuvers such as figure eights. The turns should alternate between directions, and you should make an equal number of turns in each direction. Some height variation in the route is also useful for providing observability in the Z-axis.
8. When the calibration is complete, either because the accuracy requirement has been met, or the calibration been halted by user command, the calibrated offset value can be viewed in either the **INSCALSTATUS** log or the **INSCONFIG** log.

To save a calibrated lever arm for subsequent start ups, issue the **SAVECONFIG** command after calibration is complete. If the IMU or GNSS antenna are re-mounted, re-run the calibration routine to compute an accurate lever arm.



For information about the logs and commands used in this procedure, refer to the [OEM7 Commands and Logs Reference Manual](#).

3.4.6 Body to Vehicle Frame Rotation Calibration Routine

Kinematic alignment requires that the rotational offset between the vehicle and IMU Body frame (RBV) is known. If the angles are simple (that is, a simple rotation about one axis) the values can easily be entered manually through the **SETINSROTATION RBV** command. If the rotational offset is more complex (that is, rotation is about 2 or 3 axis), then the calibration routine provides a more accurate estimation of the values.

The steps for the calibration routine are:

1. Apply power to the receiver and IMU.
2. Configure the SPAN system including an approximate the IMU Body to Vehicle frame (RBV) rotation. See *SPAN Configuration* on page 79.
3. Ensure that an accurate lever arm has been entered into the system either manually or through a lever arm calibration, see *Lever Arm Calibration Routine* on the previous page.
4. Perform an initial system alignment using one of the methods described in *System Start-Up and Alignment Techniques* on page 84. Ensure the system reaches Solution Good.

5. Enable calibration using the **INSCALIBRATE** command with an optional standard deviation target.

```
INSCALIBRATE RBV NEW [target_stdev]
```

6. To monitor the calibration, log **INSCALSTATUS** using the ONCHANGED trigger.
7. Start to move the system. As with the lever arm calibration, movement of the system is required for the observation of the angular offsets.

Drive a straight course on level ground (remember that most roads have a crown resulting in a constant roll of a few degrees). Avoid driving on a surface with a constant, non-zero, slope to prevent biases in the computed angles. Vehicle speed must be greater than 5 m/s (18 km/hr) for the calibration to complete.

8. When the calibration is complete, either because the accuracy requirement has been met, or the calibration been halted by user command, the calibrated offset value can be viewed in either the **INSCALSTATUS** log or the **INSCONFIG** log.

To save a calibrated rotation for subsequent start ups, issue the **SAVECONFIG** command after calibration is complete. Each time the IMU is re-mounted this calibration should be performed again. See also *Coarse Alignment* on page 84 and *Kinematic Alignment* on page 85 for details on coarse and kinematic alignment.




After the **INSCALIBRATE RBV ENABLE** command is entered, there are no body-vehicle rotation parameters present and a kinematic alignment is NOT possible. Therefore this command should only be entered after the system has performed either a static or kinematic alignment and has a valid INS solution.



For information about the logs and commands used in this procedure, refer to the [OEM7 Commands and Logs Reference Manual](#).

3.4.7 Multi-Line Body to Vehicle Frame Rotation Calibration Routine

The single pass Body to Vehicle frame offset calibration feature assumes flat ground when estimating the roll offsets between the IMU Body and Vehicle frames, as this component of the rotational offset is difficult to observe through typical ground vehicle motion. In practice this can result in an outstanding roll offset error as high as several degrees. For applications where vehicle roll must be well known, or pass-to-pass accuracy of a highly offset position is especially important, the Multi-Line IMU Body to Vehicle frame offset calibration routine offers higher calibrated accuracy in roll. This is done by running independent calibrations over the same ground path in opposite directions; averaging the results cancels out the effect of any terrain induced roll. A minimum of two iterations are required. Additional iteration pairs can be executed for increased reliability.

Figure 28: Multi-Line IMU Body to Vehicle Calibration

The steps for the calibration routine are:

1. Apply power to the receiver and IMU.
2. Configure the SPAN system, see *SPAN Configuration* on page 79.
3. Ensure that an accurate lever arm has been entered into the system either manually or through a lever arm calibration, see *Lever Arm Calibration Routine* on page 90.
4. Perform an initial system alignment using one of the methods described in *System Start-Up and Alignment Techniques* on page 84. Ensure the system reaches Solution Good.
5. Enable a new calibration using the **INSCALIBRATE** command, with the optional standard deviation target omitted:

```
INSCALIBRATE RBV NEW
```

6. Start to move the vehicle. Drive a straight course, at a vehicle speed greater than 5 m/s (18 km/hr). A distance of at approximately 250 metres is recommended.

To monitor the calibration, log **INSCALSTATUS** using the ONCHANGED trigger.

7. When the end of the available distance is reached, stop the vehicle. Halt the ongoing calibration by sending the **INSCALIBRATE** command again:

```
INSCALIBRATE RBV STOP
```

8. At this point **INSCALSTATUS** will report a source status of CALIBRATED. Turn the vehicle around and come to a stop on the finishing point of the previous line.

- Initiate the second pass of the calibration by issuing the **INSCALIBRATE** command with the **ADD** parameter:

```
INSCALIBRATE RBV ADD
```

- Drive the vehicle back along the original course, until you reach the starting point for the first pass. Stop the vehicle, and re-issue the **INSCALIBRATE** command, with the **STOP** parameter. **INSCALSTATUS** will again indicate a source status of CALIBRATED.

At this point the multi-line calibration can be considered complete, but more iterations can be repeated until the desired accuracy level is reached.

- When the calibration is complete, the calibrated offset value can be viewed in either the **INSCALSTATUS** log or the **INSCONFIG** log.

To save a calibrated rotation for subsequent start ups, issue the **SAVECONFIG** command after calibration is complete. Each time the IMU is re-mounted this calibration should be performed again.



After the **INSCALIBRATE RBV ENABLE** command is entered, there are no body-vehicle rotation parameters present and a kinematic alignment is NOT possible. Therefore this command should only be entered after the system has performed either a static or kinematic alignment and has a valid INS solution.



For information about the logs and commands used in this procedure, refer to the [OEM7 Commands and Logs Reference Manual](#).

3.5 Synchronizing External Equipment

A SPAN system allows you to synchronize with external equipment.

All SPAN receivers accept input pulses (events). Each event signal can be configured for positive or negative polarity. Time, or a solution (position, velocity, attitude), can be generated and output with each input pulse.

3.5.1 Configuring an Input Strobe

SPAN systems have several input strobes. The input strobes apply an accurate GNSS time to the rising, or falling, edge of an input pulse called an event. For each event, an accurate position, velocity or attitude solution is also available. Each input strobe is usually associated with a separate device, therefore different solution output lever arm offsets can be applied to each strobe.

Each input strobe can be configured using the **EVENTINCONTROL** command for the following parameters:

Polarity:

When polarity is set to positive, events trigger on the rising edge. When polarity is set to negative, events trigger on the falling edge.

Time Bias (t_bias):

A constant time bias in ns can be applied to each event pulse. Typically this is used to account for a transmission delay.

Time Guard (t_guard):

The time guard specifies the minimum number of milliseconds between pulses. This is used to coarsely filter the input pulses.

The time of the input pulses is available from the **MARKTIME**, **MARK2TIME**, **MARK3TIME** and **MARK4TIME** log. The solution synchronous with the event pulses is available from the **MARK1PVA**, **MARK2PVA**, **MARK3PVA** and **MARK4PVA** log. The logs required for input strobes are:

LOG MARK1TIMEB ONNEW

Output time for every pulse received.

LOG MARK1PVAB ONNEW

Output time, position, velocity and attitude for every pulse received at the location specified by the **SETINSTRANSLATION** command and **SETINSROTATION** command.

The above example is for the MARK1 event input. The input signal levels are 3.3 V to 0 V. Signal voltages outside these bounds damage the receiver. The minimum detectable pulse duration must be greater than or equal to 1 microsecond.



For information about the logs and commands used in this procedure, refer to the [OEM7 Commands and Logs Reference Manual](#).

3.6 Adding Timed Sensor Triggers

Use the EVENT IN and EVENT OUT connections to attach up to three sensor devices to an OEM7 receiver and then trigger the sensors based upon GPS time.

In this context a 'sensor' is any external device. The 'sensor' reference in the receiver is an object consisting of an Event_In and Event_Out pair of system strobes all linked by a sensor identifier.

You can send multiple trigger events marked with a user-specified ID and a GPS time to trigger the sensor. At the requested trigger time, the receiver outputs a user-specified LVCMOS level pulse to the sensor and waits for a response pulse to indicate a sensor measurement (i.e. camera exposure). When this response is received, the SPAN system outputs a log with the inertial position/velocity/attitude and the ID of the event.

3.6.1 Configuring the Hardware

A sensor's trigger input is connected to a valid Event_Out and the sensor's response output is connected to a valid Event_In. Three sensor slots are available for use, but may be limited to less depending on the hardware platform used.

Table 20: Valid Event Inputs and Outputs for Timed Sensor Triggers

| Valid Event Outputs | Valid Event Inputs |
|---------------------|--------------------|
| MARK1 | MARK1 |
| MARK2 | MARK2 |

| Valid Event Outputs | Valid Event Inputs |
|---------------------|--------------------|
| MARK3 | MARK3 |
| MARK4 | MARK4 |

3.6.2 Configuring the Software

Sensor objects are defined by using the **SETUPSENSOR** command. This command allows the Event_In and Event_Out lines to be specified as well as some parameters for the outgoing and incoming signals.



After configuring a sensor using the **SETUPSENSOR** command, any other commands that affect the selected event lines will disturb this functionality. For example, if MARK4 Out is selected for a sensor, but later the **EVENTOUTCONTROL** command is sent, the **EVENTOUTCONTROL** command will reconfigure the properties of the MARK4 line.

3.6.3 Using Timed Event Pulses

When sensors have been connected and configured, use the **TIMEEVENTPULSE** command to queue events on the system. **TIMEEVENTPULSE** specifies the sensors that are affected, the GPS time for the desired event (in weeks and seconds), and an event ID. You can queue 10 unprocessed events at a time. Any time input specified via this command must occur at least 1 second after the command is entered.

The timing accuracy of the **TIMEEVENTPULSE** output is 2 milliseconds.

3.6.4 Recording Incoming Sensor Events

After a **TIMEEVENTPULSE** is sent, the system can be configured to accept an incoming pulse from the sensor in order to produce a time and ID tagged inertial solution associated to that event. This is optional and useful if a sensor provides a measurement TOV pulse. The produced log is a TAGGEDxMARKPVA where the 'x' is the Event_In line associated with that sensor (via the **SETUPSENSOR** command).

For example, if the **SETUPSENSOR** command specifies SENSOR1 to use MARK1 in as the input event then a TAGGEDMARK1PVA log will be produced when any pulses on that line are observed. In this case the TAGGEDMARK1PVA log should be requested ONNEW to capture the data.

3.7 SPAN Wheel Sensor Configuration

A wheel sensor is used to measure the distance traveled by counting the number of revolutions of a ground vehicle wheel. Typical wheel sensor hardware outputs a variable frequency pulse that varies linearly with speed. If the pulses are accumulated and the size of the wheel known, a displacement of the wheel over time can be calculated. The SPAN system takes in a wheel sensor input and applies a displacement update to the GNSS+INS Kalman filter in order to constrain the position error growth during GNSS outages. SPAN also automatically estimates the size of the wheel to mitigate small changes in the size of the wheel due to hardware changes or environmental conditions.

The wheel sensor ticks are accumulated by the SPAN receiver or by the IMU and then passed on to the SPAN receiver.

- For the PwrPak7, the wheel sensor is connected to the HD26 COM PORTS connector
- For the IMU Enclosure (IMU-HG1900, IMU-ISA-100C, IMU-ENC-LN200 or IMU- μ IMU-IC), the wheel sensor is connected to the Wheel Sensor port using the optional Wheel Sensor Cable (60723137) or a custom cable. See *IMU Enclosure Wheel Sensor Cable* on page 160 for information about the Wheel Sensor Cable and the Wheel Sensor port pinout.
- For the IMU-FSAS and IMU-CPT, the wheel sensor is integrated via the IMU and wheel velocity commands are not required.
- For the IMU-IGM-A1 and IMU-IGM-S1, the wheel sensor is connected to the AUX port on the enclosure.

For information about connecting a wheel sensor, refer to *Wheel Sensor Installation* on page 66.

3.7.1 Wheel Sensor Data Collected on the PwrPak7

The PwrPak7 accepts input from a wheel sensor on the HD26 COM PORTS connector. See PwrPak7 Connectors in the [PwrPak7 Installation and Operation User Manual](#) for information about the COM PORTS connector.

Measurement Timing and Frequency

Typical wheel sensor hardware generates wheel ticks constantly as the wheel rotates. The PwrPak7 interface is configured to accumulate wheel sensor tick counts at a rate of 1 Hz.

Wheel Sensor Update Logic

Wheel sensor data is available through the **TIMEDWHEELDATA** log. The **TIMEDWHEELDATA** log can be used for applying wheel sensor updates in post-processing.

The SPAN filter uses sequential TIMEDWHEELDATA logs to compute a distance traveled between update intervals (1 Hz). This information is used to constrain free inertial drift during times of poor GNSS visibility. The filter also contains a state for modeling the circumference of the wheel as it may change due to hardware changes or environmental conditions.

The modeled wheel circumference is available in the **WHEELSIZE** log. Information about how the wheel sensor updates are being used is available in the **INSUPDATESTATUS** log.

Set up a Wheel Sensor

1. Send the following command to setup the wheel sensor.

```
SETWHEELPARAMETERS <ticks> <circ> 1.0
```



The parameters entered in the SETWHEELPARAMETERS command depend on the wheel sensor being used. For more information about this command see the **SETWHEELPARAMETERS** command in the [OEM7 Commands and Logs Reference Manual](#).

2. Send the following commands to log the wheel sensor data.

```
LOG WHEELSIZEB ONCHANGED
LOG TIMEDWHEELDATAB ONNEW
```

3.7.2 Wheel Sensor Data Collected on IMU

The SPAN system uses the wheel sensor data passed in and timed through the IMU-CPT, IMU-FSAS, IMU-IGM, IMU-HG1900, IMU-ISA-100C, IMU-ENC-LN200 or IMU- μ IMU-IC. This timed data is passed to the GNSS+INS filter to perform the update. The timed data is also available through the TIMEDWHEELDATA log. The **TIMEDWHEELDATA** log can be used for applying wheel sensor updates in post-processing.

The SPAN filter uses sequential TIMEDWHEELDATA logs to compute a distance traveled between update intervals (1Hz). This information can be used to constrain free-inertial drift during times of poor GNSS visibility. The filter also contains a state for modeling the circumference of the wheel as it may change due to hardware changes or environmental conditions.

The modeled wheel circumference is available in the **WHEELSIZE** log. Information on how the wheel sensor updates are being used is available in the **INSUPDATESTATUS** log.

Refer to the [OEM7 Commands and Logs Reference Manual](#) for information about these logs.

iMAR Wheel Sensor Interface for iIMU-FSAS and IMU-CPT users

If you have the iMAR iMWS (Magnetic Wheel Speed Sensor and Converter), the wheel sensor information is sent to the OEM7 receiver along with the raw IMU data. You can integrate other wheel sensor hardware with the IMU-FSAS.

The accumulated wheel sensor counts are available by logging the timed wheel data log with the onnew trigger:

```
LOG TIMEDWHEELDATAB ONNEW
```

Set parameters for your installation using the **SETWHEELPARAMETERS** command.

Refer to the [OEM7 Commands and Logs Reference Manual](#) for information about this command.

Wheel Sensor Interface for IMU-IGM users

IMU-IGM accepts TTL level input pulses from a wheel sensor through the AUX connector. For information about the connections available on the AUX connector, see *IMU-IGM Ports* on page 143.



The SPAN-IGM Auxiliary Port interface cable (01019015) can be used to connect the wheel sensor inputs to the IMU-IGM. However, when this cable is used with an IMU-IGM, only the wheel sensor inputs are available. The other connectors on this cable do not have connections to the IMU or receiver.

Wheel Sensor Interface for IMU Enclosure Users

On SPAN systems with an IMU in an IMU Enclosure (IMU-ISA-100C, IMU-HG1900, IMU-ENC-LN200 or IMU- μ IMU-IC), use the **SETWHEELPARAMETERS** command to enable the collection of wheel sensor data.

```
SETWHEELPARAMETERS <ticks> <circ> 1.0
```

Refer to the [OEM7 Commands and Logs Reference Manual](#) for information about this command.

3.8 Azimuth Sources on a SPAN System

The SPAN system use three different methods to calculate the azimuth.

- Course Over Ground
- Inertial Azimuth
- ALIGN Azimuth

3.8.1 Course Over Ground

The course over ground azimuth is determined using the position delta between two position solutions computed by the OEM7 receiver. This is the simplest way to compute an azimuth and is done using either the GNSS solution or the INS solution. This method does not work when the vehicle is stationary as any position difference is due to position error and the computed azimuth is meaningless.

Course over ground azimuth is of greatest advantage in aerial or marine environments where the actual direction of travel may not match the forward axis of the aircraft/boat due to winds or currents. This effect is known as the crab angle. Course over ground azimuth is a great way to compute the offset if another means of computing the vehicle azimuth is available.

Course over ground azimuths are available in several different velocity logs. See *Table 21: Logs with Azimuth Data* below.

3.8.2 Inertial Azimuth

The inertial azimuth computed by the SPAN inertial navigation filter. It uses the sensors in the IMU to compute the azimuth of the IMU (this can be rotated to another reference if desired). For more information, see the **SETINSROTATION** command in the [OEM7 Commands and Logs Reference Manual](#).

This azimuth is the one provided in the majority of the INS logs available to a SPAN user. See *Table 21: Logs with Azimuth Data* below.

3.8.3 ALIGN Azimuth

On SPAN systems with dual antennas, an azimuth is available from the dual antenna baseline. This is the same azimuth that is used as an update to the SPAN solution. It is noisier than the inertial azimuth and is available at a much lower rate, but will have a stable mean. This azimuth is computed from the master antenna to the rover antenna based on how the antennas are oriented on the vehicle.

There is a specific subset of logs that output this azimuth. See *Table 21: Logs with Azimuth Data* below.

Table 21: Logs with Azimuth Data

| Log | Log Format | Azimuth Source |
|---------|------------|---|
| BESTVEL | NovAtel | Course Over Ground From the best system solution which could be either GNSS or INS |
| GPHDT | NMEA | ALIGN |

| Log | Log Format | Azimuth Source |
|-------------------------------|------------|---|
| GPVTG | NMEA | Course Over Ground From the best system solution which could be either GNSS or INS |
| HEADING2 | NovAtel | ALIGN |
| INSATT / INSATTS / INSATTX | NovAtel | Inertial |
| INSPVA / INSPVAS / INSPVAX | NovAtel | Inertial |
| INSSPD | NovAtel | Course Over Ground Computed using the INS solution only |
| PASHR | NMEA | Inertial |

3.9 Data Collection for Post Processing

Some operations, such as aerial measurement systems, do not require real-time information from SPAN. These operations are able to generate the position, velocity or attitude solution post-mission in order to generate a more robust and accurate solution than is possible in real-time.

In order to generate a solution in post-processing, data must be simultaneously collected at a base station and each rover. The following logs must be collected in order to successfully post process data.

From a base:

- RANGECMPB ONTIME 1
- RAWEPHEMB ONCHANGED
- GLOEPHEMERISB ONCHANGED (if using GLONASS)

From a rover:

- RANGECMPB ONTIME 1
- RAWEPHEMB ONCHANGED
- GLOEPHEMERISB ONCHANGED (if using GLONASS)
- RAWIMUSXB ONNEW
- INSCONFIGB ONCHANGED
- HEADING2B ONNEW (if using ALIGN dual antenna solution)

Post processing is performed through the Waypoint Inertial Explorer[®] software package available from the NovAtel Waypoint Products Group. Visit our Web site at www.novatel.com for details.



The highest rate that you should request GNSS logs (RANGE, BESTPOS, RTKPOS, PSRPOS, and so on) while in INS operation is 5 Hz. If the receiver is not running INS (no IMU is attached), GNSS logs can be requested at rates up to 20 Hz.

3.10 Firmware Updates and Model Upgrades

Firmware updates are firmware releases which include fixes and enhancements to the receiver functionality. Firmware updates are released on the web site as they become available.

Model upgrades enable features on the receiver and may be purchased through NovAtel authorized dealers.

Contact your local NovAtel dealer first for more information. To locate a dealer in your area visit Where to Buy | Dealer Network on the NovAtel web site at www.novatel.com/where-to-buy/-sales-offices/ or contact NovAtel Customer Support directly.

For information about how to install firmware updates or model upgrades, refer to the [OEM7 Installation and Operation User Manual](#).

3.11 Variable Lever Arm

The variable lever arm concept arose to support applications in which the IMU is no longer rigidly fixed to the vehicle, but rather on a gimballed mount. This creates an issue where the input lever arm offsets to the GNSS antenna are no longer correct, because the IMU can rotate on its mount, while the antenna remains fixed.

The use of the variable lever arm functionality requires that the device to which the IMU is attached be able to send its gimbal rotation angles back to SPAN. These angles are used to recalculate the lever arm at the rate that they are received. SPAN will also be able to output a gimballed solution at the rate the gimbal angles are received.

3.11.1 Reference Frame Description

There are several frames of reference involved when dealing with a gimballed mount. The frames are all very similar, but can be quite confusing due to small differences. Below are all frames applicable to the implementation of the variable lever arm:

| Frame | Description | Notation |
|-------------------|--|----------|
| IMU Body frame | The physical IMU axes | (b) |
| Vehicle frame | Default reference frame for attitude output in SPAN logs | (v) |
| Mount body frame | The physical axes of the gimballed mount | (m) |
| Gimbal body frame | The physical axes of the gimbal plane. This frame matches the mount body frame when gimbal angles are zero and rotates relative to the mount body frame when the gimbal is active. | (g) |
| User Output Frame | An arbitrary frame, used to define the desired reference for attitude output, typically matching a gimbal mounted sensor | (ou) |

| Frame | Description | Notation |
|-------------------|--|----------|
| Mark Output Frame | An arbitrary frame, used to define the desired reference for attitude output for the MARKxPVA logs, typically matching a gimbal mounted sensor | (om) |

Figure 29: Sample Configuration below and Figure 30: Operating Gimbal on the next page illustrate a basic scenario for the information in the table above. Figure 29: Sample Configuration below shows a possible configuration for the mount body frame, IMU body frame and a user output frame, with the gimbal in a locked position. The extra rotation commands required to configure Variable Lever Arm for this setup are:

```
SETINSROTATION RBM 180 0 0
```

```
SETINSROTATION USER 0 0 90
```

```
SETINSROTATION RBV 0 0 -90
```

Figure 30: Operating Gimbal on the next page shows the gimbal in operation; the gimbal platform has moved relative to the mount body frame. The gimbal frame and IMU Body frame move together, as does the user output (or mark output) frame.





Figure 30: Operating Gimbal



3.11.2 How to Use Variable Lever Arm

The variable lever arm functionality is simple to use in a SPAN system. It requires the input of gimbal angles from the camera mount or platform that the IMU is mounted on. After that is provided, the system will automatically compute the variable lever arm and produce several messages for output.

Ensuring a proper variable lever arm is important for SPAN performance.

Basic I/O

The variable lever arm functionality is based on the input of **INPUTGIMBALANGLE** command. This command specifies the right-handed rotation angles from the **mount body frame (m)** to the **gimbal body frame (g)**, with the order of rotations Z-X-Y. Entering this command will automatically cause the system to rotate the static lever arm into the latest gimballed frame. The update rate of the variable lever arm depends on the rate of the gimbal commands which can be entered at 1 to 50 Hz. If an **INPUTGIMBALANGLE** command is not received for over 1 second then the system will return to using the static lever arm.

In addition to using the variable lever arm internally, the following information is available to the user.

Table 22: Logs used with Variable Lever Arm

| Log | Description |
|--------------------------------|---|
| VARIABLELEVERARM | This log displays the calculated variable lever arm. The VARIABLELEVERARM log is output in IMU Body frame. |
| GIMBALLEDPVA | This log has the same format as the INSPVA log, but contains the attitude rotated back to the null gimbal position. When the gimbal mount is in its zero locked position, the GIMBALLEDPVA attitude will match the attitude given in the INSPVA log. If the translational offset to the gimbal center of rotation has been provided, the position and velocity output are offset to this position. Otherwise, the position and velocity values are given at the IMU center of navigation. |
| INSPVA, INSPVAS, INSPVAX | The INSPVA log is synchronous so does not depend on the entry of the INPUTGIMBALANGLE command. However when the gimbal angles are non-zero, the INSPVA log no longer represents the orientation of the gimbal mount / vehicle, but rather the current orientation of the unlocked gimbal platform. If the orientation of the vehicle is important, use the GIMBALLEDPVA log. |

Rotations and Translations

For the information provided by the system to be meaningful, the following offsets have to be set correctly. By default the system assumes that the IMU Body frame, gimbal mount and Mount Body frame are coincident. If this is not the case then additional commands are necessary to relate all of the different frames together using the commands below. If attitude output is desired relative to an external camera, this can also be configured using these commands.

Table 23: Commands used with Variable Lever Arm


| Command | Purpose |
|------------------------|---|
| SETINSROTATION RBV | This command provides the orientation of the IMU Body frame while the gimbal frame is in the locked null position. This is required information before the SPAN system can complete an inertial alignment. The SETINSROTATION RBV command relates the IMU Body frame (b) to the Vehicle frame (v). Once an RBV rotation has been provided, default attitude output will be referenced to the Vehicle frame. |
| SETINSROTATION RBM | This command relates the IMU Body frame (b) to the Mount Body frame (m). This information is required for interpreting the rotation angles from the VARIABLELEVERARM log correctly. |
| SETINSROTATION USER | By default, attitude information output by SPAN is for the vehicle frame. If attitude output is required to be referenced to another frame (typically the axes of a gimbal-mounted sensor), the USER offset can be used to rotate the attitude output in general SPAN logs to this frame. |

| Command | Purpose |
|------------------------------|---|
| SETINSROTATION MARKx | Similar to the user rotation, this rotation can be used to change the attitude output reference frame for the MARKxPVA logs. |
| SETINSTRANSALATION GIMBAL | This command provides the offset from the IMU center of navigation to the gimbal center of navigation. This is an optional translation used by Inertial Explorer for post-processing. |

3.12 Relative INS

NovAtel's Relative INS technology generates a position, velocity and full attitude vector between two SPAN systems. One is the Master receiver and the other is the Rover receiver. Once configured, the Master receiver begins transmitting corrections to the Rover receiver. Relative information is created and the system begins filling the **RELINSPVA** log and **SYNCRELINSPVA** log on the Rover receiver. The **RELINSPVA** log is then transmitted back to the Master receiver for output.

The data link required must be able to support [864bits+108bits x #obs tracked per second]. The **RELINSPVA** log is requested ONNEW (available from 1Hz-20Hz depending on the setup of the **RELINSAUTOMATION** command) while the **SYNCRELINSPVA** log can be requested ONTIME at up to 200Hz (at the rover only). Position and velocity solutions are differenced in the ECEF frame and then rotated into the local level. The Relative offset vector that is output is dependent on Master/Rover's precise RTK vector and their eccentric offset vectors (optional offset provided using the **USER** parameter in the **SETINSTRANSALATION** command), shown in *Figure 31: Relative INS Example* on the next page.

Figure 31: Relative INS Example

An important command that can be used with Relative INS to manually change the maximum amount of time to use RTK data is the **RTKTIMEOUT** command. This command is used to set the maximum age of RTK data to use when operating as a rover station. RTK data received that is older than the specified time is ignored. The default is 60 seconds, however when using Relative INS, it is suggested this be set to 5 seconds by sending the command **RTKTIMEOUT 5**.



For information about the **RTKTIMEOUT** command, refer to the [OEM7 Commands and Logs Reference Manual](#).

3.12.1 Configure Relative INS

To configure the receivers to begin computing the relative information:

1. Setup a link between the receivers that will be used to transfer data (for example, radios).
2. Enable the transfer of relative corrections between receivers using one of the methods below.
 - Send the **RELINSAUTOMATION** command only at the Rover receiver
 - Send the **RELINSCONFIG** command at both the Master and Rover receiver



To configure Relative INS using the **RELINSAUTOMATION** command, the mater and rover receivers must be communicating using a COM port. If the master and rover are communicating via an ICOM port, the **RELINSCONFIG** command must be used.



The Model option must be present on both the rover and master for the Relative INS feature to be enabled.

Chapter 4 SPAN with Dual Antenna

NovAtel's ALIGN® heading technology generates distance and bearing information between a "master" and one or more "rover" receivers.

SPAN with Dual Antenna provides the hardware necessary to run an ALIGN baseline with an IMU and a second receiver.

With SPAN, the ALIGN GNSS baseline can be used to assist the initial alignment of the SPAN solution. In addition, the ALIGN baseline solution will aid the heading solution from the receiver if the heading drifts due to slow or constant dynamics.

ALIGN is capable of a 10 Hz heading output rate when integrated with the OEM7 receiver.



For optimal SPAN performance when using Dual Antenna with SPAN an ALIGN offset calibration is required for each unique installation. This calibration refines the IMU to antenna baseline angular offset from the initial estimate derived from the input lever arms. Refer to **INSCALIBRATE** command for details.

4.1 Installation

The hardware for SPAN with Dual Antenna is installed in a manner similar to other SPAN systems. Some points to consider during your installation are:

1. Install the IMU and the two antennas in the vehicle such that the relative distance between them is fixed.
2. The antennas should be mounted where the view of the satellites will not be obstructed by any part of the vehicle. As heading accuracy is dependent on baseline length, mount the antennas as far apart as possible. A minimum separation distance of 1 metre is recommended.
3. The lever arms or distance from the IMU to the antennas needs to be fixed and accurately measured using the coordinate axes defined on the outside of the IMU. The baseline between the two antennas does NOT need to be aligned with the vehicle axes or with the axes of the IMU.
4. Both receivers need to be powered and connected to each other via COM 2 before sending any configuration commands. It does not matter which receiver is powered on first, or how long they are both powered before sending any commands.



SPAN with Dual Antenna operation assumes the dedicated use of the COM 2 port for communication between receivers. If this port is required for another function on the SPAN-enabled master, the port can be changed using the **DUALANTENNAPORTCONFIG** command. However, the rover must always use COM2.



For information about connecting the ALIGN master and rover receivers using a port that is not a serial COM port (e.g. Ethernet), contact NovAtel Customer Support.

The two receivers need to be set up as shown in the example in *Figure 32: SPAN - Two Receiver Dual Antenna Installation* below.

Dual antenna receivers, such as the OEM7720, contain the hardware necessary to provide an ALIGN solution without an additional receiver. Set up a SPAN system with a dual antenna receiver as shown in *Figure 33: SPAN - Single Receiver Dual Antenna Installation* on the next page.

Figure 32: SPAN - Two Receiver Dual Antenna Installation





Figure 33: SPAN - Single Receiver Dual Antenna Installation

4.2 Configuring ALIGN with SPAN

Before configuring the ALIGN solution, the two receivers should both be powered on and connected directly between COM 2 of the SPAN receiver and COM 2 of the second receiver through either a null modem cable or an appropriate radio connection. For dual antenna receivers, such as the OEM7720, the receiver must be powered on.



The rover receiver must be an ALIGN-capable model.

To enable the dual-antenna ALIGN solution to aid the INS alignment and provide heading updates, the offset between the antennas and the IMU must be known. This is achieved by entering lever arms to both antennas, using the **SETINSTRANSLATION** command.

To configure SPAN with ALIGN Aiding:

1. Enter the lever arm from the IMU to the primary antenna (primary antenna is connected to the SPAN receiver).

Abbreviated ASCII example:

```
SETINSTRANSFORMATION ANT1 0.54 0.32 1.20 0.03 0.03 0.05
```

2. Enter the lever arm from the IMU to the secondary antenna (secondary antenna is connected to the second receiver or the secondary input on dual antenna receivers).

Abbreviated ASCII example:

```
SETINSTRANSFORMATION ANT2 0.54 2.32 1.20 0.03 0.03 0.05
```

Alternately, the angular offset between the dual-antenna baseline (from primary GNSS antenna to secondary GNSS antenna) and the IMU frame forward axis is entered directly via the **ALIGN** parameter of the **SETINSROTATION** command.



We recommend entering the lever arms rather than entering the angular offset as this is easier to measure and will lead to better overall accuracy.

Refer to the [OEM7 Commands and Logs Reference Manual](#) for the syntax of the above commands.

As with all ALIGN-capable products, the GNSS baseline solution is available from the **GPHDT** log and **HEADING2** log. For INS heading, use the **INSATT** log or **INSPVA** log.

The SPAN system can be configured for different alignment routines depending on the motion conditions experienced during the alignment period. For example, in marine applications, the dynamics required for either a coarse or kinematic alignment cannot be guaranteed, so a different alignment routine is required.

The different alignment routines are described in *Configuring SPAN with ALIGN* below.

4.3 Configuring SPAN with ALIGN

The SPAN receiver can be configured for different alignment routines depending on the motion conditions experienced during the alignment period. For example, in marine applications, the dynamics required for either a coarse or kinematic alignment cannot be guaranteed, so a different alignment routine will be required.



Before the ALIGN heading can be computed and used by SPAN, both GNSS antennae must have a clear view of the sky.



For optimal SPAN performance when using Dual Antenna with SPAN an ALIGN offset calibration is required for each unique installation. This calibration refines the IMU to antenna baseline angular offset from the initial estimate derived from the input lever arms. Refer to **INSCALIBRATE** command for details.

The different alignment routines are described in the following sections:

4.3.1 Alignment on a Moving Vessel - Aided Transfer Alignment

This alignment routine is the preferred dual antenna alignment method. It is used if the alignment mode is set to AIDED_TRANSFER using the **ALIGNMENTMODE** command, and can be used if the alignment mode is set to AUTOMATIC.

If your vehicle is not stationary during the alignment, such as may be the case on a ship, use the Aided Transfer Alignment routine. This alignment method uses the ALIGN baseline solution to perform an instantaneous alignment of the vehicle attitude.

The alignment happens instantaneously after the receiver establishes communication with the IMU and computes a verified, fixed integer, ALIGN solution. The INS status changes to INS_ALIGNMENT_COMPLETE or INS_SOLUTION_GOOD, depending on the variances of the ALIGN solution, and the measured lever arm/external heading offset.

To guarantee the use of this alignment mode, the **ALIGNMENTMODE** command must be sent to the receiver:

```
ALIGNMENTMODE AIDED_TRANSFER
```

4.3.2 Alignment on a Stationary Vehicle - Aided Static Alignment

An alternative to the aided transfer alignment, the ALIGN heading can be used as a seed for a coarse static alignment. In this mode, the standard coarse alignment routine runs given the initial azimuth value. As with the transfer alignment, the first verified fixed RTK solution is used to provide the alignment seed after which the coarse alignment (INS_ALIGNING) begins. After the coarse alignment is complete, the INS status changes to INS_ALIGNMENT_COMPLETE. After the attitude accuracy has converged, the INS status changes to INS_SOLUTION_GOOD. This alignment mode is useful if the initial vehicle roll is more than 20 degrees.

To use this alignment mode, the **ALIGNMENTMODE** command must be sent to the receiver.

```
ALIGNMENTMODE AIDED_STATIC
```

4.3.3 Unaided Alignment

The unaided alignment sets the SPAN system to use only single antenna alignment options (static, kinematic or manual alignment).

To use this alignment mode, the **ALIGNMENTMODE** command must be sent to the receiver.

```
ALIGNMENTMODE UNAIDED
```

4.3.4 Automatic Alignment Mode - Automatic Alignment (default)

Automatic Alignment Mode Selection is the default setting for a SPAN receiver. This mode is designed to allow alignment of the system as quickly as possible, using either an aided transfer alignment (*Alignment on a Moving Vessel - Aided Transfer Alignment* above); a kinematic alignment (*Kinematic Alignment* on page 85); or a manual alignment (*Manual Alignment* on page 86).

The first available technique will be used, regardless of its relative quality. If you wish to guarantee a specific technique is used, or use an aided static alignment, you must select the desired alignment mode manually. No additional configuration is required to use this alignment routine.

4.4 SPAN ALIGN Attitude Updates

The INS heading updates are used to help constrain the azimuth drift of the INS solution whenever possible. This is of the greatest value with lower-quality IMUs and in environments

with low dynamics where the attitude error is less observable. Slow moving marine or train applications are good examples of the intended use. By providing an external heading source, the solution drift can be constrained in these environments.

You can monitor the heading update status as outlined in the **INSUPDATESTATUS** log in the [OEM7 Commands and Logs Reference Manual](#).

APPENDIX A IMU Technical Specifications

The following appendices detail the technical specifications of the SPAN compatible IMUs.

- *HG1700 IMU (single-connector enclosure)* on the next page
- *IMU-CPT* on page 120
- *IMU-FSAS* on page 127
- *IMU-HG1900* on page 135
- *IMU-IGM* on page 140
- *IMU-ISA-100C* on page 149
- *IMU-KVH1750* on page 162
- *IMU-ENC-LN200* on page 171
- *IMU- μ IMU-IC* on page 176
- *LN-200 IMU (single-connector enclosure)* on page 181
- *OEM-IMU-ADIS-16488* on page 186
- *OEM-IMU-EG320N* on page 194
- *OEM-IMU-ISA-100C* on page 199
- *OEM-IMU-STIM300* on page 206
- *OEM-IMU- μ IMU* on page 213
- *Universal IMU Enclosure (HG1700, LN200)* on page 220
- *MIC - MEMS Interface Card* on page 230
- *UIC - Universal IMU Controller* on page 243

For technical specifications for the SPAN compatible receivers and the PwrPak7-E1, see the [OEM7 Installation and Operation User Manual](#).

A.1 HG1700 IMU (single-connector enclosure)

Table 24: HG1700 IMU Physical Specifications

| Physical | |
|------------------------|--|
| IMU Enclosure Size | 193 mm x 167 mm x 100 mm (7.6" x 6.6" x 3.9") |
| IMU Size | 160 mm x 160 mm x 100 mm (6.3" x 6.3" x 3.9") |
| IMU + Enclosure Weight | 3.4 kg (7.49 lb.) |

See the following sections for more information about the HG1700 IMU.

- *HG1700 IMU Mechanical Drawings* on the next page
- *HG1700 IMU Performance* on page 118
- *HG1700 Electrical and Environmental* on page 119
- *Interface Cable for the HG1700 IMU* on page 119

A.1.1 HG1700 IMU Mechanical Drawings



The dimensions in the following diagrams are in millimetres.

Figure 34: HG1700 Top/Bottom Dimensions





Figure 35: HG1700 Enclosure Side Dimensions



The center of Navigation, shown on the HG1700 label, for the internal IMU is the same as the enclosure center. The enclosure center measurements are labeled as IMU Enclosure Center in these figures.

A.1.2 HG1700 IMU Performance**Table 25: HG1700-AG58 IMU Performance**

| Gyroscope Performance | |
|----------------------------------|---------------------|
| Gyro Input Range | ±1000 degrees/s |
| Gyro Rate Bias | 1.0 degree/hr |
| Gyro Rate Scale Factor | 150 ppm |
| Angular Random Walk | 0.125 degrees/rt hr |
| Accelerometer Performance | |
| Accelerometer Range | ±50 g |
| Accelerometer Linearity | 500 ppm |
| Accelerometer Scale Factor | 300 ppm |
| Accelerometer Bias | 1.0 mg |
| Data Rate | |
| IMU Measurement | 100 Hz |

Table 26: HG1700-AG62 IMU Performance

| Gyroscope Performance | |
|----------------------------------|-------------------|
| Gyro Input Range | ±1000 degrees/s |
| Gyro Rate Bias | 5.0 degrees/hr |
| Gyro Rate Scale Factor | 150 ppm |
| Angular Random Walk | 0.5 degrees/rt-hr |
| Accelerometer Performance | |
| Accelerometer Range | ±50 g |
| Accelerometer Linearity | 500 ppm |
| Accelerometer Scale Factor | 300 ppm |
| Accelerometer Bias | 2.0 mg |
| Data Rate | |
| IMU Measurement | 100 Hz |

A.1.3 HG1700 Electrical and Environmental

Table 27: HG17000 Electrical Specifications

| Electrical | |
|----------------------------|--|
| IMU Power Consumption | IMU-H58: 9 W (max) IMU-H62: 8 W (max) |
| IMU Input Voltage | +12 to +28 VDC |
| Receiver Power Consumption | 1.8 W (typical) |
| System Power Consumption | 13.8 W (typical) |
| Input/Output Connectors | MIL-C-38999-III, 22 pin (all IMUs) |
| IMU Interface | RS-232 or RS-422 |

Table 28: HG17000 Environmental Specifications

| Environmental (IMU) | |
|-----------------------|---------------------------------|
| Operating Temperature | -30°C to +60°C (-22°F to 140°F) |
| Storage Temperature | -45°C to +80°C (-49°F to 176°F) |
| Humidity | 95% non-condensing |

A.1.4 Interface Cable for the HG1700 IMU

The IMU interface cable provides power to the IMU from an external power source and enables communication between the receiver and IMU. The HG1700 IMU uses the Universal IMU Enclosure Interface cable (see *Universal IMU Enclosure Interface Cable* on page 228).

A.2 IMU-CPT

Table 29: IMU-CPT Physical Specifications

| Physical | |
|------------|-------------------------------|
| IMU Size | 168 mm W X 152 mm L X 89 mm H |
| IMU Weight | 2.29 kg |

See the following sections for more information about the IMU-CPT.

- *IMU-CPT Mechanical Drawings* on the next page
- *IMU-CPT Sensor Specifications* on page 123
- *IMU-CPT Electrical and Environmental* on page 124
- *IMU-CPT Cable* on page 125

A.2.1 IMU-CPT Mechanical Drawings



The dimensions in the following diagrams are in inches and millimetres (in square brackets).

Figure 36: IMU-CPT Side and Perspective View





Figure 37: IMU-CPT Top, Front and Bottom View



A.2.2 IMU-CPT Sensor Specifications**Table 30: IMU-CPT Performance**

| Gyroscope Performance | |
|---|---|
| Bias Offset | ± 20 °/hr |
| Turn On To Turn On Bias Repeatability (Compensated) | ± 3 °/hr |
| In Run Bias Variation, At Constant Temperature | 1 °/hr @ 1σ |
| Scale Factor Error (Total) | 1500 ppm, 1σ |
| Scale Factor Linearity | 1000 ppm, 1σ |
| Temperature Dependent SF Variation | 500 ppm, 1σ |
| Angular Random Walk | 0.0667 °/ $\sqrt{\text{hr}}$ @ 1σ |
| Maximum Input | ± 375 °/sec |
| Accelerometer Performance | |
| Bias Offset | ± 50 mg |
| Turn On To Turn On Bias Repeatability | ± 0.75 mg |
| In Run Bias Variation, At Constant Temperature | 0.25 mg @ 1σ |
| Temperature Dependent Bias Variation | 0.5 mg/°C @ 1σ |
| Scale Factor Error (Total) | 4000 ppm, 1σ |
| Temperature Dependent SF Variation | 1000 ppm, 1σ |
| Accelerometer Noise | 55 $\mu\text{g}/\sqrt{\text{Hz}}$ @ 1σ |
| Bandwidth | 50 Hz |
| Accelerometer Bias | ± 10 g |
| Data Rate | |
| IMU Measurement | 100 Hz |

A.2.3 IMU-CPT Electrical and Environmental**Table 31: IMU-CPT Electrical Specifications**

| Electrical | |
|----------------------------|------------------------|
| Input Power | 9 - 18 VDC |
| Power Consumption | 13 W (max) |
| Power and I/O Connector | MIL-DTL-38999 Series 3 |
| Start-Up Time (Valid Data) | < 5 seconds |

Table 32: IMU-CPT Environmental Specifications

| Environmental | |
|------------------------------|--------------------------|
| Temperature, operational | -40°C to +65°C |
| Temperature, non-operational | -50°C to +80°C |
| Vibration, operational | 6 g rms, 20 Hz -2 KHz |
| Vibration, non-operational | 8 g rms, 20 Hz -2 KHz |
| Shock, operational | 7g 6-10 msec, 1/2 sine |
| Shock, non-operational | 60 g 6-10 msec, 1/2 sine |
| Altitude | -1000 to 50,000 ft. |
| Humidity | 95% at 35°C, 48 hrs |
| MTBF | ≥ 10,500 hours |

A.2.4 IMU-CPT Cable

The NovAtel part number for the IMU-CPT cable is 01018966. This cable provides power to the IMU from an external power source and enables communication between the receiver and the IMU.

Figure 38: IMU-CPT Development Terminated Cable




Table 33: IMU-CPT Connector Pinout Descriptions

| J1 Pin # | Function | J2 (Female DB9) Pin # | Bare Connectors |
|----------|-------------------------|-----------------------|-----------------|
| 1 | Power Return | | Labeled Pin 1 |
| 2 | 9-16 VDC Power Input | | Labeled Pin 2 |
| 3-20 | Reserved | | |
| 21 | IMU RS422 TX+ | 2 | |
| 22 | IMU RS422 TX- | 8 | |
| 23-24 | Reserved | | |
| 25 | IMU RS422 Signal Ground | 5 | |
| 26-34 | Reserved | | |
| 35 | TOV Out | 9 | |
| 36 | External Clock Input | 1 | |
| 37 | Chassis GND | | Labeled Pin 37 |
| | Chassis GND | | Ring lug |

Custom Cable Recommendations

The tables below provide recommendations for creating custom cables to replace the IMU-CPT cable (01018966).

Table 34: Connectors

| Connector | Description |
|------------------|-----------------------------------|
| J1 | MIL-DTL 38999, 37 connector, plug |
| J2 | DB-9, female |

Table 35: Maximum Cable Length

| IMU | RS-422 |
|------------|---------------|
| IMU-CPT | < 1.5 metres |

A.3 IMU-FSAS

Table 36: IMU-FSAS Physical Specifications

| Physical | |
|------------|---|
| IMU Size | 128 mm x 128 mm x 104 mm (5.04" x 5.04" x 4.09") |
| IMU Weight | 2.1 kg (4.63 lb.) |

See the following sections for more information about the IMU-FSAS.

- *IMU-FSAS Mechanical Drawings* on the next page
- *IMU-FSAS Performance* on page 131
- *IMU-FSAS Electrical and Environmental* on page 131
- *Interface Cable for IMU-FSAS* on page 132
- *IMU-FSAS Cable with Wheel Sensor* on page 132

A.3.1 IMU-FSAS Mechanical Drawings



The dimensions in the following diagrams are in millimetres.

Figure 39: IMU-FSAS Top Dimensions




Figure 40: IMU-FSAS Bottom Dimensions




Figure 41: IMU-FSAS Side Dimensions





Figure 42: IMU-FSAS Center of Navigation



A.3.2 IMU-FSAS Performance

Table 37: IMU-FSAS Performance

| Gyroscope Performance | |
|----------------------------------|-----------------------|
| Gyro Input Range | ±450 °/s |
| Gyro Rate Bias | <0.75°/hr |
| Gyro Rate Scale Factor | 300 ppm |
| Angular Random Walk | 0.1 °/sq rt hr |
| Accelerometer Performance | |
| Accelerometer Range | ±5 g (±20 g optional) |
| Accelerometer Scale Factor | 300 ppm |
| Accelerometer Bias | 1.0 mg |
| Data Rate | |
| IMU Measurement | 200 Hz |

A.3.3 IMU-FSAS Electrical and Environmental

Table 38: IMU-FSAS Electrical Specifications

| Electrical | |
|----------------------------|------------------|
| IMU Power Consumption | 16 W (max) |
| IMU Input Voltage | +10 to +34 VDC |
| Receiver Power Consumption | 1.8 W (typical) |
| System Power Consumption | 13.8 W (typical) |
| Input/Output Connectors | MIL-C-38999-III |
| IMU Interface | RS-422 |

Table 39: IMU-FSAS Environmental Specifications

| Environmental | |
|-----------------------|---------------------------------|
| Operating Temperature | -40°C to +71°C (-40°F to 160°F) |
| Storage Temperature | -40°C to +85°C (-40°F to 185°F) |
| Humidity | 95% non-condensing |

A.3.4 Interface Cable for IMU-FSAS

The IMU interface cable can be one of the following cables:

| Cable | NovAtel Part Number | Comment | For more information |
|---|---------------------|---|--|
| Universal IMU Enclosure Interface cable | 01018977 | For standard pinout enclosures. | See <i>Universal IMU Enclosure Interface Cable</i> on page 228 |
| IMU-FSAS cable with Wheel Sensor | 01018388 | For standard pinout enclosures. Includes an additional connector for wheel sensor cabling. | See <i>IMU-FSAS Cable with Wheel Sensor</i> below |

A.3.5 IMU-FSAS Cable with Wheel Sensor

The NovAtel part number for the IMU-FSAS cable with Wheel Sensor is 01018388 (see *Figure 43: IMU-FSAS Interface Cable with Wheel Sensor* below). This cable:

- provides power to the IMU from an external power source
- enables input and output between the receiver and the IMU
- enables input from an optional Wheel Sensor

See also *Wheel Sensor Installation* on page 66.

Figure 43: IMU-FSAS Interface Cable with Wheel Sensor




Table 40: IMU-FSAS Cable with Wheel Sensor Pinout

| MIL-C-38999 III Connector Pin | Function | Power 4 mm plugs | J1 Female DB9 | P4 Male DB9 | Comments |
|-------------------------------|-----------------|--------------------------------|---------------|-------------|--|
| 1 | Vin(-) | Color: black Label: Vin (-) | | | Power ground |
| 22 | Vin(-) | | | | |
| 2 | ODO_AN | | | 7 | Wheel sensor input A(-), opto-coupler: +2 to +6 V (RS-422 compatible) |
| 4 | ODO_A | | | 6 | Wheel sensor input A(+), opto-coupler: +2 to +6 V (RS-422 compatible) |
| 3 | Vin(+) | Color: red Label: Vin (+) | | | +10 to +34 VDC |
| 21 | Vin(+) | | | | |
| 5 | Not used | | | | |
| 6 | Not used | | | | |
| 7 | DAS(+) | | 1 | | Shielded data acquisition signal (LVCMOS to VARF) |
| 9 | DAS GN (-) | | 5 | | Shielded ground reference for data acquisition and control signals |
| 8 | Reserved | | | | |
| 10 | Reserved | | | | |
| 11 | OEM_CTS/ Rx- | | 8 | | Twisted pair; serial data output signal / RS-422(-) |
| 12 | OEM_Rx/ Rx+ | | 2 | | Twisted pair; serial data output signal / RS-422(+) |
| 13 | Reserved | | | | |
| 14 | DGND | | 5 | | Digital ground |
| 15 | DGND | | 5 | | Digital ground |
| 16 | ODO_B | | | 3 | Wheel sensor input B(+), opto-coupler: +2 to +6 V (RS-422 compatible) |

| MIL-C-38999 III Connector Pin | Function | Power 4 mm plugs | J1 Female DB9 | P4 Male DB9 | Comments |
|-------------------------------|----------------|------------------|---------------|-------------|---|
| 17 | ODO_BN | | | 1 | Wheel sensor input B(-), opto-coupler: +2 to +6 V (RS-422 compatible) |
| 18 | Reserved | | | | |
| 19 | OEM_Tx/ Tx+ | | 3 | | Twisted pair; serial data in / RS-422(+) |
| 20 | OEM_RTS/ Tx | | 7 | | Twisted pair; serial data in / RS-422(-) |

Custom Cable Recommendations

The tables below provide recommendations for creating custom cables to replace the IMU-FSAS cable with Wheel Sensor (01018388).

Table 41: Connectors

| Connector | Description |
|-----------|-------------------------|
| J1 | DB-9, female |
| J2 | MIL-DTL-38999 III, plug |
| P4 | DB-9, male |

Table 42: Maximum Cable Length

| IMU | RS-422 |
|-----------|--------------|
| iIMU-FSAS | < 1.5 metres |

A.4 IMU-HG1900

The IMU-HG1900 contains a Honeywell HG1900 IMU.

Table 43: IMU-HG1900 Physical Specifications

| Physical | |
|----------------------|--------------------------|
| IMU Enclosure Size | 130 mm x 130 mm x 125 mm |
| IMU Enclosure Weight | 2.34 kg |

See the following sections for more information about the IMU-HG1900.

- *IMU-HG1900 Mechanical Drawings* on the next page
- *IMU-HG1900 Sensor Specifications* on page 138
- *IMU-HG1900 Electrical and Environmental* on page 139
- *IMU-HG1900 Cables* on page 139

A.4.1 IMU-HG1900 Mechanical Drawings



The dimensions in the following diagrams are in millimetres.

Figure 44: IMU-HG1900 Dimensions





Figure 45: IMU-HG1900 Center of Navigation



A.4.2 IMU-HG1900 Sensor Specifications

Table 44: IMU-HG1900 IMU Performance

| Gyroscope Performance | |
|----------------------------------|---------------|
| Input range | ±1000 deg/sec |
| Rate bias | 5 deg/hr |
| In-run bias stability | 1 deg/hr |
| Rate Scale factor | 150 ppm |
| Angular random walk | 0.09 deg/√hr |
| Accelerometer Performance | |
| Range | ±30 g |
| Linearity | 500 ppm |
| Scale factor | 300 ppm |
| Bias repeatability | 1 mg |
| Bias in-run stability | 0.7 mg |
| Data Rate | |
| IMU Measurement | 100 Hz |

A.4.3 IMU-HG1900 Electrical and Environmental

Table 45: IMU-HG1900 Electrical Specifications

| Electrical | |
|-----------------------|------------------------|
| IMU Power Consumption | 7.5 W (typical) |
| IMU Input Voltage | +10 to +34 VDC |
| IMU Interface | RS-422 |
| Connectors | |
| Power | SAL M12, 5 pin, male |
| Data | SAL M12, 5 pin, female |
| Wheel Sensor | SAL M12, 8 pin, male |

Table 46: IMU-HG1900 Environmental Specifications

| Environmental | |
|-----------------------|------------------------------------|
| Operating Temperature | -40°C to +55°C |
| Storage Temperature | -40°C to +80°C |
| Humidity | MIL-STD-810G, Method 507.5 |
| Random Vibe | MIL-STD-810G. Method 514.6 (2.0 g) |
| Environment | IEC 60529 IP67 |

A.4.4 IMU-HG1900 Cables

IMU-HG1900 Interface Cable

The IMU-HG1900 uses the IMU Enclosure Interface Cable. Refer to *IMU Enclosure Interface Cable* on page 156 for details about this cable.

IMU-HG1900 Power Cable

The IMU-HG1900 uses the IMU Enclosure Power Cable. Refer to *IMU Enclosure Power Cable* on page 158 for details about this cable.

IMU-HG1900 Wheel Sensor Cable

The IMU-HG1900 uses the IMU Enclosure Wheel Sensor Cable. Refer to *IMU Enclosure Wheel Sensor Cable* on page 160 for details about this cable.

A.5 IMU-IGM

This section contains the specifications for both the IMU-IGM-A1 and IMU-IGM-S1.

Table 47: IMU-IGM-A1 Physical Specifications

| Physical | |
|----------------|-------------------------------|
| Enclosure Size | 152.0 mm x 137.0 mm x 50.5 mm |
| Weight | 475 g |
| Connectors | |
| MAIN | DB-15HD Female |
| AUX | DB-15HD Male |

Table 48: IMU-IGM-S1 Physical Specifications


| Physical | |
|----------------|-------------------------------|
| Enclosure Size | 152.0 mm x 137.0 mm x 50.5 mm |
| Weight | 500 g |
| Connectors | |
| MAIN | DB-15HD Female |
| AUX | DB-15HD Male |

See the following sections for more information about the IMU-IGM-A1 or IMU-IGM-S1 IMUs.

- *IMU-IGM Mechanical Drawings* on the next page
- *IMU-IGM Ports* on page 143
- *IMU-IGM Sensor Specifications* on page 145
- *IMU-IGM Electrical and Environmental* on page 146
- *IMU-IGM Interface Cable* on page 147


A.5.1 IMU-IGM Mechanical Drawings

Figure 46: IMU-IGM-A1 Dimensions



The center of navigation is at the location marked by the axis labels on the enclosure and indicated on the drawing above. It is not at the depression in the enclosure cover. The dimensions in the drawing are in millimetres.

Figure 47: IMU-IGM-S1 Dimensions



The center of navigation is at the location marked by the axis labels on the enclosure and indicated on the drawing above. It is not at the depression in the enclosure cover. The dimensions in the drawing are in millimetres.

A.5.2 IMU-IGM Ports**Table 49: IMU-IGM Main Port Pinout**

| Pin # | Label | Description |
|-------|----------------|--|
| 1 | MIC_TX/MIC_TX+ | MODE2 high or open: MIC port transmit (RS-232) MODE2 low: MIC port transmit positive (RS-422) |
| 2 | MIC_TX- | MODE2 high or open: No connection MODE2 low: MIC port transmit negative (RS-422) |
| 3 | DGND | Digital ground |
| 4 | V+ | IMU-IGM power supply input, positive |
| 5 | V- | IMU-IGM power supply input, negative |
| 6 | MIC_RX/MIC_RX+ | MODE2 high or open: MIC port receiver (RS-232) MODE2 low: MIC port receive positive (RS-422) |
| 7 | MIC_RX- | MODE2 high or open: No connection MODE2 low: MIC port receive negative (RS-422) |
| 8 | DGND | Digital ground |
| 9 | Reserved | Reserved |
| 10 | Reserved | Reserved |
| 11 | DGND | Digital ground |
| 12 | Reserved | Reserved |
| 13 | MODE2 | Mode 2 input, controls MIC port standard |
| 14 | Reserved | Reserved |
| 15 | Reserved | Reserved |

Table 50: IMU-IGM AUX Port Pinout

| Pin # | Label | Description |
|-------|----------|--|
| 1 | ODM_A+ | Wheel sensor input A positive |
| 2 | ODM_B+ | Wheel sensor input B positive (No connection on IMU-IGM-S1) |
| 3 | Reserved | Reserved |
| 4 | WS_VOUT | Wheel sensor output voltage (12 VDC) |

| Pin # | Label | Description |
|--------------|--------------|--|
| 5 | DGND | Digital ground |
| 6 | ODM_A- | Wheel sensor input A negative |
| 7 | ODM_B- | Wheel sensor input B negative (No connection on IMU-IGM-S1) |
| 8 | Reserved | Reserved |
| 9 | DGND | Digital ground |
| 10 | Reserved | Reserved |
| 11 | Reserved | Reserved |
| 12 | Reserved | Reserved |
| 13 | Reserved | Reserved |
| 14 | Reserved | Reserved |
| 15 | DGND | Digital ground |

A.5.3 IMU-IGM Sensor Specifications

Table 51: IMU-IGM-A1 IMU Performance

| Gyroscope Performance | |
|-------------------------------------|-------------------------------|
| Gyro Input Range | ± 450 °/second |
| In Run Gyro Rate Bias Stability | 6.25 °/hour |
| Angular Random Walk | 0.3 °/ $\sqrt{\text{hour}}$ |
| Accelerometer Performance | |
| Accelerometer Range | ± 18 g |
| In Run Accelerometer Bias Stability | 0.1 mg |
| Velocity Random Walk | 0.029 m/s/ $\sqrt{\text{hr}}$ |
| Data Rate | |
| IMU Measurement | 200 Hz |

Table 52: IMU-IGM-S1 IMU Performance

| Gyroscope Performance | |
|-------------------------------------|------------------------------|
| Gyro Input Range | ± 400 °/second |
| In Run Gyro Rate Bias Stability | 0.5 °/hour |
| Angular Random Walk | 0.15 °/ $\sqrt{\text{hour}}$ |
| Accelerometer Performance | |
| Accelerometer Range | ± 10 g |
| In Run Accelerometer Bias Stability | 0.05 mg |
| Velocity Random Walk | 0.07 m/s/ $\sqrt{\text{hr}}$ |
| Data Rate | |
| IMU Measurement | 125 Hz |

A.5.4 IMU-IGM Electrical and Environmental**Table 53: IMU-IGM-A1 Electrical Specifications**

| Electrical | |
|-------------------|-----------------|
| Input Voltage | 10 - 30 VDC |
| Power consumption | 2.5 W (typical) |

Table 54: IMU-IGM-A1 Environmental Specifications

| Environmental | |
|--------------------------|--------------------|
| Temperature, operational | -40°C to +65°C |
| Temperature, storage | -50°C to +80°C |
| Humidity | 95% Non-condensing |

Table 55: IMU-IGM-S1 Electrical Specifications

| Electrical | |
|-------------------|------------------|
| Input Voltage | 10 - 30 VDC |
| Power consumption | <4.6 W (typical) |


Table 56: IMU-IGM-S1 Environmental Specifications

| Environmental | |
|--------------------------|--------------------|
| Temperature, operational | -40°C to +65°C |
| Temperature, storage | -50°C to +80°C |
| Humidity | 95% Non-condensing |

A.5.5 IMU-IGM Interface Cable

The NovAtel part number for the IMU-IGM interface cable is 01019016. This cable provides power to the IMU-IGM and communication signals between the IMU-IGM and the OEM7 family receiver.

Figure 48: IMU-IGM Interface Cable



The dimensions in this drawing are in millimetres.

Table 57: IMU-IGM Interface Cable Pinout Descriptions

| J1 MAIN Pin # | Function | J2 Wire Bundle Label | J3 MIC Port Pin # |
|---------------------|--------------------------------------|----------------------------|-------------------------|
| 1 | MIC Port Transmit/Transmit+ (RS-422) | | 2 |
| 2 | MIC Port Transmit- (RS-422) | | 8 |
| 3 | Digital Ground | | |
| 4 | Battery + | BATT+ | |
| 5 | Digital Ground | BATT- | |
| 6 | MIC Port Receive/Receive+ (RS-422) | | 3 |
| 7 | MIC Port Receive- (RS-422) | | 7 |
| 8 | Digital Ground | | 5 |
| 9 | Reserved | | |

| J1 MAIN Pin # | Function | J2 Wire Bundle Label | J3 MIC Port Pin # |
|---------------------|----------------|----------------------------|-------------------------|
| 10 | Reserved | | |
| 11 | Digital Ground | | |
| 12 | Reserved | | |
| 13 | MODE 2 | MODE 2 | |
| 14 | Reserved | | |
| 15 | Reserved | | |



The MIC port can operate as either an RS-232 or RS-422 serial port.

- When the MODE 2 pin is left open or tied high, the MIC port operates as an RS-232 serial port.
- When the MODE 2 pin is tied low, the MIC port operates as an RS-422 serial port.

Custom Cable Recommendations

The tables below provide recommendations for creating custom cables to replace the IMU-IGM interface cable (01019016).

Table 58: Connectors

| Connector | Description |
|-----------|---------------|
| J1 | DB-15HD, male |
| J2 | DB-9, female |

Table 59: Maximum Cable Length

| IMU | RS-232 | RS-422 |
|------------------------|--------------|-------------|
| IMU-IGM-A1, IMU-IGM-S1 | < 1.2 metres | < 50 metres |

A.6 IMU-ISA-100C

The IMU-ISA-100C contains an ISA-100C IMU.

Table 60: IMU-ISA-100C Physical Specifications

| Physical | |
|----------------------|--------------------------|
| IMU Enclosure Size | 180 mm x 150 mm x 137 mm |
| IMU Enclosure Weight | 5.0 kg |

See the following sections for more information about the IMU-ISA-100C IMU.

- *IMU-ISA-100C Mechanical Drawings* on the next page
- *Optional Side Mounting Holes* on page 152
- *IMU-ISA-100C Performance* on page 154
- *IMU-ISA-100C Electrical and Environmental* on page 155
- *IMU Enclosure Interface Cable* on page 156
- *IMU Enclosure Power Cable* on page 158
- *IMU Enclosure Wheel Sensor Cable* on page 160

A.6.1 IMU-ISA-100C Mechanical Drawings



The dimensions in the following diagrams are in millimetres.

Figure 49: IMU-ISA-100C Dimensions





Figure 50: IMU-ISA-100C Center of Navigation




A.6.2 Optional Side Mounting Holes

There are mounting and alignment holes on both sides of the IMU enclosure to allow the IMU to be mounted on its side. These holes have the same pattern and spacing as the mounting and alignment holes on the bottom of the IMU enclosure.

To access these holes, the NovAtel label must be removed from the side of the enclosure. A small notch on the side of enclosure allows you to insert a small flat blade screw under the label to start lifting the label.

Figure 51: Optional Side Mounting Holes



A.6.3 IMU-ISA-100C Performance**Table 61: IMU-ISA-100C IMU Performance**

| Gyroscope Performance | |
|-----------------------------------|---|
| Input range | ± 495 deg/sec |
| In-run bias stability | ≤ 0.05 deg/hr |
| Scale factor repeatability | ≤ 100 ppm |
| Scale factor non-linearity | ≤ 100 ppm |
| Angular random walk | 0.012 deg/ $\sqrt{\text{hr}}$ |
| Accelerometer Performance | |
| Range | ± 10 g |
| In-run bias stability | ≤ 100 μg |
| 1 year scale factor repeatability | ≥ 1250 μg |
| Scale factor non-linearity | ≤ 100 ppm |
| Velocity random walk | ≤ 100 $\mu\text{g}/\sqrt{\text{Hz}}$ |
| Data Rate | |
| IMU Measurement | 200 Hz |

A.6.4 IMU-ISA-100C Electrical and Environmental**Table 62: IMU-ISA-100C Electrical Specifications**

| Electrical | |
|-----------------------|------------------------|
| IMU Power Consumption | 18 W (typical) |
| IMU Input Voltage | +10 to +34 VDC |
| IMU Interface | RS-422 |
| Connectors | |
| Power | SAL M12, 5 pin, male |
| Data | SAL M12, 5 pin, female |
| Wheel Sensor | SAL M12, 8 pin, male |

Table 63: IMU-ISA-100C Environmental Specifications

| Environmental | |
|-----------------------|----------------------------|
| Operating Temperature | -40°C to +55°C |
| Storage Temperature | -40°C to +85°C |
| Humidity | MIL-STD-810G, Method 507.5 |
| Water Ingress | MIL-STD-810G. Method 512.5 |

A.6.5 IMU Enclosure Interface Cable

The NovAtel part number for the IMU Enclosure interface cable is 01019319 (see *Figure 52: IMU Enclosure Interface Cable* below). This cable enables communication between the receiver and the IMU.



 This cable is used for all versions of the IMU Enclosure (IMU-ISA-100C, IMU-ENC-LN200, IMU-HG1900 and IMU-μIMU-IC).

Figure 52: IMU Enclosure Interface Cable



 Dimensions are in millimetres.

Table 64: IMU Enclosure Interface Cable Pinouts

| P1 Pinout (M12) | Function | J2 Pinout (DB9) |
|-----------------|----------|-----------------|
| 1 | TX+ | 2 |
| 2 | RX+ | 3 |
| 3 | TX- | 8 |
| 4 | RX- | 7 |
| 5 | GND | 5 |
| Shield | Shield | Shield |

Custom Cable Recommendations

The tables below provide recommendations for creating custom cables to replace the IMU Enclosure interface cable (01019319).

Table 65: Connectors

| Connector | Description |
|-----------|-------------------------|
| P1 | M12x1, 5 position, male |
| J2 | DB-9, female |

Table 66: Maximum Cable Length

| IMU | RS-422 |
|--------------|-------------|
| IMU-ISA-100C | < 50 metres |


A.6.6 IMU Enclosure Power Cable

The NovAtel part number for the IMU Enclosure power cable is 60723136 (see *Figure 53: IMU Enclosure Power Cable* below). This cable provides power to the IMU from an external power source.



This cable is used for all versions of the IMU Enclosure (IMU-ISA-100C, IMU-ENC-LN200, IMU-HG1900 and IMU-μIMU-IC).

Figure 53: IMU Enclosure Power Cable



Dimensions are in millimetres.

Table 67: IMU Enclosure Power Cable Pin-outs


| P1 Pinout (M12) | Function | Bare Wire Color |
|-----------------|----------------|-----------------|
| 1 | VIN- | Brown |
| 2 | VIN+ | White |
| 3 | VIN+ | Blue |
| 4 | VIN- | Black |
| 5 | Chassis Ground | Grey |



This cable uses a M12x1, 5 position, female connector.


A.6.7 IMU Enclosure Wheel Sensor Cable

The NovAtel part number for the IMU Enclosure wheel sensor cable is 60723137 (see *Figure 54: IMU Enclosure Wheel Sensor Cable* below). This cable enables communication between the IMU and the wheel sensor.

 This cable is used for all versions of the IMU Enclosure (IMU-ISA-100C, IMU-ENC-LN200, IMU-HG1900 and IMU-μIMU-IC).

See also *Wheel Sensor Installation* on page 66.

Figure 54: IMU Enclosure Wheel Sensor Cable



 Dimensions are in millimetres.

Table 68: IMU Enclosure Wheel Sensor Cable Pinouts

| P1 Pinout (M12) | Function | Bare Wire Color |
|-----------------|----------------|-----------------|
| 1 | A+ | White |
| 2 | B+ | Brown |
| 3 | Chassis Ground | Green |
| 4 | A- | Yellow |

| P1 Pinout (M12) | Function | Bare Wire Color |
|-----------------|----------------|-----------------|
| 5 | B- | Grey |
| 6 | Chassis Ground | Pink |
| 7 | Reserved | Blue |
| 8 | Reserved | Red |

Custom Cable Recommendations

The tables below provide recommendations for creating custom cables to replace the IMU Enclosure Wheel Sensor cable (60723137).

Table 69: Connectors

| Connector | Description |
|-----------|---------------------------|
| P1 | M12x1, 8 position, female |
| J2 | DB-9, female |

Table 70: Maximum Cable Length

| IMU | RS-422 |
|-------------------|-------------|
| IMU-ISA-100C | < 50 metres |
| IMU-ENC-LN200 | |
| IMU-HG1900 | |
| IMU- μ IMU-IC | |

A.7 IMU-KVH1750

Table 71: IMU-KVH1750 Physical Specifications

| Physical | |
|------------------------|-------------------|
| Enclosure Size (Ø x H) | 88.9 mm X 73.7 mm |
| Weight | <0.7 kg |

See the following sections for more information about the IMU-KVH-1750.

- *IMU-KVH1750 Mechanical Drawings* on the next page
- *IMU-KVH1750 Sensor Specifications* on page 167
- *IMU-KVH1750 Electrical and Environmental* on page 168
- *IMU-KVH1750 Cable* on page 169

A.7.1 IMU-KVH1750 Mechanical Drawings



The dimensions in the following diagrams are in millimetres.

Figure 55: IMU-KVH1750 Bottom view




Figure 56: IMU-KVH1750 Top View




Figure 57: IMU-KVH1750 Side View





Figure 58: IMU-KVH1750 Gyro Axes



A.7.2 IMU-KVH1750 Sensor Specifications**Table 72: IMU-KVH1750 Performance**

| Gyroscope Performance | |
|---|---|
| Maximum Input Rate | ±490 °/second |
| Bias Stability (constant temperature) | 0.05°/hr (typical) 0.1°/hr (max) |
| Bias Temperature Sensitivity (full temp.) | 0.7°/hr (typical) 1°/hr (max) |
| Bias Offset (at 25° C) | ±2°/hr |
| Scale Factor (nominal) | 1 ±0.2% |
| Scale Factor Non-linearity (at 25° C) | ≤50 ppm |
| Scale Factor Temperature Sensitivity | ≤200 ppm |
| Angular Random Walk | ≤0.012 °/√hr |
| Input Axis Misalignment | ±0.4 mrad |
| Accelerometer Performance | |
| Maximum Input | ±10 g |
| Bias Stability (at 25° C) | ≤0.05 mg |
| Scale Factor Temperature Sensitivity | ≤100 ppm/°C (typical) 250 ppm/°C (max) |
| Velocity Random Walk | 0.12 mg/√Hz |
| Input Axis Misalignment | ±1.0 mrad |
| Data Rate | |
| IMU Measurement | 200 Hz |

A.7.3 IMU-KVH1750 Electrical and Environmental**Table 73: IMU-KVH1750 Electrical Specifications**

| Electrical | |
|------------------------------------|---------------------------|
| Input Voltage | 9 - 36 VDC |
| Power Consumption | 5W (typical), 8W (max) |
| Turn-On Time (room temp.) | ≤1.25 seconds |
| Full Performance Time (room temp.) | ≤60 seconds |
| IMU Interface | RS-422 |
| Connectors | |
| Power and I/O | 15-pin Micro-D (male) |


Table 74: IMU-KVH1750 Environmental Specifications

| Environmental | |
|------------------------------|------------------------|
| Temperature, operational | -40°C to +75°C |
| Temperature, non-operational | -50°C to +85°C |
| Vibration, operational | 8 g rms, 20 Hz -2 kHz |
| Vibration, non-operational | 12 g rms, 20 Hz -2 kHz |
| Shock, operational | 9 g (11 ms, sawtooth) |
| Shock, non-operational | 40 g (11 ms, sawtooth) |

A.7.4 IMU-KVH1750 Cable

The NovAtel part number for the IMU-KVH1750 cable is 01019211. This cable provides power to the IMU from an external power source and enables communication between the receiver and the IMU.

Figure 59: IMU-KVH1750 Cable



Dimensions are in millimetres.

Table 75: IMU-KVH1750 Connector Pinout Descriptions

| J1 (15 Pin Micro D Female) | | P2 (Female DB9) | | P3 |
|----------------------------|--------------|-----------------|----------------------|--------|
| Pin # | Signal Name | Pin # | Signal Name | Labels |
| 1 | TX+ | 2 | RX+ | |
| 2 | TX- | 8 | RX- | |
| 3 | RX- | 7 | TX- | |
| 4 | RX+ | 3 | TX+ | |
| 5 | Reserved | | | |
| 6 | Reserved | | | |
| 7 | Reserved | | | |
| 8 | Reserved | | | |
| 9 | Power Return | | | PWR- |
| 10 | VDC Power | | | PWR+ |
| 11 | MSync | 1 | IMU Event Out (Sync) | |
| 12 | TOV-Out | 9 | Event In | |
| 13 | Reserved | | | |

| J1 (15 Pin Micro D Female) | | P2 (Female DB9) | | P3 |
|----------------------------|----------------|-----------------|----------------|--------|
| Pin # | Signal Name | Pin # | Signal Name | Labels |
| 14 | Reserved | | | |
| 15 | Signal Ground | 5 | Signal Ground | |
| Shell | Chassis Ground | Shell | Chassis Ground | |



A hardware change by KVH regarding KVH1750 IMUs (manufactured after November 2015) expect a differential MSYNC signal input (J1 (15 pin micro D female) of the IMU: Pin 11 MSync+, Pin 7 MSync-). This was previously a single ended input signal on Pin 11 only. The NovAtel VARF signal used to provide the MSYNC to the IMU remains single ended, however significant testing has been completed with the existing IMU-KVH1750 Cable (01019211) in safe environments (no interference sources). No issues or failures have been observed. There are no plans to modify NovAtel cables at this time. However, for any custom or OEM cable solutions, it is recommended to follow KVH guidelines in providing a differential MSYNC signal, converting the VARF to differential and properly shielding for optimal reliability.

Custom Cable Recommendations

The tables below provide recommendations for creating custom cables to replace the IMU-KVH1750 cable (01019211).

Table 76: Connectors

| Connector | Description |
|-----------|-------------------------|
| J1 | Micro-D, 15-pin, female |
| J2 | DB-9, female |

Table 77: Maximum Cable Length

| IMU | RS-422 |
|-------------|--------------|
| IMU-KVH1750 | < 1.5 metres |

A.8 IMU-ENC-LN200

The IMU-ENC-LN200 contains an LN200 or LN200C IMU.

Table 78: IMU-ENC-LN200 Physical Specifications

| Physical | |
|----------------------|--------------------------|
| IMU Enclosure Size | 150 mm x 134 mm x 134 mm |
| IMU Enclosure Weight | <3.4 kg |

See the following sections for more information about the IMU-ENC-LN200.

- *IMU-ENC-LN200 Mechanical Drawings* on the next page
- *IMU-ENC-LN200 Sensor Specifications* on page 174
- *IMU-ENC-LN200 Electrical and Environmental* on page 175
- *IMU-ENC-LN200 Cables* on page 175

A.8.1 IMU-ENC-LN200 Mechanical Drawings



The dimensions in the following diagrams are in millimetres.

Figure 60: IMU-ENC-LN200 Dimensions





Figure 61: IMU-ENC-LN200 Center of Navigation



A.8.2 IMU-ENC-LN200 Sensor Specifications**Table 79: IMU-ENC-LN200 IMU Performance**

| Gyroscope Performance | |
|----------------------------------|---------------|
| Input range | ±1000 deg/sec |
| Rate bias | 1.0 deg/hr |
| Scale factor error | 100 ppm |
| Angular random walk | 0.07 deg/√hr |
| Accelerometer Performance | |
| Input range | ±40 g |
| Scale factor asymmetry | 150 ppm |
| Scale factor error | 300 ppm |
| Bias | 0.3 mg |
| Data Rate | |
| IMU Measurement | 200 Hz |

Table 80: IMU-ENC-LN200C IMU Performance

| Gyroscope Performance | |
|----------------------------------|--------------|
| Input range | ±490 deg/sec |
| Rate bias | 1.0 deg/hr |
| Scale factor error | 100 ppm |
| Angular random walk | 0.07 deg/√hr |
| Accelerometer Performance | |
| Input range | ±15 g |
| Scale factor asymmetry | 150 ppm |
| Scale factor error | 300 ppm |
| Bias | 1.0 mg |
| Data Rate | |
| IMU Measurement | 200 Hz |

A.8.3 IMU-ENC-LN200 Electrical and Environmental

Table 81: IMU-ENC-LN200 Electrical Specifications

| Electrical | |
|-----------------------|------------------------|
| IMU Power Consumption | 14 W (typical) |
| IMU Input Voltage | +10 to +34 VDC |
| IMU Interface | RS-422 |
| Connectors | |
| Power | SAL M12, 5 pin, male |
| Data | SAL M12, 5 pin, female |
| Wheel Sensor | SAL M12, 8 pin, male |

Table 82: IMU-ENC-LN200 Environmental Specifications

| Environmental | |
|-----------------------|------------------------------------|
| Operating Temperature | -40°C to +55°C |
| Storage Temperature | -40°C to +80°C |
| Humidity | MIL-STD-810G, Method 507.5 |
| Random Vibe | MIL-STD-810G, Method 514.6 (2.0 g) |
| Environment | IEC 60529 IP67 |

A.8.4 IMU-ENC-LN200 Cables

IMU-ENC-LN200 Interface Cable

The IMU-ENC-LN200 uses the IMU Enclosure Interface Cable. Refer to *IMU Enclosure Interface Cable* on page 156 for details about this cable.

IMU-ENC-LN200 Power Cable

The IMU-ENC-LN200 uses the IMU Enclosure Power Cable. Refer to *IMU Enclosure Power Cable* on page 158 for details about this cable.

IMU-ENC-LN200 Wheel Sensor Cable

The IMU-ENC-LN200 uses the IMU Enclosure Wheel Sensor Cable. Refer to *IMU Enclosure Wheel Sensor Cable* on page 160 for details about this cable.

A.9 IMU- μ IMU-IC

The IMU- μ IMU-IC contains a Litef μ IMU.

Table 83: IMU- μ IMU-IC Physical Specifications

| Physical | |
|----------------------|--------------------------|
| IMU Enclosure Size | 130 mm x 130 mm x 115 mm |
| IMU Enclosure Weight | 2.57 kg |

See the following sections for more information about the IMU- μ IMU.

- *IMU- μ IMU-IC Mechanical Drawings* on the next page
- *IMU- μ IMU-IC Sensor Specifications* on page 179
- *IMU- μ IMU-IC Electrical and Environmental* on page 180
- *IMU- μ IMU-IC Cables* on page 180

A.9.1 IMU- μ IMU-IC Mechanical Drawings



The dimensions in the following diagrams are in millimetres.

Figure 62: IMU- μ IMU-IC Dimensions





Figure 63: IMU- μ IMU-IC Center of Navigation



A.9.2 IMU- μ IMU-IC Sensor Specifications**Table 84: IMU- μ IMU-IC IMU Performance**

| Gyroscope Performance | |
|----------------------------------|--|
| Input range | ± 499 deg/sec |
| Bias stability | ≤ 6 deg/hr |
| Scale factor error | ≤ 1400 ppm |
| Angular random walk | ≤ 0.3 deg/ $\sqrt{\text{hr}}$ |
| Accelerometer Performance | |
| Input range | ± 15 g |
| Bias repeatability | ≤ 3 mg |
| Scale factor error | ≤ 1500 ppm |
| Velocity random walk | ≤ 0.25 mg/deg/ $\sqrt{\text{hz}}$ |
| Data Rate | |
| IMU Measurement | 200 Hz |

A.9.3 IMU- μ IMU-IC Electrical and Environmental

Table 85: IMU- μ IMU-IC Electrical Specifications

| Electrical | |
|-----------------------|------------------------|
| IMU Power Consumption | 11 W (typical) |
| IMU Input Voltage | +10 to +34 VDC |
| IMU Interface | RS-422 |
| Connectors | |
| Power | SAL M12, 5 pin, male |
| Data | SAL M12, 5 pin, female |
| Wheel Sensor | SAL M12, 8 pin, male |

Table 86: IMU- μ IMU-IC Environmental Specifications

| Environmental | |
|-----------------------|------------------------------------|
| Operating Temperature | -40°C to +55°C |
| Storage Temperature | -40°C to +80°C |
| Humidity | MIL-STD-810G, Method 507.5 |
| Random Vibe | MIL-STD-810G. Method 514.6 (2.0 g) |
| Environment | IEC 60529 IP67 |

A.9.4 IMU- μ IMU-IC Cables

IMU- μ IMU-IC Interface Cable

The IMU- μ IMU-IC uses the IMU Enclosure Interface Cable. Refer to *IMU Enclosure Interface Cable* on page 156 for details about this cable.

IMU- μ IMU-IC Power Cable

The IMU- μ IMU-IC uses the IMU Enclosure Power Cable. Refer to *IMU Enclosure Power Cable* on page 158 for details about this cable.

IMU- μ IMU-IC Wheel Sensor Cable

The IMU- μ IMU-IC uses the IMU Enclosure Wheel Sensor Cable. Refer to *IMU Enclosure Wheel Sensor Cable* on page 160 for details about this cable.

A.10 LN-200 IMU (single-connector enclosure)

Table 87: LN-200 IMU Physical Specifications

| Physical | |
|--------------------|--|
| IMU Enclosure Size | 135 mm x 153 mm x 130 mm (5.315" x 6.024" x 5.118") |
| IMU Size | 89 mm D x 85 mm H (3.504" D x 3.346" H) |
| IMU Weight | 3.19 kg (7.02 lb.) |

See the following sections for more information about the LN-200 IMU.

- *LN-200 IMU Mechanical Drawings* on the next page
- *LN-200 IMU Performance* on page 184
- *LN-200 Electrical and Environmental* on page 184
- *Interface Cable for the LN-200 IMU* on page 185

A.10.1 LN-200 IMU Mechanical Drawings



The dimensions in the following diagrams are in millimetres.

Figure 64: LN-200 IMU Enclosure Top/Bottom Dimensions and Center of Navigation





Figure 65: LN-200 Enclosure Side Dimensions



The Center of Navigation offsets, shown on the LN-200 label, are for the internal IMU and are different than for the enclosure center. The enclosure center is labelled as IMU Center in these figures. Dimensions are shown in millimeters.

A.10.2 LN-200 IMU Performance**Table 88: LN-200 IMU Performance**

| Gyroscope Performance | |
|----------------------------------|--------------------|
| Gyro Input Range | ±1000 degrees/s |
| Gyro Rate Bias | 1°/hr |
| Gyro Rate Scale Factor | 100 ppm |
| Angular Random Walk | 0.07 degrees/rt-hr |
| Accelerometer Performance | |
| Accelerometer Range | ±40 g |
| Accelerometer Linearity | 150 ppm |
| Accelerometer Scale Factor | 300 ppm |
| Accelerometer Bias | 0.3 mg |
| Data Rate | |
| IMU Measurement | 200 Hz |

A.10.3 LN-200 Electrical and Environmental**Table 89: LN-200 Electrical Specifications**

| Electrical | |
|----------------------------|------------------------------------|
| IMU Power Consumption | 16 W (max) |
| IMU Input Voltage | +12 to +28 VDC |
| Receiver Power Consumption | 1.8 W (typical) |
| System Power Consumption | 13.8 W (typical) |
| Input/Output Connectors | MIL-C-38999-III, 22 pin (all IMUs) |
| IMU Interface | RS-232 or RS-422 |

Table 90: LN-200 Environmental Specifications

| Environmental (LN-200 IMU) | |
|-----------------------------------|---------------------------------|
| Operating Temperature | -30°C to +60°C (-22°F to 140°F) |
| Storage Temperature | -45°C to +80°C (-49°F to 176°F) |
| Humidity | 95% non-condensing |

A.10.4 Interface Cable for the LN-200 IMU

The IMU interface cable provides power to the IMU from an external power source and enables communication between the receiver and IMU. The LN-200 IMU uses the Universal IMU Enclosure Interface cable (see *Universal IMU Enclosure Interface Cable* on page 228).

A.11 OEM-IMU-ADIS-16488



The OEM-IMU-ADIS-16488 requires a MEMS Interface Card (MIC) to connect to an OEM719 or OEM729 receiver. See *MIC - MEMS Interface Card* on page 230.

To connect the OEM-IMU-ADIS-16488 to an OEM7700 or OEM7720 receiver, you can use either a MIC or a direct connection via the SPI port.

Table 91: OEM-IMU-ADIS-16488 Physical Specifications

| Physical | |
|----------------------------|-----------------------------|
| IMU Size | 47 mm x 44 mm x 14 mm |
| IMU Weight | 48 g |
| IMU with mounting PCB size | 71.1 mm x 45.7 mm x 17.6 mm |

See the following sections for more information about the OEM-IMU-ADIS-16488.

- *OEM-IMU-ADIS-16488 Mechanical Drawings* on the next page
- *OEM-IMU-ADIS-16488 Sensor Specifications* on page 190
- *OEM-IMU-ADIS-16488 Electrical and Environmental* on page 190
- *OEM-IMU-ADIS-16488 SPI Connection* on page 191
- *ADIS-16488 IMU-to-MIC Cable Assembly* on page 193

A.11.1 OEM-IMU-ADIS-16488 Mechanical Drawings



The dimensions in these drawings are in millimetres.

The following two drawings include the ADIS-16488 interface board. The ADIS-16488 with interface board is intended for use with a MIC.

Figure 66: ADIS-16488 Dimensions






Figure 67: ADIS-16488 Center of Navigation



The following diagram shows the ADIS-16488 without the interface board. The ADIS-16488 without interface board is for applications where the IMU connects directly to the OEM7 receiver using a SPI port.

Figure 68: OEM ADIS-16488 Dimensions



A.11.2 OEM-IMU-ADIS-16488 Sensor Specifications

Table 92: OEM-IMU-ADIS-16488 Performance

| Gyroscope Performance | |
|-------------------------------------|----------------|
| Gyro Input Range | ±450°/second |
| In-run Gyro Rate Bias Stability | 6.25°/hour |
| Angular Random Walk | 0.30°/√hour |
| Accelerometer Performance | |
| Accelerometer Range | ±18 g |
| In-run Accelerometer Bias Stability | 0.1 mg |
| Velocity Random Walk | 0.029 m/s√hour |
| Data Rate | |
| IMU Measurement | 200 Hz |

A.11.3 OEM-IMU-ADIS-16488 Electrical and Environmental

Table 93: OEM-IMU-ADIS-16488 Electrical Specifications

| Electrical | |
|-------------------|---------------------------------------|
| Input Power | +3.0 to + 3.6 VDC +3.3 VDC typical |
| Power consumption | 254 mA typical |
| IMU Interface | SPI |

Table 94: OEM-IMU-ADIS-16488 Environmental Specifications

| Environmental | |
|------------------------------|-----------------|
| Temperature, operational | -40°C to +85°C |
| Temperature, non-operational | -40°C to +105°C |

A.11.4 OEM-IMU-ADIS-16488 SPI Connection

The following table shows the connections required when connecting the OEM-IMU-ADIS-16488 IMU to a SPI compatible OEM7 receiver, such as the OEM7700 or OEM7720.

Table 95: Receiver to ADIS-16488 Pin Connections

| ADIS-16488 | | Receiver | | Description |
|------------|----------|----------|------------|---|
| Pin | Pin Name | Pin | Pin Name | |
| 1 | NC | – | – | Do not connect |
| 2 | NC | – | – | Do not connect |
| 3 | SCLK | 44 | SPI_SCLK | SPI Serial Clock |
| 4 | SDO | 43 | SPI_MISO | SPI Data Output |
| 5 | SDI | 41 | SPI_MOSI | SPI Data Input |
| 6 | /CS | 42 | SPI_nCS | SPI Chip Select |
| 7 | DIO1 | 26 | EVENT_OUT2 | Synchronization signal |
| 8 | /RST | – | – | <p>Reset IMU</p> <p>RST must be high for the IMU to be active.</p> <p>To enable the IMU when the receiver is powered on, connect this pin to Pin 1 or Pin 2 of the receiver interface connector through a 10 kΩ resistor (recommended).</p> <p>Can also connect this pin to any stable 3.3 VDC power supply or output configuration to have more control over when IMU is enabled. When using this configuration note that:</p> <ul style="list-style-type: none"> pin 8 must be pulled low for greater than 100 ms to properly soft-reset the IMU pin has an internal pull-up resistor |
| 9 | DIO2 | 29 | EVENT_IN2 | Data ready |
| 10 | VDD | – | – | 3.3 VDC power supply |
| 11 | VDD | – | – | 3.3 VDC power supply |
| 12 | VDD | – | – | 3.3 VDC power supply |
| 13 | GND | – | – | Digital ground |
| 14 | GND | – | – | Digital ground |

| ADIS-16488 | | Receiver | | |
|------------|----------|----------|----------|----------------|
| Pin | Pin Name | Pin | Pin Name | Description |
| 15 | GND | – | – | Digital ground |
| 16 | NC | – | – | Do not connect |
| 17 | NC | – | – | Do not connect |
| 18 | NC | – | – | Do not connect |
| 19 | NC | – | – | Do not connect |
| 20 | NC | – | – | Do not connect |
| 21 | NC | – | – | Do not connect |
| 22 | NC | – | – | Do not connect |
| 23 | NC | – | – | Do not connect |
| 24 | NC | – | – | Do not connect |



For the location of the receiver pins, refer to the [OEM7 Installation and Operation User Manual](#).

For more information about connecting using a SPI port, refer to *Connect an OEM-IMU-ADIS-16488 Directly to an OEM7 Receiver Card* on page 35.

A.11.5 ADIS-16488 IMU-to-MIC Cable Assembly

The NovAtel part number for the ADIS-16488 IMU-to-MIC interface cable is 01019008 (*Figure 69: ADIS-16488 IMU-to-MIC Cable Assembly* below). This cable provides power to the IMU and enables communication between the MIC and the IMU.

Figure 69: ADIS-16488 IMU-to-MIC Cable Assembly




Table 96: ADIS-16488 IMU-to-MIC Cable Pinout

| P2 Pin | Signal Name | P1 Pin |
|--------|---------------|--------|
| 1 | IMU_VDD | 1 |
| 2 | IMU_VDD | 2 |
| 3 | SPI_NSS | 3 |
| 4 | SPI_CLK | 4 |
| 5 | Ground | 5 |
| 6 | SPI_MOSI | 6 |
| 7 | SPI_MISO | 7 |
| 8 | Ground | 8 |
| 9 | ADIS_IMU_DIO1 | 9 |
| 10 | ADIS_IMU_DIO2 | 10 |

A.12 OEM-IMU-EG320N

Table 97: OEM-IMU-EG320N Physical Specifications

| Physical | |
|------------|-----------------------|
| IMU Size | 24 mm x 24 mm x 10 mm |
| IMU Weight | 10 g |

See the following sections for more information about the OEM-IMU-EG320N IMU.

- *OEM-IMU-EG320N Mechanical Drawings* on the next page
- *OEM-IMU-EG320N Sensor Specifications* on page 196
- *OEM-IMU-EG320N Electrical Environmental* on page 196
- *OEM-IMU-EG320N Interface Connector* on page 197

A.12.1 OEM-IMU-EG320N Mechanical Drawings



 The following graphics are courtesy of Seiko Epson Corporation. In the following graphics, the dimensions are in millimetres.

Figure 70: EG320N Dimensions



A.12.2 OEM-IMU-EG320N Sensor Specifications**Table 98: OEM-IMU-EG320N Performance**

| Gyroscope Performance | |
|----------------------------------|----------------|
| Input Rate (max) | ±150°/second |
| Bias Repeatability | 0.5°/second |
| Bias Instability | 3.5°/hour |
| Angular Random Walk | 0.1°/√hour |
| Accelerometer Performance | |
| Accelerometer Range | ±5 g |
| Bias Repeatability | 15 mg |
| Bias Instability | 0.1 mg |
| Velocity Random Walk | 0.05 m/s/√hour |
| Data rate | |
| IMU Measurement | 125 Hz |

A.12.3 OEM-IMU-EG320N Electrical Environmental**Table 99: OEM-IMU-EG320N Electrical Specifications**

| Electrical | |
|-------------------|--|
| Input Power | +3.15 to +3.45 VDC +3.3 VDC typical |
| Power consumption | 0.1 W nominal |

Table 100: OEM-IMU-EG320N Environmental Specifications

| Environmental | |
|------------------------------|---------------------------------------|
| Temperature, operational | -40°C to +85°C |
| Temperature, non-operational | -40°C to +85°C |
| Vibration, operating | MIL-STD-810G, 7.7 g RMS, 20 - 2000 Hz |
| Shock, operating | MIL-STD/810G, 40 g, 11 ms |
| Shock, survival | 1000 g, half sine, 0.5 ms |

A.12.4 OEM-IMU-EG320N Interface Connector


 This graphic is courtesy of Seiko Epson Corporation.

Figure 71: OEM-IMU-EG320N Pin Locations




Table 101: OEM-IMU-EG320N Connector

| Pin | Pin Name | Description |
|-----|----------|----------------------|
| 1 | SCLK | SPI Serial Clock |
| 2 | SDO | SPI Data Output |
| 3 | GND | Digital ground |
| 4 | GND | Digital ground |
| 5 | SDI | SPI Data Input |
| 6 | /CS | SPI Chip Select |
| 7* | SOUT | UART Data Out |
| 8 | GND | Digital ground |
| 9* | SIN | UART Data In |
| 10 | VCC | 3.3 VDC power supply |
| 11 | VCC | 3.3 VDC power supply |

| Pin | Pin Name | Description |
|-----|-------------|---|
| 12 | VCC | 3.3 VDC power supply |
| 13 | DRDY(GPIO1) | Data Ready |
| 14 | GPIO2(EXT) | External Trigger |
| 15 | GND | Digital ground |
| 16 | /RST | Reset IMU RST must be high for the IMU to be active. |
| 17 | NC | Do not connect |
| 18 | NC | Do not connect |
| 19 | NC | Do not connect |
| 20 | NC | Do not connect |



The IMU-OEM-EG320N requires a Samtec CLM-110-02-H-D mating connector.

A.13 OEM-IMU-ISA-100C



The OEM-IMU-ISA-100C requires a Universal IMU Controller Card to connect to a NovAtel receiver. See *UIC - Universal IMU Controller* on page 243.

Table 102: OEM-IMU-ISA-100C Physical Specifications

| Physical | |
|------------|--------------------------|
| IMU Size | 100 mm x 130 mm x 125 mm |
| IMU Weight | 2 kg |

See the following sections for more information about the OEM-IMU-ISA-100C IMU.

- *OEM-IMU-ISA-100C Mechanical Drawings* on the next page
- *OEM-IMU-ISA-100C Sensor Specifications* on page 202
- *OEM-IMU-ISA-100C Electrical and Environmental* on page 202
- *OEM-IMU-ISA-100C IMU to UIC Cable Assembly* on page 203

A.13.1 OEM-IMU-ISA-100C Mechanical Drawings


 The following graphics are courtesy of Northrop Grumman LITEF GmbH. The dimensions in the following graphics are in millimetres.

Figure 72: ISA-100C Dimensions





Figure 73: ISA-100C Coordinate Axis



A.13.2 OEM-IMU-ISA-100C Sensor Specifications**Table 103: OEM-IMU-ISA-100C IMU Performance**

| Gyroscope Performance | |
|-----------------------------------|---|
| Input range | ± 495 deg/sec |
| In-run bias stability | ≤ 0.05 deg/hr |
| Scale factor repeatability | ≤ 100 ppm |
| Scale factor non-linearity | ≤ 100 ppm |
| Angular random walk | 0.012 deg/ $\sqrt{\text{hr}}$ |
| Accelerometer Performance | |
| Range | ± 10 g |
| In-run bias stability | ≤ 100 μg |
| 1 year scale factor repeatability | ≥ 1250 μg |
| Scale factor non-linearity | ≤ 100 ppm |
| Velocity random walk | ≤ 100 $\mu\text{g}/\sqrt{\text{Hz}}$ |
| Data Rate | |
| IMU Measurement | 200 Hz |

A.13.3 OEM-IMU-ISA-100C Electrical and Environmental**Table 104: OEM-IMU-ISA-100C Electrical Specifications**

| Electrical | |
|-------------------|--|
| Input Power | +3.3 V, ± 5.25 V, ± 15 V, -15 V (optional) |
| Power consumption | ≤ 10 W (typical) 16 W (maximum) |
| Connector | 44 pin HD D-Sub, male |

Table 105: OEM-IMU-ISA-100C Environmental Specifications

| Environmental | |
|--------------------------|--|
| Temperature, operational | -40°C to $+71^{\circ}\text{C}$ |

A.13.4 OEM-IMU-ISA-100C IMU to UIC Cable Assembly

The NovAtel part number for the OEM-IMU-ISA-100C IMU to UIC interface cable is 01019393 (Figure 74: OEM-IMU-ISA-100C IMU to UIC Cable Assembly below). This cable provides power to the IMU and enables communication between the UIC and the IMU.

Figure 74: OEM-IMU-ISA-100C IMU to UIC Cable Assembly




Table 106: OEM-IMU-ISA-100C IMU to UIC Cable Pinout

| J2 Pin (ISA-100C) | Signal | J1 Pin (UIC) |
|-------------------|--------|--------------|
| 1 | GND | 9 |
| 2 | 3.3 V | 1 |
| 3 | GND | 4 |
| 4 | GND | 5 |
| 5 | GND | 6 |

| J2 Pin (ISA-100C) | Signal | J1 Pin (UIC) |
|------------------------------|---------------|-------------------------|
| 6 | GND | 8 |
| 7 | GND | 10 |
| 8 | GND | 15 |
| 9 | GND | 16 |
| 10 | GND | 21 |
| 11 | GND | 22 |
| 12 | 5.25 V | 43 |
| 13 | -5.25 V | 49 |
| 14 | -5.25 V | 50 |
| 15 | -5.25 V | |
| 16 | 15 V | 7 |
| 17 | 3.3 V | 3 |
| 18 | GND | 28 |
| 19 | - | - |
| 20 | - | - |
| 21 | NOGOx | 18 |
| 22 | - | - |
| 23 | GND | 29 |
| | GND | 35 |
| 24 | TXC+ | 32 |
| 25 | SYNC- | 34 |
| 26 | GND | 41 |
| 27 | TXD+ | 40 |
| 28 | - | - |
| 29 | GND | 42 |
| 30 | 5.25 V | 44 |
| 31 | 3.3 V | 2 |
| 32 | 3.3 V | |

| J2 Pin (ISA-100C) | Signal | J1 Pin (UIC) |
|------------------------------|-----------------------|-------------------------|
| 33 | PWRDOWN _x | 12 |
| 34 | RESETIMU _x | 14 |
| 35 | - | - |
| 36 | GND | 45 |
| 37 | - | - |
| 38 | TXC- | 30 |
| 39 | GND | 48 |
| 40 | SYNC+ | 36 |
| 41 | TXD- | 38 |
| 42 | - | - |
| 43 | GND | 48 |
| 44 | 5.25 V | 46 |

A.14 OEM-IMU-STIM300



The OEM-IMU-STIM300 can use a MEMS Interface Card (MIC) or a direct RS-422 link to connect to an OEM7 receiver.

For information about using a MIC, see *MIC - MEMS Interface Card* on page 230.

For information about using a direct RS-422 link, see *Connect an OEM-IMU-STIM300 Directly to an OEM7 Receiver Card* on page 40.

Table 107: OEM-IMU-STIM300 Physical Specifications

| Physical | |
|------------|-----------------------|
| IMU Size | 45 mm x 39 mm x 22 mm |
| IMU Weight | 55 g |

See the following sections for more information about the OEM-IMU-STIM300 IMU.

- *OEM-IMU-STIM300 Mechanical Drawings* on the next page
- *OEM-IMU-STIM300 Sensor Specifications* on page 208
- *OEM-IMU-STIM300 Electrical and Environmental* on page 208
- *OEM-IMU-STIM300 Direct Connection* on page 209
- *STIM300 IMU-to-MIC Cable Assembly* on page 211

A.14.1 OEM-IMU-STIM300 Mechanical Drawings



The following graphics are courtesy of Sensoror AS.
In the following graphics, the dimensions are in millimetres.

Figure 75: STIM300 Dimensions





Figure 76: STIM300 Center of Navigation



A.14.2 OEM-IMU-STIM300 Sensor Specifications**Table 108: OEM-IMU-STIM300 Performance**

| Gyroscope Performance | |
|-------------------------------------|--------------------------------|
| Gyro Input Range | $\pm 400^\circ/\text{second}$ |
| In-run Gyro Rate Bias Stability | 0.5°/hour |
| Angular Random Walk | 0.15°/ $\sqrt{\text{hour}}$ |
| Accelerometer Performance | |
| Accelerometer Range | ± 10 g |
| In-run Accelerometer Bias Stability | 0.05 mg |
| Velocity Random Walk | 0.07 m/s/ $\sqrt{\text{hour}}$ |
| Data rate | |
| IMU Measurement | 125 Hz |

A.14.3 OEM-IMU-STIM300 Electrical and Environmental**Table 109: OEM-IMU-STIM300 Electrical Specifications**

| Electrical | |
|-------------------|--------------------------------------|
| Input Power | +4.5 to +5.5 VDC +5.0 VDC typical |
| Power consumption | 1.5 W nominal |
| Connector | 15 pin Micro-D, female |

Table 110: OEM-IMU-STIM300 Environmental Specifications

| Environmental | |
|------------------------------|----------------|
| Temperature, operational | -40°C to +85°C |
| Temperature, non-operational | -55°C to +90°C |

A.14.4 OEM-IMU-STIM300 Direct Connection

The following table shows the connections required when connecting the OEM-STIM300 to an OEM7700 or OEM7720 receiver using a RS-422 link.

Table 111: Receiver to STIM300 Pin Connections

| STIM300 | | RS-422 Line Driver | | Receiver | | Description |
|---------|-----------|--------------------|-------|----------|-----------|--|
| Pin | Pin Name | Output | Input | Pin | Pin Name | |
| 1 | STIM TXD- | RS422 B- | - | - | - | Part of RS-422 transmit pair from STIM300 |
| 2 | STIM RxD- | RS422 A- | - | - | - | Part of RS-422 receive pair from STIM300 |
| 3 | NC | - | - | - | - | Do not connect |
| 4 | STIM TOV | - | - | 29 | EVENT_IN2 | <div style="border: 1px solid black; padding: 5px;"> <p>Interface Circuit Required</p> <p>The STIM TOV output uses 5V logic, but the OEM7 EVENT_IN lines are not 5V tolerant. A circuit to convert from 5V logic to 3.3V levels is required.</p> </div> |
| 5 | NC | - | - | - | - | Do not connect |
| 6 | NC | - | - | - | - | Do not connect |
| 7 | NC | - | - | - | - | Do not connect |
| 8 | 5V Pwr | - | - | - | - | 5 VDC power supply |
| 9 | STIM TxD+ | RS422 B+ | - | - | - | Part of RS-422 transmit pair from STIM300 |
| 10 | STIM RxD+ | RS422 A+ | - | - | - | Part of RS-422 receive pair from STIM300 |
| 11 | NC | - | - | - | - | Do not connect |
| 12 | GND | - | - | - | - | Any receiver ground pin |
| 13 | GND | - | - | - | - | Any receiver ground pin |

| STIM300 | | RS-422 Line Driver | | Receiver | | Description |
|---------|----------|--------------------|-------------|----------|--------------|--|
| Pin | Pin Name | Output | Input | Pin | Pin Name | |
| 14 | NC | – | – | – | – | Do not connect |
| 15 | GND | – | – | – | – | Any receiver ground pin |
| – | – | – | LVCMOS A IN | | COMx_ TXD | Any receiver COM port transmit and receive pair |
| – | – | – | LVCMOS B IN | | COMx_ RXD | |
| – | – | – | GND | | | Any receiver ground pin |




For the location of the receiver ground pins and transmit and receive pairs, refer to the [OEM7 Installation and Operation User Manual](#).

For more information about connecting using a SPI port, refer to *Connect an OEM-IMU-STIM300 Directly to an OEM7 Receiver Card* on page 40.

A.14.5 STIM300 IMU-to-MIC Cable Assembly

The NovAtel part number for the STIM300 IMU-to-MIC interface cable is 01019161 (*Figure 77: STIM300 IMU-to-MIC Cable Assembly* below). This cable provides power to the IMU and enables communication between the MIC and the IMU.

Figure 77: STIM300 IMU-to-MIC Cable Assembly



The dimensions in this drawing are in millimetres.

Table 112: STIM300 IMU-to-MIC Cable Pinout

| P2 Pin (MIC) | Signal | P1 Pin (STIM300) |
|--------------|-----------------|------------------|
| 1 | No connection | – |
| 2 | No connection | – |
| 3 | No connection | – |
| 4 | No connection | – |
| 5 | No connection | – |
| 6 | Ground | 12 |
| 7 | Ground | 13 |
| 8 | VSUP (5V input) | 8 |
| 9 | VSUP (5V input) | |
| 10 | Ground | 15 |
| 11 | Transmit Data+ | 10 |
| 12 | Transmit Data- | 2 |
| 13 | Receive Data+ | 9 |
| 14 | Receive Data- | 1 |

| P2 Pin (MIC) | Signal | P1 Pin (STIM300) |
|---------------------|---------------|-------------------------|
| 15 | No connection | - |
| 16 | No connection | - |
| 17 | IMU DAS | 4 |
| 18 | No connection | - |
| 19 | IMUTYPE1 | 15 |
| 20 | No connection | - |

A.15 OEM-IMU- μ IMU



The OEM-IMU- μ IMU requires a Universal IMU Controller to connect to a NovAtel receiver. See *UIC - Universal IMU Controller* on page 243.

Table 113: OEM-IMU- μ IMU Physical Specifications

| Physical | |
|-------------------------------|---------------|
| IMU Size (\varnothing x H) | 85 mm x 60 mm |
| IMU Weight | 0.68 kg |

See the following sections for more information about the OEM-IMU- μ IMU.

- *OEM-IMU- μ IMU Mechanical Drawings* on the next page
- *OEM-IMU- μ IMU Sensor Specifications* on page 217
- *OEM-IMU- μ IMU Electrical and Environmental* on page 217
- *μ IMU to UIC Cable Assembly* on page 218

A.15.1 OEM-IMU- μ IMU Mechanical Drawings



The following graphics are courtesy of Northrop Grumman LITEF GmbH.
The dimensions in the following graphics are in millimetres.

Figure 78: μ IMU Dimensions






Figure 79: μ IMU Coordinate Axis



Arrows indicate positive values.

A.15.2 OEM-IMU- μ IMU Sensor Specifications

Table 114: OEM-IMU- μ IMU IMU Performance

| Gyroscope Performance | |
|----------------------------------|--|
| Input range | ± 499 deg/sec |
| Bias stability | ≤ 6 deg/hr |
| Scale factor error | ≤ 1400 ppm |
| Angular random walk | ≤ 0.3 deg/ $\sqrt{\text{hr}}$ |
| Accelerometer Performance | |
| Input range | ± 15 g |
| Bias repeatability | ≤ 3 mg |
| Scale factor error | ≤ 1500 ppm |
| Velocity random walk | ≤ 0.25 mg/deg/ $\sqrt{\text{hz}}$ |
| Data Rate | |
| IMU Measurement | 200 Hz |

A.15.3 OEM-IMU- μ IMU Electrical and Environmental

Table 115: OEM-IMU- μ IMU Electrical Specifications


| Electrical | |
|-------------------|----------------------|
| Input Power | +5.0 VDC |
| Power consumption | <8 W |
| Connector | 31 pin Micro-D, plug |

Table 116: OEM-IMU- μ IMU Environmental Specifications

| Environmental | |
|--------------------------|----------------|
| Temperature, operational | -55°C to +71°C |

A.15.4 μ IMU to UIC Cable Assembly

The NovAtel part number for the μ IMU to UIC interface cable is 01019760 (Figure 80: μ IMU to UIC Cable Assembly below). This cable provides power to the IMU and enables communication between the UIC and the IMU.



The dimensions in this drawing are in millimetres.

Table 117: μ IMU to UIC Cable Pin-out

| P1 Pin (μ IMU) | Signal | J2 Pin (UIC) |
|---------------------|-----------------|--------------|
| 1 | Ground | B2 |
| 2 | Ground | A3 |
| 3 | Transmit Data+ | B20 |
| 4 | Transmit Data- | B19 |
| 5 | Transmit Clock- | B15 |
| 6 | Transmit Clock+ | B16 |
| 7 | Ground | B3 |
| 8 | Ground | B4 |
| 13 | NOGO | B9 |
| 16 | SYNC- | B17 |
| 17 | IMU_5V25 | A22 |
| 18 | IMU_5V25 | B22 |

| P1 Pin (μIMU) | Signal | J2 Pin (UIC) |
|---|---------------|-------------------------|
| 19 | IMU_5V25 | B23 |
| 20 | Ground | A21 B21 |
| 21 | Ground | B5 B11 |
| 22 | Ground | A23 B24 |
| 26 | Lug Ring | - |
| 27 | IMU_PDWARN | B6 |
| 30 | IMU_RESET | B7 |
| 31 | SYNC+ | B18 |
| | IMU_TYPE_3 | A15 to A18 |
| | IMU_TYPE_1 | A13 to A11 |

A.16 Universal IMU Enclosure (HG1700, LN200)

The Universal IMU Enclosure is available with the HG1700 and LN-200 IMUs.

Table 118: Universal IMU Enclosure Physical Specifications

| PHYSICAL | |
|----------------------|--------------------------|
| IMU Enclosure Size | 168 mm x 195 mm x 146 mm |
| IMU Enclosure Weight | 4.25 kg |

See the following sections for more information about the IMUs available in the Universal IMU Enclosure.

- *Universal IMU Enclosure Mechanical Drawings* on the next page
- *IMU Performance* on page 225
- *Electrical and Environmental* on page 227
- *Universal IMU Enclosure Interface Cable* on page 228

A.16.1 Universal IMU Enclosure Mechanical Drawings



The dimensions for the drawing in this section are in mm [inches].

Figure 81: Universal IMU Enclosure Side Dimensions




Figure 82: Universal IMU Enclosure Top/Bottom Dimensions




Figure 83: Universal IMU Center of Navigation





Figure 84: Universal IMU Frame Axis



A.16.2 IMU Performance**Table 119: HG1700-AG58 IMU Performance**

| Gyroscope Performance | |
|----------------------------------|-----------------|
| Gyro Input Range | ±1000 deg/sec |
| Gyro Rate Bias | 1.0 deg/hr |
| Gyro Rate Scale Factor | 150 ppm |
| Angular Random Walk | 0.125 deg/rt-hr |
| Accelerometer Performance | |
| Accelerometer Range | ±50 g |
| Accelerometer Linearity | 500 ppm |
| Accelerometer Scale Factor | 300 ppm |
| Accelerometer Bias | 1.0 mg |
| Data Rate | |
| IMU Measurement | 100 Hz |

Table 120: HG1700-AG62 IMU Performance

| Gyroscope Performance | |
|----------------------------------|---------------|
| Gyro Input Range | ±1000 deg/sec |
| Gyro Rate Bias | 5.0 deg/hr |
| Gyro Rate Scale Factor | 150 ppm |
| Angular Random Walk | 0.5 deg/rt-hr |
| Accelerometer Performance | |
| Accelerometer Range | ±50 g |
| Accelerometer Linearity | 500 ppm |
| Accelerometer Scale Factor | 300 ppm |
| Accelerometer Bias | 2.0 mg |
| Data Rate | |
| IMU Measurement | 100 Hz |

Table 121: LN200 IMU Performance

| Gyroscope Performance | |
|----------------------------------|----------------|
| Gyro Input Range | ±1000 deg/sec |
| Gyro Rate Bias | 1.0 deg/hr |
| Gyro Rate Scale Factor | 100 ppm |
| Angular Random Walk | 0.07 deg/rt-hr |
| Accelerometer Performance | |
| Accelerometer Range | ±40 g |
| Accelerometer Linearity | 150 ppm |
| Accelerometer Scale Factor | 300 ppm |
| Accelerometer Bias | 0.3 mg |
| Data Rate | |
| IMU Measurement | 200 Hz |

A.16.3 Electrical and Environmental**Table 122: Universal IMU Enclosure Electrical Specifications**

| Electrical | |
|----------------------------|--|
| IMU Power Consumption | HG1700-AG58: 9 W (max) HG1700-AG62: 8 W (max) LN-200: 16 W (typical) |
| IMU Input Voltage | +12 to +28 VDC (all IMUs) |
| Receiver Power Consumption | 1.8 W (typical, for all IMUs) |
| Input/Output Connectors | MIL-C-38999-III, 22 pin (all IMUs) |
| IMU Interface | RS-232 or RS-422 |

Table 123: Universal IMU Enclosure Environmental Specifications

| Environmental | |
|----------------------|--|
| Temperature | HG1700-AG58, HG1700-AG62 Operating: -30°C to +60°C Storage: -45°C to +80°C |
| | LN-200 Operating: -30°C to +60°C Storage: -45°C to +80°C |
| Humidity | Operates at 95% RH, non-condensing (all IMUs) |

A.16.4 Universal IMU Enclosure Interface Cable

The NovAtel part number for the Universal IMU Enclosure interface cable is 01018977 (see *Figure 85: Universal IMU Enclosure Interface Cable* below). This cable provides power to the IMU from an external power source and enables communication between the receiver and the IMU.

Figure 85: Universal IMU Enclosure Interface Cable




Table 124: Universal IMU Enclosure Interface Cable Pinouts

| J2 Pinout | Function | Connector | Pin/Label |
|-----------|--------------|-----------|-----------|
| 1 | $V_{IN} (-)$ | P2 | Vin (-) |
| 22 | $V_{IN} (-)$ | | |
| 2 | Not used | | |
| 3 | $V_{IN} (+)$ | P1 | Vin (+) |
| 21 | $V_{IN} (+)$ | | |
| 4 | Not used | | |
| 5 | Not used | | |
| 6 | Not used | | |
| 7 | DAS (+) | J1 | 1 |
| 8 | Not used | | |
| 9 | DAS GND (-) | J1 | 5 |
| 10 | Not used | | |

| J2 Pinout | Function | Connector | Pin/Label |
|-----------|-------------|-----------|-----------|
| 11 | OEM_CTS/Rx- | J1 | 8 |
| 12 | OEM_Rx/Rx+ | J1 | 2 |
| 13 | Not used | | |
| 14 | DGND | J1 | 5 |
| 15 | DGND | J1 | 5 |
| 16 | Not used | | |
| 17 | Not used | | |
| 18 | Not used | | |
| 19 | OEM_Tx/Tx+ | J1 | 3 |
| 20 | OEM_RTS/Tx- | J1 | 7 |
| | Shield | P3 | Shield |

Custom Cable Recommendations

The tables below provide recommendations for creating custom cables to replace the Universal IMU Enclosure interface cable (01018977).

Table 125: Connectors

| Connector | Description |
|-----------|-------------------------|
| J1 | DB-9, female |
| J2 | MIL-DTL-38999 III, plug |

Table 126: Maximum Cable Length

| IMU | RS-232 | RS-422 |
|-----------------------|--------------|--------------|
| HG1700, LN-200, LCI-1 | < 2.0 metres | < 50 metres |
| iIMU-FSAS | N/A | < 1.5 metres |

A.17 MIC - MEMS Interface Card

Table 127: MEMS Interface Card Physical Specifications

| Physical | |
|------------|--|
| MIC Size | 74.9 mm x 45.7 mm x 19.5 mm (2.94" x 1.80" x 0.76") |
| MIC Weight | 31 g (0.0683 lb) |

See the following sections for more information about the MIC.

- *MIC Mechanical Drawings* on the next page
- *MIC Electrical and Environmental* on page 233
- *MIC Connectors* on page 234
- *HG1930 IMU-to-MIC Cable Assembly* on page 239
- *HG1700 and HG1900 IMU-to-MIC Cable Assembly* on page 241

A.17.1 MIC Mechanical Drawings



The dimensions in the following drawings are in millimetres.

Figure 86: MIC Top/Bottom Dimensions





Figure 87: MIC Keep-Out Zone



Cross hatched areas indicate "keepout" areas intended for NovAtel circuitry. NovAtel reserves the right to modify components and component placements inside cross hatched keepout zones, while maintaining design, form, fit and function.

A.17.2 MIC Electrical and Environmental**Table 128: MIC Electrical Specifications**

| Electrical | |
|--------------------------------|--|
| MIC Input Voltage | 10 VDC to 30 VDC |
| Power Consumption ¹ | +5 VDC @ 1 Amp for IMU +3.3 VDC @ 1 Amp for IMU +15 VDC @ 0.5 Amp for IMU -15 VDC @ 0.08 Amp for IMU +3.3 VDC @ 0.6 Amp for OEM719 |
| IMU Data Interfaces | UART and SDLC over RS-422 |

Table 129: MIC Electrical and Environmental Specifications

| Environmental | |
|-----------------------|----------------------------------|
| Operating Temperature | -40°C to +75°C (-40°F to 167°F) |
| Storage Temperature | -55°C to +90°C (-67°F to 194°F) |
| Random Vibe | MIL-STD 810G (Cat 24, 7.7 g RMS) |
| Sine Vibe | IEC 60068-2-6 |
| Bump | IEC 68-2-29 (25 g) |
| Shock | MIL-STD-810G (40 g) |

¹Sample system power consumption: 5.7 W when powering an HG1900 IMU and OEM719 receiver, in board stack configuration, from VIN=15 VDC at +25°C.

A.17.3 MIC Connectors**Table 130: MIC Connectors**

| Connector | Description | Part Number | Mating Connector Part number |
|-----------|--|----------------------------------|-----------------------------------|
| J301 | 20-pin OEM719 mating connector | 501189-3010 Molex Electronics | Connects only to OEM719 receiver. |
| P101 | 3-pin locking power connector | 43650-0313 Molex Electronics | 43645-0300 Molex Electronics |
| P301 | 30-pin locking communication connector | 501571-3007 Molex Electronics | 501189-3010 Molex Electronics |
| P601 | 20-pin locking IMU connector for Honeywell and Sensoror IMUs | 53780-2070 Molex Electronics | 51146-2000 Molex Electronics |
| P701 | 10-pin locking IMU connector for ADIS IMUs | 53780-1070 Molex Electronics | 51146-1000 Molex Electronics |

Table 131: Pinouts for Power Connector (P101)

| Pin | Signal | Type | Description | Comments |
|-----|--------|-------|----------------|---|
| 1 | VIN+ | Power | Power input | +10 VDC to +30 VDC |
| 2 | VIN- | Power | Power return | Connect to negative terminal of battery |
| 3 | GND | Power | Chassis ground | |

Table 132: Pinouts for User Interface Connector (P301)

| Pin | Signal | Type | Description | Comments |
|-----|--------|--------|--------------------------------|----------|
| 1 | N/C | | | |
| 2 | N/C | | | |
| 3 | LED3 | Output | Status LED 3 / Self-test | |
| 4 | LED2 | Output | Status LED 2 / GPS Time Status | |

| Pin | Signal | Type | Description | Comments |
|-----|--------------------|------------------|--|---|
| 5 | DGND | Power | Digital ground | |
| 6 | LED1 | Output | Status LED 1 / IMU Data Status | |
| 7 | Reserved | N/A | Leave as no connect | |
| 8 | DGND | Power | Digital ground | |
| 9 | Reserved | N/A | Leave as no connect | |
| 10 | Reserved | N/A | Leave as no connect | |
| 11 | N/C | N/A | | |
| 12 | N/C | N/A | | |
| 13 | USB D- | Bidirectional | USB interface data (-) | Only available in board stackup with OEM719 In standalone, no connect |
| 14 | USB D+/ COM3 RX | Bidirectional | USB interface data (+)/ COM3 receive data | Only available in board stackup with OEM719 In standalone, no connect The USB port is enabled by default and the COM3 port is disabled by default. If you enable the COM3 port, the USB port is disabled. |
| 15 | RESETIN | Input | OEM719 reset in | Only available in board stackup with OEM719 In standalone, no connect |
| 16 | VARF/ CAN1 RX | Output/ Input | Variable frequency output/CAN1 receive data | Only available in board stackup with OEM719 In standalone, no connect The VARF output is enabled by default and the CAN1RX input is disabled by default. If you disable VARF, the CAN1RX input is enabled. |
| 17 | EVENT2/ CAN1 TX | Input/ Output | Event2 input/ CAN1 transmit data | Only available in board stackup with OEM719 In standalone, no connect The Event2 input is enabled by default and the CAN1TX output is disabled by default. If you disable EVENT2, the CAN1TX output is enabled. |
| 18 | CAN2 RX | Input | CAN2 receive data | Only available in board stackup with OEM719 In standalone, no connect |

| Pin | Signal | Type | Description | Comments |
|-----|--------------------|--------|--|---|
| 19 | EVENT1/ COM3 TX | Input | Event1 input/ COM3 transmit data | Only available in board stackup with OEM719 In standalone, no connect The Event1 input is enabled by default and the COM3 port is disabled by default. If you enable the COM3 port, the Event1 input is disabled. |
| 20 | DGND | Power | Digital ground | |
| 21 | MIC TX | Output | | In board stackup with OEM719, this pin is for firmware download In standalone use, this pin can be used for either firmware download and/or for IMU data communication to a SPAN receiver |
| 22 | MIC RX | Input | | In board stackup with OEM719, this pin is for firmware download In standalone use, this pin can be used for either firmware download and/or for IMU data communication to a SPAN receiver |
| 23 | DGND | Power | | |
| 24 | USER_ TXD2 | Output | | In board stackup with OEM719, this is the access to the OEM719 COM2 port In standalone, no connect |
| 25 | USER_ RXD2 | Input | | In board stackup with OEM719, this is the access to the OEM719 COM2 port In standalone, no connect |
| 26 | DGND | Power | Digital ground | |
| 27 | PV | Output | Access to OEM719 position valid | Only available in board stackup with OEM719 In standalone, no connect |
| 28 | DGND | Power | Digital ground | |
| 29 | 1PPS | Output | Access to OEM719 1PPS | Only available in board stackup with OEM719 In standalone, no connect |
| 30 | CAN2 TX | Output | CAN2 transmit data | Only available in board stackup with OEM719 In standalone, no connect |



All signal I/O with the exception of USB port are at LVCMOS levels.

Table 133: Pinouts for IMU Connector (P601)

| Pin | Signal | Type | Description | Comments |
|-----|----------|---------------|--|--|
| 1 | GND | | Chassis ground | |
| 2 | GND | | Chassis ground | |
| 3 | 15V | Output Power | Positive 15 VDC supply | Enabled/disabled depending on the IMU type detected |
| 4 | 15V | Output Power | Positive 15 VDC supply | Enabled/disabled depending on the IMU type detected |
| 5 | -15V | Output Power | Negative 15 VDC supply | Enabled/disabled depending on the IMU type detected |
| 6 | DGND | | Digital ground | Enabled/disabled depending on the IMU type detected |
| 7 | DGND | | Digital ground | Enabled/disabled depending on the IMU type detected |
| 8 | IMU VDD | Output Power | Positive voltage supply for IMU logic circuits | IMU_VDD can be +3.3 VDC or +5 VDC depending on the IMU type detected |
| 9 | IMU VDD | Output Power | Positive voltage supply for IMU logic circuits | |
| 10 | DGND | Power | Digital ground | |
| 11 | Tx Data+ | Output | Serial data out+ | Non-inverting |
| 12 | Tx Data- | Output | Serial data out- | Inverting |
| 13 | RX Data+ | Input | Serial data in+ | Non-inverting RS-422 data input |
| 14 | RX Data- | Input | Serial data in- | Inverting RS-422 data input |
| 15 | CLK+ | Bidirectional | Serial data clock+ | Non-inverting portion of RS-422 link |
| 16 | CLK- | Bidirectional | Serial data clock- | Inverting portion of RS-422 link |
| 17 | IMU DAS | Bidirectional | Data acquisition signal | Provides synchronization for IMU data (LVCMOS level) |
| 18 | IMUTYPE0 | Input | detect IMU type | LVCMOS level, not 5V tolerant |
| 19 | IMUTYPE1 | Input | detect IMU type | LVCMOS level, not 5V tolerant |
| 20 | IMUTYPE2 | Input | detect IMU type | LVCMOS level, not 5V tolerant |



All signal I/O are at LVCMOS levels.

Table 134: Pinouts for IMU Connector (P701)

| Pin | Signal | Type | Description | Comments |
|-----|----------|---------------|--|--------------------------------|
| 1 | IMU_VDD | Output Power | Positive voltage supply for IMU logic circuits | IMU_VDD must be +3.3 VDC |
| 2 | IMU_VDD | Output Power | Positive voltage supply for IMU logic circuits | |
| 3 | SPI_NSS | | Slave Select | LVC MOS level, not 5V tolerant |
| 4 | SPI_SCK | Output | Serial Clock | LVC MOS level, not 5V tolerant |
| 5 | DGND | | Digital Ground | |
| 6 | SPI_MOSI | Output | Master Output / Slave Input | LVC MOS level, not 5V tolerant |
| 7 | SPI_MISO | Input | Master Input / Slave Output | LVC MOS level, not 5V tolerant |
| 8 | DGND | | Digital Ground | |
| 9 | IMU_DIO1 | Bidirectional | | LVC MOS level, not 5V tolerant |
| 10 | IMU_DIO2 | Bidirectional | | LVC MOS level, not 5V tolerant |

Table 135: MIC LED Indicator Drivers


| Board State | Status LED 1 | Status LED 2 | Status LED 3 |
|------------------|---------------------------|--------------------------|--------------------------|
| Bootup | Toggles at 2 Hz Self-test | Off | On |
| Normal Operation | On | Toggles at 2 Hz GPS Time | Toggles at 2 Hz IMU Data |
| No IMU Connected | Toggles at 1 Hz Error | Toggles at 2 Hz GPS Time | Toggles at 1 Hz Error |



When the MIC boots up, it requires approximately 10 seconds to perform a self-test. If a software update has been performed, the board can take up to 70 seconds at startup to complete the reprogramming.

A.17.4 HG1930 IMU-to-MIC Cable Assembly

The NovAtel part number for the HG1930 IMU-to-MIC interface cable is 01018827 (*Figure 88: HG1930 IMU-to-MIC Cable Assembly* below). This cable provides power to the IMU and enables communication between the MIC and the IMU.



The dimensions in this drawing are in millimetres.

Table 136: HG1930 IMU-to-MIC Cable Assembly

| P1 IMU Cable End (FCI-MINITEK) | | P2 MIC Cable End | |
|--------------------------------|-----|------------------|-----|
| Pin | Pin | Pin | Pin |
| 1 | | 15 | |
| 2 | | 16 | |
| 3 | | 13 | |
| 4 | | 14 | |
| 5 | | 8 | |
| 7 | | 7 | |
| 6 | | 9 | |
| 8 | | 10 | |
| 11 | | 3 | |
| | | 4 | |
| 12 | | 6 | |
| | | 19 | |
| 9 | | 5 | |
| 10 | | 1 | |
| | | 2 | |




For more information, refer to the IMU documentation provided by Honeywell.

A.17.5 HG1700 and HG1900 IMU-to-MIC Cable Assembly

The NovAtel part number for the HG1700 and HG1900 IMU-to-MIC interface cable is 01018828 (Figure 89: HG1700 and HG1900 IMU-to-MIC Cable Assembly below). This cable provides power to the IMU and enables communication between the MIC and the IMU.

Figure 89: HG1700 and HG1900 IMU-to-MIC Cable Assembly



The dimensions in this drawing are in millimetres.

Table 137: HG1700 and HG1900 IMU-to-MIC Cable Assembly

| P1 IMU Cable End (FCI-MINITEK) | | P2 MIC Cable End | |
|--------------------------------|--|------------------|--|
| Pin | | Pin | |
| 1 | | 15 | |
| 2 | | 16 | |
| 3 | | 13 | |
| 4 | | 14 | |
| 5 | | 8 | |
| 7 | | 7 | |
| 6 | | 9 | |
| 8 | | 10 | |
| 11 | | 3 | |
| | | 4 | |
| 12 | | 6 | |
| | | 18 | |
| 9 | | 5 | |
| 10 | | 1 | |
| | | 2 | |



For more information, refer to the IMU documentation provided by Honeywell.

A.18 UIC - Universal IMU Controller

Table 138: UIC Physical Specifications

| Physical | |
|------------|---|
| UIC Size | 100 mm x 113 mm x 17.54 mm (3.94" x 4.45" x 0.69") |
| UIC Weight | 125 g (0.28 lb) |

See the following sections for more information about the UIC.

- *UIC Mechanical Drawings* on the next page
- *UIC Electrical and Environmental* on page 246
- *UIC Connectors* on page 247
- *HG1900 IMU to UIC Cable Assembly* on page 251
- *LN200 IMU to UIC Cable Assembly* on page 252

A.18.1 UIC Mechanical Drawings



The dimensions in the following drawings are in millimetres.

Figure 90: UIC Dimensions and Keep Out Zones






Figure 91: UIC Connectors, LEDs and Heat Sink Details



Cross hatching indicates mounting rail on both sides with noted exception for J101 connector.



A.18.2 UIC Electrical and Environmental**Table 139: UIC Electrical Specifications**

| Electrical | |
|---------------------|---------------------------|
| UIC Input Voltage | 10 VDC-34 VDC |
| Power Consumption | 4 W ^a |
| IMU Data Interfaces | UART and SDLC over RS-422 |

Table 140: UIC Environmental Specifications

| Environmental | |
|-----------------------|----------------------------------|
| Operating Temperature | -40°C to +75°C (-40°F to 167°F) |
| Storage Temperature | -55°C to +90°C (-67°F to 194°F) |
| Random Vibe | MIL-STD 810G (Cat 24, 7.7 g RMS) |
| Sine Vibe | IEC 60068-2-6 |
| Bump | IEC 68-2-29 (25 g) |
| Shock | MIL-STD-810G (40 g) |

^aAt 12 VDC input.

A.18.3 UIC Connectors

Table 141: UIC Connectors

| Connector | Description | Part Number | Mating Connector Part number |
|-----------|---|-----------------------------------|---------------------------------|
| J101 | 5-pin UIC power connector ^a | 43650-0513 Molex Electronics | 43645-0500 Molex Electronics |
| J102 | 16-pin UIC to receiver communication connector ^b | 98464-G61-16LF FCI Electronics | 90311-016LF FCI Electronics |
| J1401 | 50-pin UIC to IMU communication connector | LTMM-125-02-L-D (Samtec) | SQT-125-01-L-D (Samtec) |

Table 142: Pinouts for Power Connector (J101)

| Pin | Signal | Type | Description | Comments |
|-----|--------|-------|----------------|---|
| 1 | VIN+ | Power | Power input | +10 VDC to +34 VDC |
| 2 | VIN+ | Power | Power input | +10 VDC to +34 VDC |
| 3 | VIN- | Power | Power return | Connect to negative terminal of battery |
| 4 | VIN- | Power | Power return | Connect to negative terminal of battery |
| 5 | GND | Power | Chassis ground | |

Table 143: Pinouts for UIC to Receiver Communications Connector (J102)

| Pin | Signal | Type | Description | Comments |
|-----|---------|--------|--------------------------|--|
| A1 | UIC_RX+ | Input | RS-422 serial data in+ | RS-422 serial port for UIC to receiver communication |
| A2 | UIC_RX- | Input | RS-422 serial data in- | |
| A3 | UIC_TX+ | Output | RS-422 serial data out+ | |
| A4 | UIC_TX- | Output | RS-422 serial data out- | |
| A5 | A+ | Input | Wheel sensor input A (+) | Connects to the wheel sensor. |

^aA filter module (similar to Delta FL 75L07) in series with the power cable maybe needed to pass conducted emission.

^bA tubular ferrite bead (similar to Laird Technologies 28B0375-300) maybe attached to the data cable to reduce radiated emissions.

^cAll signal I/O are at LVCMOS levels (not 5V tolerant).

| Pin | Signal | Type | Description | Comments |
|-----|---------------------------|--------|--------------------------|-------------------------------|
| A6 | A- | Input | Wheel sensor input A (-) | Connects to the wheel sensor. |
| A7 | Reserved | | | |
| A8 | Reserved | | | |
| B1 | Reserved | | | |
| B2 | Reserved | | | |
| B3 | EVENT_OUT+ | Output | Event output (+) | |
| B4 | EVENT_OUT- | Output | Event output (-) | |
| B5 | B+ | Input | Wheel sensor input B (+) | Connects to the wheel sensor. |
| B6 | B- | Input | Wheel sensor input B (-) | Connects to the wheel sensor. |
| B7 | Reserved (do not connect) | | | |
| B8 | CGND | Power | Chassis ground | |

Table 144: Pinouts for UIC to IMU Communications Connector (J1401)

| Pin | Signal | Type | Description |
|-----|----------|--------------|-------------------------|
| 1 | 3.3V | Output Power | Positive 3.3 VDC supply |
| 2 | 3.3V | Output Power | Positive 3.3 VDC supply |
| 3 | 3.3V | Output Power | Positive 3.3 VDC supply |
| 4 | GND | Power | Digital ground |
| 5 | GND | Power | Digital ground |
| 6 | GND | Power | Digital ground |
| 7 | 15V | Output Power | Positive 15 VDC supply |
| 8 | GND | Power | Digital ground |
| 9 | -15V | Output Power | Negative 15 VDC supply |
| 10 | GND | Power | Digital ground |
| 11 | NSS | | SPI Slave Select |
| 12 | PWRDOWNx | Output | Power down warning |

^aAll signal I/O are at LVCMOS levels (not 5V tolerant).

^bAll signal I/O are at LVCMOS levels (not 5V tolerant).

| Pin | Signal | Type | Description |
|-----|----------------|--------|---------------------------------|
| 13 | SCK | Output | SPI Serial Clock |
| 14 | RESETIMUx | Output | Reset IMU |
| 15 | GND | Power | Digital ground |
| 16 | GND | Power | Digital ground |
| 17 | MISO | Input | SPI Master Input / Slave Output |
| 18 | NOGOx | | |
| 19 | MOSI | Output | SPI Master Output / Slave Input |
| 20 | DIO2 | | |
| 21 | GND | Power | Digital ground |
| 22 | GND | Power | Digital ground |
| 23 | IMU_TYPE0 | Input | Detect IMU type 0 |
| 24 | IMU_EVENT_IN | | |
| 25 | IMU_TYPE1 | Input | Detect IMU type 1 |
| 26 | IMU_EVENT_OUT | | |
| 27 | IMU_TYPE2 | Input | Detect IMU type 2 |
| 28 | GND | Power | Digital ground |
| 29 | IMU_TYPE3 | Input | Detect IMU type 3 |
| 30 | TXC- | | |
| 31 | IMU_DATA_OUT1- | | |
| 32 | TXC+ | | |
| 33 | IMU_DATA_OUT1+ | | |
| 34 | SYNC- | | |
| 35 | GND | Power | Digital ground |
| 36 | SYNC+ | | |
| 37 | IMU_DATA_OUT2- | | |
| 38 | TXD- | | |
| 39 | IMU_DATA_OUT2+ | | |

^aAll signal I/O are at LVCMOS levels (not 5V tolerant).

| Pin | Signal | Type | Description |
|-----|--------|--------------|--------------------------|
| 40 | TXD+ | | |
| 41 | GND | Power | Digital ground |
| 42 | GND | Power | Digital ground |
| 43 | 5.25V | Output Power | Positive 5.25 VDC supply |
| 44 | 5.25V | Output Power | Positive 5.25 VDC supply |
| 45 | GND | Power | Digital ground |
| 46 | 5.25V | Output Power | Positive 5.25 VDC supply |
| 47 | GND | Power | Digital ground |
| 48 | GND | Power | Digital ground |
| 49 | -5.25V | Output Power | Negative 5.25 VDC supply |
| 50 | -5.25V | Output Power | Negative 5.25 VDC supply |

^aAll signal I/O are at LVCMOS levels (not 5V tolerant).

A.18.4 HG1900 IMU to UIC Cable Assembly

The NovAtel part number for the HG1900 IMU to UIC interface cable is 01019762 (*Figure 92: OEM-IMU-HG1900 IMU to UIC Cable Assembly* below). This cable provides power to the IMU and enables communication between the IMU and the UIC.

Figure 92: OEM-IMU-HG1900 IMU to UIC Cable Assembly




Table 145: OEM-IMU-HG1900 IMU to UIC Cable Pinout

| J1 Pins (to HG1900) | J2 Pins (to UIC) |
|---------------------|------------------|
| 1 | A3 B5 |
| 2 | A4 |
| 3 | Lug Ring |
| 4 | A5 |
| 5 | A23 |
| 6 | B21 |
| 7 | B22 |
| 8 | A22 |
| 9 | B19 |
| 10 | B20 |
| 11 | A16 |
| 12 | A17 |
| | A11 to A12 |

A.18.5 LN200 IMU to UIC Cable Assembly

The NovAtel part number for the LN200 IMU to UIC interface cable is 01019763 (*Figure 93: OEM-IMU-LN200 IMU to UIC Cable Assembly* below). This cable provides power to the IMU and enables communication between the MIC and the IMU.

Figure 93: OEM-IMU-LN200 IMU to UIC Cable Assembly




Table 146: OEM-IMU-LN200 IMU to UIC Cable Pinout

| J1 Pins (to LN200) | J2 Pins (to UIC) |
|--------------------|------------------|
| A2 | B19 |
| A3 | B15 |
| B1 | B20 |
| B2 | B16 |
| C1 | A3 B14 |

| J1 Pins (to LN200) | | J2 Pins (to UIC) | |
|---------------------------|--|-------------------------|-----|
| D1 | | A24 | B24 |
| D2 | | A21 | B21 |
| D3 | | Lug Fork | |
| E1 | | A22 | |
| E2 | | B22 | |
| E3 | | B23 | |
| F3 | | A4 | |
| G2 | | A5 | |
| K1 | | B4 | B5 |
| L2 | | B18 | |
| L3 | | B17 | |
| | | A8 to A13 | |
| | | A11 to 12 | |
| | | A15 to A18 | |

APPENDIX B HG1700 IMU in Universal Enclosure




Important! Assemble in accordance with applicable industry standards. Ensure all ESD measures are in place, in particular, use a ground strap before exposing or handling any electronic items, including the IMU. Take care to prevent damaging or marring painted surfaces, O-rings, sealing surfaces and the IMU.

The following procedure provides the necessary information to install the HG1700 sensor into the Universal Enclosure (NovAtel part number 01018589), both illustrated below. The steps required for this procedure are:

- Disassemble the Universal Enclosure
- Install the HG1700 Sensor Unit
- Reassemble the Universal Enclosure

Figure 94: Required Parts



Use thread-locking fluid on all fasteners except for the flex cable connectors.



Torque values for all fasteners, including those for the flex cable, are as follows:


- Size 2-56: 0.20-0.25 N-m (1.8-2.2 lb-in) [28-35 oz/in]
- Size M4: 1.36-1.58 N-m (12.0-14.0 lb-in)
- Size 8-32: 1.55-1.70 N-m (13.7-15.0 lb-in)

B.1 Disassemble the Universal Enclosure

Disassemble the Universal Enclosure as follows:


1. Using a 3 mm hex bit, remove the M4 screws (they will be reused) and the base, as shown in *Figure 95: Remove Base* below. Ensure the O-rings come with the base when it is removed, and that they are not damaged.

Figure 95: Remove Base




2. Using a 30 mm socket, remove the jam nut and free the wiring harness connector from the body, as shown in *Figure 96: Disconnect Wiring Harness from Enclosure Body* on the next page. Retain the O-ring and the jam nut for reassembly.

Figure 96: Disconnect Wiring Harness from Enclosure Body



3. Using a 2.5 mm hex bit, unscrew the M4 screws and remove the IMU mounting plate, bracket and cable harness, as shown in *Figure 97: Remove IMU Mounting Plate and Bracket* on the next page:

Figure 97: Remove IMU Mounting Plate and Bracket




B.2 Install the HG1700 Sensor Unit

To install the HG1700 sensor unit in the Universal Enclosure:


1. Using a Phillips screwdriver, remove the 8-32 IMU mounting screws from the IMU mounting plate, as shown in *Figure 98: Remove IMU Mounting Screws* on the next page.

Figure 98: Remove IMU Mounting Screws



2. Check the connection of the internal cable harness to the board assembly and route as shown in *Figure 99: Connect IMU to IMU Mounting Plate* below. Before you connect the IMU cable harness, make sure the connector on the board assembly is clicked open. Connect the IMU cable harness to the IMU (fasten the 2-56 screws but do not use thread-locking fluid), then connect to the board assembly. Ensure the cable housing latches.


Figure 99: Connect IMU to IMU Mounting Plate




3. Being careful of the connectors and the orientation, align the pilot holes of the IMU with the

pilot pins of the mounting plate. Gently place the IMU and mounting plate together, being careful not to pinch the cable harness. Screw the IMU and mounting plate together, using thread-locking fluid on the 8-32 screws, as shown in *Figure 100: Installing IMU to Mounting Plate* below.


Figure 100: Installing IMU to Mounting Plate




4. Starting with the round pilot hole, shown in *Figure 101: Assemble Into Enclosure Body* on the next page, align the pilot holes of the assembled plate (noting the orientation) with the pilot pins of the enclosure body. Lower the assembly into place, then fasten using thread-locking fluid on the M4 screws.

Figure 101: Assemble Into Enclosure Body


5. Connect the internal cable harness to the enclosure body, as shown in *Figure 102: Fasten Internal Cable Harness* on the next page. During this step, ensure the connector O-ring (supplied with the connector of the internal cable harness) remains flat within the connector's groove, and make sure the groove is clean and free of debris. Fasten the connector to the enclosure body wall using the jam nut supplied with the connector. Apply thread-locking fluid then, with a 30 mm socket, tighten the jam nut to 6.9 N-m (61 lb-in/5.1 lb-ft).

Figure 102: Fasten Internal Cable Harness


6. Ensure the O-rings are in place. If they are not, as necessary, make sure the grooves of the enclosure base are clean and free of debris, using isopropyl alcohol. As shown in *Figure 103: Install O-rings* below, install the outer environmental and inner EMI O-rings in the enclosure base, being careful not to stretch or twist them. O-rings must remain flat within the grooves during the remainder of the assembly procedure.

Figure 103: Install O-rings

7. Clean the surface of the enclosure body, where it mates with the O-rings, using isopropyl alcohol. As shown in *Figure 104: Install Enclosure Body on the Base* on the next page, align the reference markers and pilot holes/pins of the enclosure body and base. Carefully lower the body onto the base, observing the O-rings and alignment of corners. Press the enclosure body into place, starting with the round pilot hole indicated in *Figure 104: Install Enclosure Body on the Base* on the next page.


Figure 104: Install Enclosure Body on the Base

8. While squeezing and holding the enclosure body and base together to maintain tight contact, carefully turn the assembly over and place it on its top, as shown in *Figure 105: Screw Enclosure Base to Body* below. Using a 3 mm hex bit, lightly fasten four equally spaced M4 screws to hold the parts together. Apply thread-locking fluid to each screw before inserting. Install the remaining screws in similar fashion. Tighten all screws then check all of them again for tightness. Tighten these screws to 1.36-1.58 N-m (12-14 lb-in). Do not over-tighten.

Figure 105: Screw Enclosure Base to Body

9. Ensure the product identification label, the logo plate and the center of navigation labels are properly affixed and contain the correct information. The final assembled unit will be similar to that shown in *Figure 106: Final Assembly* on the next page.

Figure 106: Final Assembly



APPENDIX C LN-200 IMU in Universal Enclosure




Important! Assemble in accordance with applicable industry standards. Ensure all ESD measures are in place, in particular, use a ground strap before exposing or handling any electronic items, including the IMU. Take care to prevent damaging or marring painted surfaces, O-rings, sealing surfaces, and the IMU.

The following procedure provides the necessary information to install the LN-200 sensor into the Universal Enclosure (NovAtel part number 01018590), both illustrated below. The steps required for this procedure are:

- Disassemble the Universal Enclosure
- Install the LN-200 Sensor Unit
- Reassemble the Universal Enclosure

Figure 107: Required Parts



Use thread-locking fluid on all fasteners except for the cable harness connectors.



Torque values for all fasteners, including those for the cable harness screws, are as follows:


- Size 6-32: 0.79-0.90 N-m (7.0-8.0 lb-in)
- Size M4: 1.36-1.58 N-m (12.0-14.0 lb-in)

C.1 Disassemble the Universal Enclosure

Disassemble the Universal Enclosure as follows:


1. Using a 3 mm hex bit, remove the M4 screws (they will be reused) and the base, as shown in *Figure 108: Remove Base* below.

Figure 108: Remove Base




2. While squeezing and holding the assembly tightly together, carefully turn the assembly over and set it down as shown in *Figure 109: Disconnect Wiring Harness from SDLC Card* below. Raise the enclosure body, and disconnect the internal cable harness at the SDLC board. Ensure the O-rings remain with the base when it is removed, and that they are not damaged.

Figure 109: Disconnect Wiring Harness from SDLC Card




3. Lift the enclosure lid off the assembly to expose the IMU bracket, shown in *Figure 110: IMU Bracket* below. Disconnect the harness at the SDLC card and remove.

Figure 110: IMU Bracket



4. Using a 3 mm hex bit, unscrew 4 mm screws and remove the IMU bracket with SDLC, as shown in *Figure 111: Remove IMU Bracket/SDLC* below.

Figure 111: Remove IMU Bracket/SDLC




C.2 Install the LN-200 Sensor Unit

To install the LN-200 sensor unit in the Universal Enclosure:


1. Using a 3 mm hex bit, remove original captive 6-32 screws and washers (4 each) from the LN-200 IMU. Add three washers under each of the original washers and fasten the IMU to the enclosure base, as shown in *Figure 112: Install LN-200 IMU to Base* on the next page. Use thread-locking fluid on each screw.

Figure 112: Install LN-200 IMU to Base




2. Using a long 3 mm hex bit, install the IMU bracket/SDLC to the base, as shown in *Figure 113: Install Bracket to Base* below. Use thread-locking fluid on each M4 screw.

Figure 113: Install Bracket to Base



3. Connect the cable harness to the board assembly and IMU, routing it as shown in *Figure 114: Making Connections* on the next page. Ensure latching of the cable connector housings and fasten the 6-32 screw at the IMU end using a 5/32" hex bit. Do not use thread-locking fluid and do not overtighten.


Figure 114: Making Connections



Make sure the tape of the harness is positioned for maximum protection.

4. While carefully holding the body over the bracket, connect the internal cable harness to the board assembly, as shown in *Figure 115: Connect Internal Cable Harness* below.


Figure 115: Connect Internal Cable Harness



5. Clean the surface of the enclosure body, where it will mate with the O-rings, using isopropyl


alcohol. While ensuring all wires will fit inside the bracket without being pinched, align the reference markers and pilot holes/screws of the enclosure body and base, and carefully lower the body onto the base, observing the O-rings and the alignment of corners. Start with the round pilot hole indicated in *Figure 116: Installing the Enclosure Body to the Base* below, then press the assembly into place.

Figure 116: Installing the Enclosure Body to the Base




6. While squeezing and holding the enclosure body and base together to maintain tight contact, carefully turn the assembly over and place it on its top, as shown in *Figure 117: Screw Enclosure Base to Body* on the next page. Using a 3 mm hex bit, lightly fasten four equally spaced M4 screws to hold the parts together. Use thread-locking fluid on all screws. Install the remaining screws in similar fashion. Tighten all screws to 1.36-1.58 N-m (12-14 lb-in). Do not over-tighten.

Figure 117: Screw Enclosure Base to Body



7. Ensure the product identification label, the logo plate and the center of navigation labels are properly affixed and contain the correct information. The final assembled unit is shown in *Figure 118: Final Assembly* below.

Figure 118: Final Assembly



APPENDIX D HG1700 IMU in SPAN HG Enclosure

The following procedure provides the necessary information to install the HG1700 sensor into the SPAN HG Enclosure (NovAtel part number 01017898). The steps required for this procedure are:

- Disassemble the SPAN HG Enclosure
- Install the HG1700 Sensor Unit
- Make Electrical Connections
- Reassemble the SPAN HG Enclosure



 Ensure you use a ground strap before installing the internal circuit boards. Do NOT scratch any surfaces of the unit.

Figure 119: Required Parts




| Reference | Description |
|-----------|--------------------|
| 1 | SPAN IMU Enclosure |
| 2 | HG1700 Flex Cable |
| 3 | HG1700 Sensor Unit |

D.1 Disassemble the SPAN IMU Enclosure

The SPAN IMU disassembly steps are as follows:


1. Remove the six bolts from the top cover using a hex key, as shown in *Figure 120: Bolts and Hex Key* on the next page:

Figure 120: Bolts and Hex Key



2. Set aside the bolts with their sealing washers.
3. Lift the top cover off the tube body and set it aside, as shown in *Figure 121: Lift Top Cover, Tube Body and 3 Ring Spacer Screws* on the next page.
4. Lift the tube body away from its base plate and set it aside.
5. Remove the 3 ring spacer screws and set them aside.


Figure 121: Lift Top Cover, Tube Body and 3 Ring Spacer Screws



D.2 Install the HG1700 Sensor Unit

To re-assemble the SPAN IMU with the HG1700 sensor, see *Figure 122: SPAN IMU Re-Assembly* on the next page and follow these steps:

1. Mount the HG1700 sensor with the attached #8 screws. Apply threadlock to the screw threads. Use a hex key to torque each screw to 10 in-lbs.
2. Fit the tube body over the HG1700 sensor and onto the base plate.


Figure 122: SPAN IMU Re-Assembly

D.3 Make the Electrical Connections

To make the electrical connections you need a 3/32" hex key, the flex cable and the partially assembled SPAN IMU from *Install the HG1700 Sensor Unit* on the previous page. Now follow these steps:

1. Attach the flex cable to the HG1700 sensor ensuring that all the pins are fully connected. Check also that the pins are fully seated and that the flex cable stiffener around the pins is not bent upward, see *Figure 123: Attach Flex Cable* on the next page.

Figure 123: Attach Flex Cable



2. Tighten the screws to 4 in-lbs.
3. Connect the opposite end of the flex cable to the corresponding connector on the IMU card ensuring that the contacts on the flex cable mate with the contacts on the connector, as shown in *Figure 123: Attach Flex Cable* above.
4. Check that the flex cable is locked in place.



Figure 124: Incorrect (Bowed) Flex Cable Installation below shows an incorrect installation of the flex cable where it is bowed in the middle. It will not operate properly in this position. *Figure 125: Correct (Flat) Flex Cable Installation* below shows the proper installation of the flex cable. Notice how the flex cable sits flush against the IMU surface.

Figure 124: Incorrect (Bowed) Flex Cable Installation






Figure 125: Correct (Flat) Flex Cable Installation



D.4 Re-Assemble the SPAN IMU Enclosure

Use a hex key to align the long bolts with the threaded holes in the base, as shown in *Figure 120: Bolts and Hex Key* on page 272. Apply threadlock to threads. Finger tighten all bolts and torque them in a cross pattern to 12 in-lbs. The fully assembled IMU enclosure is shown in *Figure 126: HG1700 SPAN IMU* on the next page.

Figure 126: HG1700 SPAN IMU



APPENDIX E LN-200 IMU in SPAN IMU Enclosure


The following procedure provides the necessary information to install the LN-200 sensor (NovAtel part number 80023515) into the SPAN IMU enclosure (NovAtel part number 01017656) using the LN-200 wiring harness (NovAtel part number 01017655). The steps required for this procedure are:

- Disassemble the SPAN IMU Enclosure
- Install the LN-200 Sensor Unit
- Make Electrical Connections
- Reassemble the SPAN IMU Enclosure



Important! Ensure you use a ground strap before installing the internal circuit boards. Do NOT scratch any surfaces of the unit.

Figure 127: Required Parts




| Reference | Description |
|-----------|-----------------------|
| 1 | SPAN IMU Enclosure |
| 2 | LN-200 Wiring Harness |
| 3 | LN-200 Sensor Unit |

E.1 Disassemble the SPAN IMU Enclosure

The SPAN IMU disassembly steps are as follows:


1. Remove the six bolts from the top cover using a hex key, as shown in *Figure 128: Bolts and Hex Key* below:

Figure 128: Bolts and Hex Key



2. Set aside the bolts with their sealing washers.
3. Lift the top cover off the tube body and set it aside.
4. Lift the tube body away from its base plate and set it aside, as shown in *Figure 129: Lift Top Cover and Tube Body* on the next page.


Figure 129: Lift Top Cover and Tube Body



E.2 Install the LN-200 Sensor Unit

To install the LN-200 sensor, follow these steps:

1. Mount the LN-200 sensor with the attached M4 screws. Apply threadlock to the screw threads. Use a hex key to torque each screw to 10 in-lbs.
2. Fit the tube body over the LN-200 sensor and onto the base plate.


Figure 130: SPAN IMU Re-Assembly

E.3 Make the Electrical Connections


To make the electrical connections you will need a 3/32" hex key, the wiring harness and the partially assembled SPAN IMU from *Install the LN-200 Sensor Unit* on the previous page. Now follow these steps:

1. Attach the LN-200 wire harness to the mating connector on the LN-200. Check that the connector is fully seated, as shown in *Figure 131: Attach Wiring Harness* on the next page.

Figure 131: Attach Wiring Harness




2. Connect the Samtec connector at the other end of the wiring harness to the corresponding connector on the internal IMU card, as shown in *Figure 132: Attach Samtec Connector* on the next page. Ensure that the connector is locked in place.

Figure 132: Attach Samtec Connector

E.4 Re-Assemble the SPAN IMU Enclosure

Use a hex key to align the long bolts with the threaded holes in the base, as shown in *Figure 128: Bolts and Hex Key* on page 279. Apply threadlock to threads. Finger tighten the 6 bolts then torque them in a cross pattern to 12 in-lbs. The fully assembled IMU enclosure is shown in *Figure 133: LN-200 SPAN IMU* on the next page.

Figure 133: LN-200 SPAN IMU



APPENDIX F Frequently Asked Questions

1. How do I know if my IMU is connected properly?
 - a. Refer to the **VERSION** log. If your IMU is communicating with a SPAN enabled receiver, the IMU details will be included in the log.
 - b. When powered, the HG-1700 IMU makes a noticeable humming sound. If no sound is heard, check that the cable between the receiver and IMU is connected properly.
 - c. Most IMUs do not make noise. Check that the IMU interface cable is properly connected to the receiver.
For the IMU-ISA-100C, IMU-FSAS, IMU-CPT, IMU-HG1900, IMU-ENC-LN200, IMU- μ IMU-IC and IMU-KVH1750, ensure the IMU interface cable is connected to an RS-422 capable port and the port is configured to use RS-422.
 - d. If the cable is connected properly, check the flex cable mounted on top of the IMU. Refer to the instructions in this manual on proper IMU installation to ensure that the cable is seated properly on the IMU pins. See *HG1700 IMU in Universal Enclosure* on page 254 or *LN-200 IMU in Universal Enclosure* on page 264 for more details.
 - e. Check the input power supply. A minimum of 12V should be supplied to the system for stable IMU performance. The supply should also be able to output at least 12W over the entire operating temperature range.
2. What is the minimum configuration I need to do to get the system running?
 - a. Set the IMU type and IMU communication port with the **CONNECTIMU** command.
 - b. Specify the translational offset between the IMU center of navigation and the primary GNSS antenna phase center with the **SETINSTRANSULATION** command.
 - c. Specify the rotational offset between the IMU Body frame and the Vehicle frame, with the **SETINSROTATION** command.
3. What types of IMUs are supported?

SPAN currently supports the following IMUs:

 - ADIS-16488 from Analog Devices
 - EG320N from Epson
 - HG1700, HG1900 and HG1930 from Honeywell
 - IMU-FSAS for iMar
 - IMU-KVH1750 and IMU-CPT from KVH
 - ISA-100C and μ IMU from Northrop Grumman LITEF
 - LN-200 from Litton
 - STIM300 from Sensoror

Use the **CONNECTIMU** command to specify the type of IMU used.
4. Why don't I have any INS data?
 - a. By default, the raw IMU data begins flowing at system start up. If there is no INS data, check that the system has been configured properly. See question 3 above.

b. If the **INSCOMMAND** command has been set to **START_FINE_TIME**, the RAWIMU logs are not available until the system has solved for time. This requires that an antenna is attached and satellites are visible to the system. You can verify that time is solved by checking the time status in the header of any standard header SPAN log such as BESTPOS. When the time status reaches FINETIME, the inertial filter starts and IMU data is available.

5. How can I access the inertial solution?

The GNSS+INS solution is available from a number of specific logs dedicated to the inertial filter. The **INSPOS** log, **INSPVA** log, **INSVEL** log, **INSSPD** log and **INSATT** log are the most commonly used logs for extracting the INS solution. These logs can be logged at any rate up to the rate of the IMU data (100, 125 or 200 Hz depending on your IMU model). The solution can also be triggered by the mark input signal by requesting the **MARKxPVA** logs.

6. Can I still access the GNSS-only solution while running SPAN?

The GNSS only solution used when running the OEM7 receiver without the IMU is still available when running SPAN. Logs such as the **PSRPOS** log and **RTKPOS** log are still available. The **BESTGNSSPOS** log is also available to provide the best available GNSS only solution. Any non-INS logs should be logged at a maximum rate of 5 Hz when running SPAN. Only INS-specific logs should be logged at rates higher than 5 Hz when running SPAN.

7. What will happen to the INS solution when I lose GNSS satellite visibility?

When GNSS tracking is interrupted, the INS solution bridges through the gaps with what is referred to as free-inertial navigation. The IMU measurements are used to propagate the solution. Errors in the IMU measurements accumulate over time to degrade the solution accuracy. For example, after one minute of GNSS outage, the horizontal position accuracy is approximately 2.5 m when using an HG1700 AG58. The SPAN solution continues to be computed for as long as the GNSS outage lasts, but the solution uncertainty increases with time. This uncertainty can be monitored using the **INSSTDEV** log or **INSSTDEVS** log.

8. Why can SPAN not align with my IMU-KVH1750?

SPAN requires that the IMU-KVH1750 be configured with non-default settings. If you have obtained your IMU-KVH1750 directly from KVH, or have manually changed the IMU configuration, refer to *Connect Directly to the IMU* on page 43 for information about configuring the IMU for operation with SPAN.



Further details on the command and logs in this section are available in the [OEM7 Commands and Logs Reference Manual](#).

APPENDIX F Importance of Antenna Selection

An antenna behaves both as a spatial and frequency filter, therefore, selecting the right GNSS antenna is critical for optimizing performance. An antenna must match the receiver's capabilities and specifications, as well as meet size, weight, environmental and mechanical specifications for the intended application.

Factors to consider when choosing a GNSS antenna include:

1. Constellation and signals

Each GNSS constellation and SBAS has its own signal frequencies and bandwidths. An antenna must cover the signal frequencies transmitted by the constellation and bandwidth supported by the GNSS receiver.

2. Antenna gain

Gain is a key performance indicator of a GNSS antenna. Gain can be defined as the relative measure of an antenna's ability to direct or concentrate radio frequency energy in a particular direction or pattern. A minimum gain is required to achieve a minimum carrier-to-power-noise ratio (C/No) to track GNSS satellites. The antenna gain is directly related to the overall C/No of the navigation GNSS receivers. Hence, antenna gain helps define the tracking ability of the system.

3. Element Gain

The element gain defines how efficient the antenna element is at receiving the signals. In any signal chain, you are only as good as the weakest link, so an antenna element with low element gain might be compensated by an increased low noise amplifier gain. However, the signal-to-noise ratio or C/No is still degraded.

4. Antenna beamwidth and gain roll-off

Gain roll-off is a factor of beamwidth, and specifies how much the gain changes over the elevation angle of the antenna. From the antenna's point of view, the satellites rise from the horizon towards zenith and fall back to the horizon. The variation in gain between zenith (directly overhead) and the horizon is known as the gain roll-off. Different antenna technologies have different gain roll-off characteristics.


5. Phase center stability

The phase center of the antenna is the point where the signals transmitted from satellites are collected. When a receiver reports a location fix, that location is essentially the phase center of the antenna.

The electrical phase center of any antenna will vary with the position of the transmitting signal it is receiving by as much as a few millimetres. As GNSS satellites move across the sky, the electrical phase center of the signal received will typically move with the satellite position unless the antenna has been carefully designed to minimize Phase Center Offset (PSO) and Phase Center Variation (PCV).

The PCO with respect to the Antenna Reference Point (ARP) is the difference between the mechanical center of antenna rotation and electrical phase center location. The PCO is also frequency dependent which means that there can be a different offset for each signal frequency. The PCV identifies how much the phase center moves with respect to the satellite elevation angles.

Figure 134: Plot of Good and Poor Antenna Phase Center Variation over Elevation Angle 0-90°



Many users can accept accuracies of less than a metre so these small phase center variations cause a negligible amount of position error. But if you require high precision, Real Time Kinematic (RTK) receivers can achieve position accuracies of 2-4 cm and a few millimetres of phase center error translates to a 10-15% error in reported position. For RTK survey applications, geodetic grade antennas offer superior PCO/PCV performance.

6. The application

An antenna has to meet the performance, environmental, mechanical, and operational requirements of the intended application. For example, GNSS antennas used for aviation applications should ideally be TSO/FAA certified and be rugged enough to handle extreme

temperatures and vibration profiles. Survey rover antennas should be able to survive rough handling by surveyors including a pole drop.

The table below highlights some of the important desirable features needed for a GNSS antenna based upon the user’s application.

| Desirable Feature | Survey | GIS | Reference Station | Aviation/Aerial Survey | Marine | Construction/Mining | Precision Agriculture | Vehicle Tracking | Dock Operations | Unmanned Aircraft | Unmanned Vehicle | Timing |
|--|--------|-----|-------------------|------------------------|--------|---------------------|-----------------------|------------------|-----------------|-------------------|------------------|--------|
| Low Profile | | | | • | | • | | • | | • | | |
| Ultra-low PCO/PCV | • | | • | | | | | | | | | |
| Low PCO/PCV | | • | | • | | • | • | | | • | • | |
| High Vibration | | | | • | | • | • | | • | • | • | |
| Rugged | • | • | • | | | • | | | • | | | |
| Single Frequency | | | | | | | | | | | | • |
| Multi Constellation | • | • | • | • | • | • | • | | • | • | • | |
| Multi Frequency (RTK) | • | • | • | | • | • | • | | • | • | • | |
| L-band frequency (Correction Services) | | | | | • | | • | | | | | |
| Narrow Bandwidth | | | | | | | | | | | | • |
| Weatherproof | • | • | • | • | • | • | • | • | • | • | • | • |
| Corrosion Resistant | | | • | | • | • | | | • | | | • |
| High Multipath Suppression | • | | • | | • | • | • | | • | | • | |
| Pole Mount | • | • | • | | • | • | | | • | | | • |
| Magnetic/Surface Mount | | | | | | • | • | • | • | | • | |
| TSO/FAA Certification | | | | • | | | | | | • | | |
| Extended Temperature Range | | | • | • | | | | | | • | | |
| Small Form-factor/ Lightweight | | • | | | | | | | | • | | |
| High Altitude Operation | | | • | • | | | | | | • | | |

APPENDIX G Replacement Parts for SPAN

The following are a list of the replacement parts available. Should you require assistance, or need to order additional components, contact your local NovAtel dealer or Customer Support.

| NovAtel Part | Part Description |
|---|---|
| IMU-CPT IMU-FSAS-EI IMU-H1900-CA50 IMU-H1930-CA50 IMU-H58 IMU-H62 IMU-IGM-A1 IMU-IGM-S1 IMU-ISA-100C IMU-KVH1750 IMU-ENC-LN200 IMU- μ IMU-IC OEM-IMU-ADIS-16488 OEM-IMU-EG320N OEM-IMU-HG1900 OEM-IMU-ISA-100C OEM-IMU-LN200 OEM-IMU-STIM300 OEM-IMU- μ IMU UIMU-H58 UIMU-H62 UIMU-LN200 | IMUs (see <i>Table 2: SPAN-Compatible IMUs</i> on page 25 for details) |
| OEM719 OEM729 OEM7700 OEM7720 PwrPak7 | Receivers |
| OEM-IMU-ADIS-MIC OEM-IMU-STIM-MIC | MEMS Interface Card (MIC) for MEMS IMUs |

| NovAtel Part | Part Description |
|-----------------------------|---|
| OEM-IMU-ISA-UIC | Universal IMU Controller (UIC) for OEM-IMU-ISA-100C |
| IMU Interface Cables | |
| 01018388 | iIMU-FSAS IMU with Wheel Sensor Interface cable |
| 01018966 | IMU-CPT IMU interface cable |
| 01018977 | Universal IMU Enclosure Interface cable |
| 01019007 | ADIS IMU Cable Kit |
| 01019013 | IMU-IGM Stack Up Cable |
| 01019015 | SPAN-IGM Auxiliary Port Interface Cable |
| 01019016 | IMU-IGM Interface Cable |
| 01019040 | SPAN-IGM/IMU-IGM Bracket Kit |
| 01019174 | OEM-IMU-STIM300 Cable |
| 01019211 | IMU-KVH1750 Interface Cable |
| 01019319 | IMU Enclosure Interface Cable |
| 01019393 | UIC to ISA-100C Interface Cable |
| 01019760 | UIC to μ IMU Interface Cable |
| 01019762 | UIC to HG1900 Interface Cable |
| 01019763 | UIC to LN200 Interface Cable |
| 60723136 | IMU Enclosure Power Cable |
| 60723137 | IMU Enclosure Wheel Data Cable |

